



# ThinManager 13 Thin Client Management Platform

Catalog Number 9541



User Manual

Original Instructions





	<b>Preface</b>	
	About This Publication .....	11
	Download Firmware, AOP, EDS, and Other Files .....	11
	Summary of Changes.....	11
	Additional Resources .....	11
	<b>Chapter 1</b>	
<b>Quick Setup Overview</b>	Microsoft .....	13
	ThinManager.....	13
	Installation & Activation .....	13
	ThinManager Database Encryption .....	14
	Configuration .....	18
	Network .....	19
	VLANs and Subnets.....	19
	Network Level Authentication (NLA) .....	19
	Hardware Introduction.....	20
	Results.....	20
	<b>Chapter 2</b>	
<b>Introduction</b>	ThinManager User Access .....	22
	Location Services .....	23
	ThinManager Interface.....	23
	Menus.....	25
	Customizing the Toolbar .....	29
	Icons .....	30
	Terminals.....	31
	Display Servers.....	32
	<b>Chapter 3</b>	
<b>Licenses</b>	ThinManager Master License .....	39
	ThinManager Redundancy .....	40
	Auto-synchronization for Redundancy .....	40
	Manual Synchronization for Redundancy.....	43
	ThinManager License Process .....	45
	FactoryTalk Activations.....	49
	FactoryTalk Activation Files .....	49
	<b>Chapter 4</b>	
<b>ThinManager System</b>	Windows Users .....	53
	ThinManager Security Group Users.....	53
	ThinManager Users .....	53
	ThinManager User Manual Unlock .....	54
	TLS Certificates.....	57
	API .....	57

## Sources

### Chapter 5

Remote Desktop Servers .....	61
Microsoft Configuration .....	61
Defining Remote Desktop Servers in ThinManager .....	61
Remote Desktop Server Graph .....	71
Remote Desktop Server Status .....	72
Remote Desktop Server Group .....	77
Containers .....	83
Containers on Thin Clients .....	84
Terminal Profile Setup for Containers .....	87
Containers on Servers using Windows Server 2019 .....	89
Container Host Server Installation .....	90
Install Container Images .....	92
Define the Container Host Display Server .....	93
Define the Container Host Display Client .....	94
Apply the Container Display Client to a Terminal .....	98
Install the TLS Certificates .....	100
IP Cameras .....	104
Configure the IP Camera .....	105
Define the IP Camera as a Display Server .....	105
IP Camera .....	107
Define the USB Camera as a Display Server .....	109
VNC Servers .....	112
Workstations .....	113
VCenter Servers .....	115
Snapshots .....	117
Adding a Virtual Server .....	119

## Content

### Chapter 6

Remote Desktop Services Display Clients .....	123
Desktop .....	124
Single Application Deployment with AppLink .....	131
Connection Options .....	141
Failover .....	151
Instant Failover .....	154
Camera Display Clients .....	155
Camera Overlay Template .....	157
Terminal Shadow .....	162
Shadow Any Terminal .....	162
Shadow a Specific Terminal .....	162
Shadow of the Terminal .....	162
Workstation Deployment .....	162
Step 1 – On the PC .....	162
Step 2 – Workstation Display Client .....	162
Add the Workstation Display Client to the Terminal .....	162
VNC Shadow .....	162
Shadow Any VNC Server .....	162
Shadow a Specific VNC Server .....	162
Virtual Screens .....	162

Virtual Screen Display Client Wizard .....	162
Predefined Templates .....	162
Add a Virtual Screen to a Terminal .....	162
Custom Overlays .....	162
Display Client Override on Virtual Screens .....	162
Terminal Shadow .....	171
Shadow Any Terminal .....	171
Shadow a Specific Terminal .....	174
Shadow of the Terminal .....	177
Workstation Deployment .....	180
Step 1 – On the PC .....	180
Step 2 – Workstation Display Client .....	182
Add the Workstation Display Client to the Terminal .....	185
VNC Shadow .....	190
Shadow Any VNC Server .....	190
Shadow a Specific VNC Server .....	192
Virtual Screens .....	195
Virtual Screen Display Client Wizard .....	195
Predefined Templates .....	198
Add a Virtual Screen to a Terminal .....	203
Custom Overlays .....	206
Display Client Override on Virtual Screens .....	216

## Chapter 7

### Devices

Terminal Configuration .....	221
Terminal Configuration Wizard in ThinManager .....	221
Active Directory User Login Account .....	243
Search for Active Directory User .....	243
Search for Active Directory Location .....	243
User Accounts in the Terminal Configuration Wizard .....	246
Copy Settings from another Terminal .....	259
Use Groups for Organization .....	261
Use Groups for Configuration .....	265
IP Configuration .....	275
ThinManager-ready Thin Client IP Configuration .....	276
Add and Configure Thin Clients .....	280
PXE Server and PXE Boot .....	281
Local WinTMC Configuration .....	294
WinTMC Configuration in ThinManager .....	296
Mobile Devices .....	300
Configure an iPad in ThinManager .....	300
Guided Access on the iPad .....	311
Configure an Android Device in ThinManager .....	314

## Chapter 8

### ThinManager Users

Introduction .....	321
ThinManager User Services Introduction .....	321
Permission-deployed Applications in ThinManager .....	323
Permission-deployed Applications Diagrams .....	323



ThinManager Access Group Creation .....	326
Add Access Group to a Display Client .....	329
Configure Terminals for Location Services .....	331
Create the ThinManager User without a Windows Account .....	335
Location Services Results .....	338
Log On to Location Services .....	339
Log Out of Location Services .....	342
Assign Roaming Display Clients to a ThinManager User .....	343
Roaming Display Clients in Location Services Diagrams .....	343
Create the ThinManager User via Active Directory .....	345
ThinManager Configuration Wizard .....	350
Add User-specific Display Clients .....	353
Log On with a ThinManager User Account .....	358
Log Out of Location Services .....	361
Roaming Applications for Non-domain Users .....	362
ThinManager User Groups .....	369
Add a ThinManager User to a ThinManager User Group .....	374
Batch Create ThinManager Users using Active Directory OU .....	377
Password and Account Management .....	381
Active Directory .....	381
Shortcut Method to Add Access Groups .....	389
ThinManager User Schedule .....	391
Card Readers and Fingerprint Scanners .....	393
Card and Badge Configuration for a ThinManager User .....	393
Fingerprint Reader .....	404
Location Services .....	413
Create a Location with the Location Configuration Wizard .....	414
Add a Location to a Terminal .....	422
Mobile Device Interactions with Location Services .....	427

## Chapter 9

### Locations

Unassigned Locations .....	431
Create an Unassigned Location .....	431
Fencing and Sub-Locations .....	437
Child Sub-locations .....	441
ThinManager User Access .....	445
Create a Location with Restricted Applications .....	446
Use Permissions to Restrict an Application .....	446
Add a Restricted Application to a Location .....	448
Put It Together .....	451
One QR Code, Multiple Actions .....	454
Calculate Permissions .....	457
Manual Interaction with Locations .....	459
Shadow .....	461
Transfer .....	464
Transfer at the Location .....	466
Clone .....	468
Addition of Resolver Codes with Mobile Device .....	471
Assignment of Resolvers .....	471

Register QR Codes with an Android Device.....	475
Bluetooth Beacons .....	478
Relevance Settings.....	479
Bluetooth Beacons Defined on an iPad.....	480
Bluetooth Beacons Defined on an Android .....	484
Wi-Fi Access Points .....	489
iPad-defined Wi-Fi Access Points .....	489
Android-defined Wi-Fi Access Points .....	493
GPS.....	496
iPad-Registered GPS.....	497
Android-registered GPS.....	500
Add Actions to Resolver Codes .....	504
Interact with the Location .....	507
Shadow .....	508
Forced Transfer.....	510
Transfer.....	513
Clone .....	517

## Chapter 10

### Events

Create a ThinManager Event .....	521
----------------------------------	-----

## Chapter 11

### Packages

Firmware, Packages, and Modules .....	525
Update Packages and Files.....	526
Customizing Packages .....	528
Configure Packages for a Model of Thin Client.....	532
Configure Packages for an Individual Thin Client .....	534

## Chapter 12

### Modules

Module List.....	537
Add a Module.....	539
Individual Module Details .....	542
ICA Modules .....	542
Keyboard Modules .....	543
Key Block Module.....	543
Key Block Single Key Module .....	543
Keyboard Configuration Module .....	544
On-Screen Keyboard Module .....	544
RF Ideas pcProx USB Module .....	545
Share Keyboard and Mouse Module .....	545
Language Modules .....	546
Language Selection Module.....	546
Local Storage Modules.....	546
USB Flash Drive Module.....	547
USB Memory Card Reader Module .....	547
Miscellaneous Modules .....	548
Add Serial Port .....	548
Barcode Configuration Module .....	548

Bluetooth Module .....	548
Firmware Update Module .....	548
Instant Failover Module .....	549
Local Print Module .....	550
MultiStation Configuration Module .....	551
Redundant Ethernet Module .....	551
Terminal Shadow Module .....	551
TermMon ActiveX Configuration Module .....	551
Time Zone Redirection Module .....	552
TMTerm DLL Configuration Module .....	552
USB to Serial Module .....	552
User Override Module .....	552
Mouse Modules .....	553
Locate Pointer Module .....	553
Mouse Configuration Module .....	553
PS/2 Mouse Module .....	554
Serial Mouse Driver .....	554
Share Keyboard and Mouse Modules .....	554
Network Modules .....	554
Domain Name System Module .....	554
Second Network Module .....	555
Third Network Module .....	555
RDP Modules .....	556
RDP Experience Module .....	556
RDP Port Module .....	556
RDP Serial Port Redirection Module .....	556
RDP Session IP Module .....	557
Smart Card Module .....	557
Relevance Modules .....	557
Bluetooth Module .....	557
iPhone Beacon .....	560
DigitalPersona UareU Fingerprint Reader .....	560
RF Ideas pcProx Modules .....	561
TermMon ActiveX Configuration .....	563
USB Flash Drive Module .....	564
Wavetrend Tag Reader (Package 5 Only) .....	564
Screen Saver Modules .....	564
MultiSession Screen Saver Module .....	564
Screen Saver Module .....	565
Sound Modules .....	566
Universal Sound Driver .....	566
TermSecure Modules .....	567
Touch Screen .....	568
Serial Drivers .....	568
USB Touch Screen Driver .....	570
Video Driver Modules .....	571
Custom Video Mode Module .....	571
Monitor Configuration Module .....	572



---

## ThinManager Server Configuration Wizard

### Chapter 13

Introduction Page.....	573
Unknown Terminals Page .....	574
Terminal Replacement Page .....	575
Historical Logging Page .....	576
SysLog Configuration Page .....	577
Event Log Tab .....	578
System Schedule Page .....	579
Security Groups Page.....	580
Event Selection Page .....	583
Email or Windows Messaging Recipients Page.....	584
Database Management Page .....	587
Multicast Configuration Page .....	590
HTTPS Server Settings Page .....	592
Shadow Configuration Page .....	595
Biometric Device Configuration Page .....	596
Docker Server Settings Page .....	597

## MultiMonitor

### Chapter 14

MultiMonitor Layout Page .....	600
MultiMonitor Display Client Selection Page .....	606
Override Function .....	607
Share Keyboard and Mouse Module.....	610
Master Thin Client Configuration .....	611
Replica Thin Client Configuration.....	612
Share Keyboard and Mouse with MultiMonitor.....	613

## Reports

### Chapter 15

Select Reports .....	615
Report Tab .....	616
Print Report .....	616
Report Template Installation.....	617

## Scheduling

### Chapter 16

System Scheduling of Reports.....	619
Schedule Configuration Backups .....	623

## TermMon ActiveX

### Chapter 17

Register the Control.....	628
Read-only Properties .....	628
Read-Write Properties.....	629
Events .....	629
Methods .....	630
Control Constants .....	632
TermMonEvent .....	633
TermMonCommand.....	633

---

TermMonConst .....	634
TermMonRelevance .....	634
<b>Glossary</b> .....	635

## About This Publication

This publication provides comprehensive information for users of ThinManager® thin client management software.

## Download Firmware, AOP, EDS, and Other Files

Download firmware, associated files (such as AOP, EDS, and DTM), and access product release notes from the Product Compatibility and Download Center at [rok.auto/pcdc](http://rok.auto/pcdc).

ThinManager resources are also available at [thinmanager.com](http://thinmanager.com).

## Summary of Changes

This publication contains the following new or updated information. This list includes substantive updates only and is not intended to reflect all changes.

Topic	Page
TLS Certificates	57
API	57
Events	521
HTTPS Server Settings Page	592

## Additional Resources

These documents contain additional information concerning related products from Rockwell Automation.

Resource	Description
EtherNet/IP Network Devices User Manual, <a href="http://ENET-UM006">ENET-UM006</a>	Describes how to configure and use EtherNet/IP® devices to communicate on the EtherNet/IP network.
Ethernet Reference Manual, <a href="http://ENET-RM002">ENET-RM002</a>	Describes basic Ethernet concepts, infrastructure components, and infrastructure features.
System Security Design Guidelines Reference Manual, <a href="http://SECURE-RM001">SECURE-RM001</a>	Provides guidance on how to conduct security assessments, implement Rockwell Automation products in a secure system, harden the control system, manage user access, and dispose of equipment.
Industrial Components Preventive Maintenance, Enclosures, and Contact Ratings Specifications, publication <a href="http://IC-TD002">IC-TD002</a>	Provides a quick reference tool for Allen-Bradley industrial automation controls and assemblies.
Safety Guidelines for the Application, Installation, and Maintenance of Solid-state Control, publication <a href="http://SGI-1.1">SGI-1.1</a>	Designed to harmonize with NEMA Standards Publication No. ICS 1.1-1987 and provides general guidelines for the application, installation, and maintenance of solid-state control in the form of individual devices or packaged assemblies incorporating solid-state components.
Industrial Automation Wiring and Grounding Guidelines, publication <a href="http://1770-4.1">1770-4.1</a>	Provides general guidelines for installing a Rockwell Automation industrial system.
Product Certifications website, <a href="http://rok.auto/certifications">rok.auto/certifications</a>	Provides declarations of conformity, certificates, and other certification details.

You can view or download publications at [rok.auto/literature](http://rok.auto/literature).



---

## Notes:

## Quick Setup Overview

This chapter guides you through the actions needed to build and activate a ThinManager system.

### Microsoft

Complete the following activities to install and configure Remote Desktop Services.

- Build a Remote Desktop Server with the supported Microsoft Windows Server operating system. Enable the Remote Desktop Services (Terminal Services) role. See [Microsoft Configuration on page 61](#).
- Create a Microsoft Remote Desktop Licensing Server and add Remote Desktop Services Client Access Licenses (RDSCALs) for each thin client. These were called Terminal Server Client Access Licenses (TSCALs) in Server 2003. The servers also require a normal CAL.
- It is common to have each ThinManager-managed terminal automatically log in to the Remote Desktop Server when it boots up. Therefore, create a unique Windows user for each ThinManager-managed terminal. For domain deployments, this is done within Active Directory. For work group deployments, this is done on each Remote Desktop Server. Add the users to the Remote Desktop Users group to make sure each user has permission to start Remote Desktop Server sessions on each Remote Desktop Server.
- Apply appropriate security to each user profile using the standard Microsoft techniques.

### ThinManager

This section describes how to install, activate, and configure ThinManager.

### Installation & Activation

Perform the following actions to install and activate ThinManager.


Install ThinManager software onto a computer to create ThinManager Server. During ThinManager installation, you are prompted to enter an optional Windows user account to set the ThinServer service login account.



It is recommended to use a Windows User as the ThinServer Service Account and follow the principle of least privilege. For more information about changing the ThinServer Service Account, see [Local Administrative Login for ThinServer on page 74](#).

- With ThinManager version 13, only 64-bit installations are supported, and 32-bit system installations are converted to 64-bit.
- During installation, there is a prompt to enable API. When enabled, User API Keys may be generated to execute endpoints. This can be enabled or

disabled later in the ThinManager Server Configuration wizard. See [API on page 57](#) for more information.

- If using ThinManager Master Licensing, follow these steps.
    - Create a Master ThinManager License, see [ThinManager Master License on page 39](#)
    - Verify that the License Mode is set to ThinManager Master License, see [Figure 38 on page 39](#)
    - Add enough Product Licenses for each ThinManager-managed terminal
  - If using FactoryTalk Activation, follow these steps. See [FactoryTalk Activations on page 49](#).
    - Install the FactoryTalk Activation Manager on each computer where ThinManager is installed
    - Download the FactoryTalk Activations for ThinManager
-  It is not a requirement that you install Factory Talk Activation Manager on the ThinManager server as you can have a centralized license server that is not on the ThinManager server.
- Change the License Mode in ThinManager to FactoryTalk Activation and assign the newly downloaded activations

## ThinManager Database Encryption


ThinManager 11.2 introduced a major encryption change, with the Advanced Encryption Standard, AES, used to encrypt the ThinManager database instead of the previous encryption key. This led to a few important changes.

The database requires a password to be used as part of the encryption key and prompts for a password as soon as it is installed or updated.

### Installation

When ThinManager 11.2 and later is first run, a dialog box appears, which prompts for a new database password.

**Figure 1 - Database Password Dialog Box**



1. Type a password into the Password field and click OK.



This password is used for the encryption key when the database is configured. There are no requirements for length or complexity. You can leave the Password field blank.

---

**IMPORTANT** In ThinManager 12 and earlier, the Database Password is unrecoverable if lost.

---

### Manual Backup

To manually back up the database, follow these instructions.

1. Choose Manage>Backup.

You are prompted to create a password for the backup.

**Figure 2 - Database Password Dialog Box**

2. Type the password into the Password field.
3. Type the password into the Verify field.
4. Click OK.

The manual backup password is for the copy of the database as a backup only, not the running database. The password allows a user to backup the configuration with a short password to send to support without the need to send the main database password.

There are no requirements for length or complexity of the backup password. The password can be blank.

---

**IMPORTANT** In ThinManager 12 and earlier, the Database Password is unrecoverable if lost.


---

### Manual Restore

To manually restore an encrypted backup, follow these steps.

1. Choose Manage>Restore.

The Database Password dialog box appears and prompts for the backup database password, not the original database password.

**Figure 3 - Database Password**

2. Type the Password and click OK.

### *Automatic Backup*


ThinManager can be configured to backup the configuration automatically. These automatic backups use the original password entered when ThinManager was configured.

The backups are now be saved in  
 C:\ProgramData\Rockwell Software\ThinManager  
 instead of C:\Program Files (x86)\Rockwell Software\ThinManager.

### *Database Password Change*

Prior to ThinManager 12.1, the running database password was unrecoverable if forgotten. With ThinManager 12.1, the running database password can be changed inside the ThinManager Server Configuration Wizard.

Users with the Administer ThinManager Servers role within ThinManager Security Groups can change the database password without knowing the previously set password. By default, Administrators Windows User Group has access to this role.

**Figure 4 - ThinManager Security Groups Page**

To change the database password, see [Database Management Page on page 587](#).

1. Navigate to the Database Management page of the ThinManager Server Configuration Wizard. See [ThinManager Server Configuration Wizard on page 573](#) for more information on how to open the wizard.

**Figure 5 - Database Management Page**

2. Type the new password in the New Database Password and Verify New Password fields.
3. Click Change Password to commit the changes.

A dialog box confirms the database password change was successful.

**Figure 6 - Successful Database Password Change dialog**

4. Click OK.

The database password is changed.

User accounts without the Administer ThinManager Servers security role can change the running database password. However, they are prompted to enter the current database password. See [Figure 7 on page 18](#).

**Figure 7 – Current Database Password field**


---

**IMPORTANT** Backups are still unrecoverable if the password is lost.

---

5. Click Vacuum to compress the running database, which is useful prior to database exportation or major database change.
6. Click Finish to exit the wizard.

## Configuration

Perform the following actions to configure ThinManager.

- Define the Remote Desktop Servers at Display Servers> Remote Desktop Servers>Remote Desktop Server Wizard. See [Defining Remote Desktop Servers in ThinManager on page 61](#) for information.
- Define the Display Clients at Display Clients> Remote Desktop Services>Display Client Wizard to deploy the applications. See [Content on page 123](#) for information.
- Define the Terminals at Terminal> Terminal Configuration Wizard. See [Terminal Configuration on page 221](#) for information.
- Associate the hardware to the Terminal configuration. See [Terminal Hardware Page on page 224](#) for information.

## Network

Thin clients and Remote Desktop Servers need a reliable network.

Verify that traffic is allowed on the network ports that follow in all software and hardware firewalls.

Port	Protocol	Description
UDP/67	DHCP – IP Address Assignment	Used by the PXE Server (if using PXE boot)
UDP/69	TFTP	
TCP/1494	Citrix ICA	Used by the ICA protocol (if using ICA instead of RDP)
UDP/1758	Multicast TFTP	Used if the default Multicast is enabled. If the network MTU size is not the default, then the packet size needs to be changed on the Multicast Configuration page of the ThinManager Server Configuration Wizard.
TCP/2031	Proprietary – Configuration	Used to pass the configuration from the ThinManager Server to the ThinManager thin clients
TCP/2376	Docker Client Communication	Needed to allow an encrypted channel for the terminal to connect to a Container Host to display the Container content.
TCP/3268	LDAP	Used for LDAP queries targeted at the global catalog with Active Directory
TCP/3389	RDP	Used by the Microsoft RDP protocol (if using RDP in v2.4.1 or later)
UDP/4011	DHCP	Used when the DHCP server is on the ThinManager server or when using the UEFI BIOS to boot.
UDP/4900	TFTP	Used for the TFTP download of the firmware
TCP/5900	Proprietary – Shadow	Used to shadow Terminals. This can be changed on the Shadow Configuration page of the ThinManager Server Configuration Wizard.
TCP/8443	HTTPS	(Optional) Can be configured and used to deliver some modules to thin client after the firmware is delivered. If closed, the module falls back to UDP 69 or UDP 4900, depending on the hardware, for module delivery. Can be changed in ThinServer.
ICMP Echo Packets (Ping)	ICMP	Used by WinTMC and Enforce Primary
DHCP	DHCP	Configure as needed

## VLANs and Subnets

You should have only one PXE server per network. It is beneficial to have a separate VLAN for each ThinManager Server pair that replies to PXE requests.

## Network Level Authentication (NLA)

ThinManager supports Network Level Authentication (NLA) with firmware package 7.1.113 and later.

- If a terminal has a valid Windows account entered in its configuration for an automatic login, then the client passes that info through NLA to authenticate. The client logs in and starts a session without operator awareness.
- If a terminal does not have a valid Windows account entered in its configuration, then an NLA login screen is displayed, which requires a valid user account and password. This gets passed to the Remote Desktop Server for the login. A Windows Security/Login page is never displayed.



NLA must be turned off on the Remote Desktop Servers if you want to use a Smart Card for authentication.

## Hardware Introduction

A ThinManager-ready thin client can use Dynamic Host Configuration Protocol (DHCP) or a static IP address for the client and ThinManager Server IP address. Its BIOS instructs it to download the firmware.

A ThinManager-compatible thin client is a thin client that lacks the ThinManager BIOS. ThinManager-compatible thin clients do not store static IP addresses; so, each of them requires DHCP to assign the client IP address. The ThinManager Server IP address and bootfile name can be provided by a DHCP server or the ThinManager PXE Server.

For more information visit [partners.thinmanager.com/terminals](https://partners.thinmanager.com/terminals)

Perform these actions with regard to hardware.

- Establish the IP addressing scheme for the ThinManager-managed terminals. ThinManager-ready thin clients can use Static IP or DHCP. ThinManager-compatible thin clients use PXE boot and, therefore, require DHCP.
  - To use Static addresses, open the IP Address menu on the thin client and enter the IP address of the thin client and the ThinManager Server.
  - To use DHCP, configure Option 066 for the IP address of the ThinManager Server, and Option 067 as acpboot.bin.
  - To use PXE Boot, enable PXE boot via Manage>PXE Server to launch the PXE Server wizard.
- Use either of the methods that follow to attach the terminals to ThinManager:
  - Turn on the terminal and select Create New Terminal when the offline terminals are listed.
  - Pre-create the terminals in ThinManager and select the proper terminal name when the terminal is turned on and offline terminals are listed.

## Results

Step 1: The clients connect to the ThinManager Server and download the firmware and configuration.

Step 2: The configuration sends the clients to the Remote Desktop Server to log in and start a session, and delivers any additional content assigned to the terminal's configuration.



## Introduction

ThinManager is a content delivery system that delivers content from a source to a device, where a user can view and interact with the content.

ThinManager is the management system. Relevance is an extension that allows you to grant or deny access based on location or user permissions.

This manual covers the variations of content deployment using ThinManager® with Relevance®.

**Figure 8 - Thin Manager Content Delivery by Device, User, or Location**



ThinManager is the tool that allows you to define sources, deploy content, configure devices, and allow user access. Each device connects to it to receive its configuration and instructions.

**Figure 9 - Typical Simple Deployment**




ThinManager is a software program that is installed on a computer or server in your system. The simplest use of ThinManager is to deploy a Windows application from a Windows Remote Desktop Server to a ThinManager-ready device. However, ThinManager provides many more options for deploying applications.

Figure 10 - Sources, Content, Devices, and User Options

Sources	Content	Devices	Users
<b>Display Servers</b>	<b>Display Clients</b>	<b>Terminals</b>	
Remote Desktop Servers	Windows Applications	ThinManager Ready thin clients	Manual Login
Virtual Servers	Workstations	ThinManager Compatible thin clients	Auto-Login
Workstations	IP Cameras	WinTMC on PC	Relevance User
IP Cameras	Shadowed Terminals	iTMC on iPad	HID Card and Reader
Terminals via Shadow	VNC Server Shadow	AndroidTMC on Android	Fingerprint Reader
VNC Servers			Smart Card


These options allow you to tailor a customized content delivery system.

Figure 11 - ThinManager Content Deployment



ThinManager centralizes content servers and deploys the content to the plant floor, office, or control room as needed.


Figure 12 - Standard Industrial Architecture



An industrial network pulls the I/O to the PLCs. The Remote Desktop Server hosts the sessions that run the HMI and talk to the PLCs to gather and display the data.



## ThinManager User Access

ThinManager can provide additional security to the system that controls deployment of applications to users. This was formerly called TermSecure and is now integrated into ThinManager with Relevance as Access.

**Figure 13 - Access**

## Location Services

The Location Services component builds on the ThinManager system in that it adds location to the application delivery. This allows content to be sent to the right person, at the right place, at the right time.

**Figure 14 - Stylized Content Deployment****Figure 15 - Content Deployment in ThinManager Tree**


You create Locations in Location Services and send content to the locations. These can be assigned locations with a tethered terminal, or they can be unassigned locations that have no terminal at the location and are accessed solely by mobile devices.

Locations can be resolved manually or by using QR codes, Bluetooth beacons, Wi-Fi networks, or GPS.

## ThinManager Interface


This section leads you through the important features on the ThinManager interface. Press F1 to find specific information while in the ThinManager program.

Figure 16 - ThinManager Interface



The ThinManager Interface has several components.

Note	Component	Description
1	Application Button	Launches the ThinManager Server Configuration wizard to configure global ThinManager settings.
2	Quick Access Toobar	Click the pull-down arrow to customize this toolbar. Add icons of commonly used tasks from the menu bar, like Restart, Send Message, Modify, Backup, and Shadow.
3	Menu Bar	Separates the functions into categories.
4	Ribbon Bar	Contains icons for the functions. Hide when unused via the Minimize the Ribbon command on the Quick Access pull-down arrow menu.
5	Detail Pane Tabs	Allows you to choose details to display. The tabs and detail selections change depending on what is selected in the tree. Drag the tabs to change the order.
6	Tree	Displays the components of ThinManager with the Outlook Bar Tab control so the branches of the ThinManager tree are shown one at a time.
7	Detail Pane	Displays the information for the selected tab for the highlighted tree component. The Detail Pane can be torn away by dragging the tab away from ThinManager. The Detail Pane can be re-docked by dragging the pane title bar back to the tabs.
8	Tree Selector	The selector buttons at the bottom of the tree control select which branch is active and visible. These can be pulled upwards to stack the buttons, or pulled down to minimize the buttons.

**Figure 17 - Tree Selector Buttons - Minimized Buttons at the Bottom/Buttons Stacked**


Stacked the buttons allow you to make a quicker switch, but the minimized buttons allow more room to show components in a larger system.

There is an arrow that allows customization tasks—you can hide or reorder the branches of the tree.

## Menus


The menus of ThinManager use the Microsoft Outlook ribbon but contain similar functions as previous versions.

This is a brief description. Many of these functions will be explained in greater detail in the sections of the manual that cover setup and configuration.

**Figure 18 - Edit**


Feature	Description
Add ThinManager Server	Allows connection to, and management of, other ThinManager Servers from your local interface. Appropriate permissions on the remote computer are required for access. Intended for a remote connection, not the partner in a synchronized pair.
Disconnect	Breaks the connection to the remote ThinManager Server.
Remove	Deletes the remote ThinManager Server from the local list. Does not affect the remote ThinManager Server.
Refresh	Refreshes the data.
Modify	Opens the configuration wizard for a highlighted tree component.

Feature	Description
Add	Launches a new configuration wizard for a highlighted tree component.
Add Group	Launches a group configuration wizard for a highlighted tree component.
Copy	Launches a dialog that allows you to create a copy of a highlighted item.
Delete	Deletes a highlighted item.
Rename	Renames a highlighted item.
Lock	Locks a highlighted item.
Unlock	Unlocks a locked item.
Find	Use to search for names, descriptions, IP addresses, and other data in the tree.
Find Next	Repeatedly search for a term.

**Figure 19 - Manage**


Feature	Description
Packages	Opens the Package Manager window.
Restore	Opens a file browser to let you restore a previously saved ThinManager configuration.
Backup	Opens a file browser that lets you back up and save a ThinManager configuration for emergency restoration. This backup can be automated using the Scheduler.
Restore Biometric Database	Opens a file browser to let you restore a previously saved Biometric database.
Backup Biometric Database	Opens a file browser to let you save your Biometric data.
Synchronize	Use to manually synchronize a pair of ThinManager Servers if you are not using the recommended automatic synchronization.
PXE Server	Launches the PXE Server configuration wizard.
ThinManager Server List	Opens the ThinManager Server configuration wizard for automatic synchronization.
DNS Configuration	Opens the DNS configuration wizard to allow ThinManager to resolve names using your DNS.
Configure Default Terminal	Allows configuration of the default Terminal if you are using auto-creation of Terminals.
Language	
Web Management	Allows web access management when it is implemented in the future.
Manage Accounts	Allows password management of Active Directory accounts. See <a href="#">Manage Accounts Management on page 381</a> for details.
Synchronize Passwords	Allows synchronization of passwords between ThinManager and the Active Directory for the chosen accounts. See <a href="#">Synchronize Password on page 387</a> for details.
Settings (Active Directory)	Allows you to use Active Directory, set Password Settings, and select whether to use Windows Security Groups or Active Directory Organizational Units. See <a href="#">Settings on page 388</a> for details.
Manage Resolvers	Opens the Resolver Management window that lets you Add, Delete, and Edit resolvers added through a mobile device. See <a href="#">Mobile Device Interactions with Location Services on page 427</a> for details.
Settings (Resolver)	Opens the ThinManager Settings window that lets you define iBeacons and manage Bluetooth filtering.
Access Groups	Opens the Access Groups dialog box where you create access groups for ThinManager User Services. See <a href="#">ThinManager Access Group Creation on page 326</a> for details.
TLS Certificate	Opens the Manage TLS Certificates wizard, where you can generate new certificates, copy, or import certificates or keys. These certificates include Browser Custom CA Certificate, Docker Server CA Certificate, HTTPS Server Certificate, and Syslog Client Certificate. See <a href="#">TLS Certificates on page 57</a> for details.

Figure 20 - Install



Feature	Description
Firmware Package	Updates a firmware package, which consists of a firmware version and the modules for that version.
Firmware	Updates the firmware without an update of modules.
Modules	Updates a module without an update of the firmware.
Boot Loader	Updates the boot loader used in PXE boot.
Chain Loader	Updates the chain loader used in PXE boot.
Licenses	Launches the Licensing window to add licenses to ThinManager.
License Mode	Selects between the traditional ThinManager licensing or the Rockwell Automation FactoryTalk activation.
TermCap Database	The Terminal Capability Database has information on the abilities of every ThinManager-ready thin client. A new version is released with every newly supported thin client. Service packs update the TermCap but this allows you to update the TermCap if a new unit you have is not listed.
Reports	Adds a report and SQL query if you need a newly released one before it is added in a service pack.


Figure 21 - Tools



Feature	Description
Restart	Resends the configuration to a highlighted terminal.
Reboot	Cycles power to a highlighted terminal and reloads the firmware and configuration.
Reboot Server	Cycles power to a highlighted Remote Desktop Server. Although it will give you a warning prompt, do not use unless you are serious about restarting a Remote Desktop Server. All sessions end abruptly when the server is rebooted.
Power Off	Powers off a highlighted virtual machine or thin client with a Wake-On-LAN function enabled.
Power On	This will power on a highlighted virtual machine or a thin client with a Wake-On-LAN function enabled.
Calibrate Touchscreen	Initiates the calibrate touchscreen program on a highlighted terminal.
Send Message	Sends a message to a highlighted terminal.
Enable	Re-enables a disabled terminal, Remote Desktop Server, or location.
Disable	Disables a highlighted terminal, Remote Desktop Server, or location. A terminal stops showing the session but shows a ThinManager splash screen. The session continues to run on the Remote Desktop Server. A disabled Remote Desktop Server kicks off all the ThinManager thin clients from the Remote Desktop Server, and forces them to a backup server. The Remote Desktop Server is still functional and allows RDP connections from other sources. This is useful to force failover to a backup so you can update your Remote Desktop Servers on the fly. A location will stop showing the session when disabled.
Clear	Clears the event log for the highlighted Terminal or Remote Desktop Server.




Figure 22 - View




Feature	Description
Status Bar	Check to display the status bar at the bottom of the ThinManager interface.
Show Connected Only	Hides any unpowered or unconnected thin clients. Although it can be useful, it is best left checked as it can be confusing when the unpowered terminal is hidden.
Options	Launches the Options window with the settings for license notifications, and allows new terminals and users to initiate a Terminal Configuration Wizard or ThinManager User Configuration Wizard.
Application	Use to choose the color scheme for ThinManager.
Tabs	Use to choose the tab scheme for ThinManager.
Disable Tab Reordering	Check to lock the Detail Pane tabs in their current position. Normally, the tabs can be rearranged.
Disable Tab Tear-Off	Check to lock the Detail Pane tabs in their current position. Normally, the tabs can be dragged free from the ThinManager console.
Select Reports	Opens the Select Reports window that lets you select the reports for the various components. Select the Report tab for a highlighted component to see the actual report or use the Scheduler to generate a report automatically.
Print	Use to print a highlighted Report tab.

Figure 23 - Remote View



Feature	Description
Interactive	Check to click into and control a shadow session. Clear this option for view-only mode.
Scaled to Window	Shrinks the shadowed terminal to fit into the details pane. Clear this option to show it in the correct resolution with scroll bars to give you a closer view.
Go Full Screen	Makes the shadowed terminal's image full screen. Use CTL+ALT+Break to undo full screen. To close ThinManager, use ALT+F4.
Send Keys	Sends the selected key sequence to a shadowed terminal.
Zoom In	Use to click inside a shadow session and zoom in for detail. This option is dimmed until the Interactive checkbox is cleared.
Zoom Out	Use to click inside a shadow session and zoom out for an overview. This option is dimmed until the Interactive checkbox is cleared.
Connect Options	Use to configure the RDP settings when you connect to a Remote Desktop Server console from ThinManager.



**Figure 24 - Help**

Feature	Description
About	Shows the version and build number of ThinManager.
Help	Launches the ThinManager Help.

## Customizing the Toolbar

Select More Commands from the Customize Quick Access Toolbar pull-down menu to launch the Customize window and add icons of frequently used functions.




**Figure 25 - Customize Quick Access Toolbar Menu**

Figure 26 - Customize Window



Feature	Description
Choose commands from	Use to select commands from each group.
Commands	Lists the available command options. Select one and click Add to move it to the right-hand list to add it to the Quick Access bar. Adjust the order using the up and down arrows.
Show Quick Access Toolbar below the Ribbon	Check to move the Quick Access bar.

Figure 27 - Quick Access Toolbar



The icons for the selected functions appear in the Quick Launch menu. Click one to launch that function or wizard.

Icons

ThinManager tree icons show the status of components.

ThinManager Server

The ThinManager Server branch has two ThinManager icons.

**Figure 28 - ThinManager Server Tree Icons**

Icon	Description
Green ThinManager	ThinManager console is talking to the ThinServer.
Red ThinManager	ThinManager console is not talking to the ThinServer. Right-click on the icon and select Reconnect from the menu.



Note: You should not add the second ThinManager Server of a synchronized pair in the tree of your Primary ThinManager Server. The data is the same. Adding a second ThinManager Server is intended to display a remote connection to a different system.

## Terminals

The Terminal branch of the ThinManager tree has several different icons.

### Terminal Tree Icons




Icon	Represents
Dual Monitor	A Terminal Group
Lock	A Terminal with an open configuration wizard
Exclamation Mark	A Terminal with a configuration change that needs a restart
Globe	A Terminal with an assigned Location, which is shown in parentheses
Green Monitor	A Terminal that is booted and connected to the ThinManager Server
Yellow Monitor	A Terminal that is going through the boot process
User	A Terminal that has a ThinManager User logged in to the Terminal. The user name is shown in parentheses.
Red Monitor	A Terminal that is either turned off or not able to communicate with the ThinManager Server
Red X	A Terminal that was Disabled using the Tools>Disable command

## Display Servers

The Display Server tree has several different icons.

Figure 29 - Display Server Tree Icons



Icon	Represents
Blue Server	The Remote Desktop Server branch
Server with Folder	A Remote Desktop Server Group
Server with Virtual Boxes	A Virtual Server defined through the VCenter Server tool
Blue Camera	The Camera branch
Camera with Folder	A Camera Group
Gray Camera	A Camera
Blue Eye	The VNC Server branch
Cyan Eye with Folder	A VNC Server Group
Cyan Eye	A VNC Server

Figure 30 - Remote Desktop Server Icon Colors



The color stripe on a Remote Desktop Server icon indicates its connection status.

Icon	Represents
Server with Gray Stripe	A Remote Desktop Server without an administrative account
Server with Green Stripe	A Remote Desktop Server with a connection to the ThinServer using an administrative account
Server with Red Stripe	A Remote Desktop Server with an account but unable to make a connection to the ThinServer




Note: A red stripe does not mean that a Terminal cannot connect to the Remote Desktop Server. It only indicates the status of the ThinManager Server to Remote Desktop Server communication.

### Display Clients


The Display Client branch has several icons.

**Figure 31 - Remote Desktop Services Display Client Branch Icons**




Icon	Represents
Dark Gray Server and Blue Monitor	The Display Client Tree Branch
Blue Server and Blue Monitor	The Remote Desktop Services Branch
Light Gray Server and Blue Monitor	A Remote Desktop Services Display Client
Gray Server	A Remote Desktop Server assigned to a Display Client

Figure 32 - Other Display Client Branch Icons



Icon	Represents
Dark Gray Server and Blue Monitor	The Display Client Tree Branch
Blue Server and Blue Monitor	The Remote Desktop Services Branch
Blue Camera and Blue Monitor	The Camera Branch
Gray Camera and Blue Monitor	A Camera Display Client
Gray Camera inside a Blue Box	A Camera Overlay assigned to a Display Client
Dark Blue Terminal and Blue Monitor	The Terminal Shadow Branch
Light Blue Terminal and Blue Monitor	The Terminal Shadow Display Client
Dark Blue Virtual Boxes and Blue Monitor	The Terminal Shadow Branch
Medium Blue Virtual Boxes and Blue Monitor	The Workstation Display Client
Dark Blue Eye and Blue Monitor	The VNC Server Branch
Light Blue Eye and Blue Monitor	The VNC Server Display Client

**Figure 33 - Virtual Screen Display Client Branch Icons**

Icon	Represents
Dark Blue Monitor and Blue Monitor	The Virtual Screen Branch
Blue Monitor and Blue Monitor	The Virtual Screen Display Client
Blue Square within a Blue Monitor	The Virtual Screen Overlay
A Light Gray Server and Blue Monitor	A Display Client. Assigned to the Overlay
A Light Gray Server	A Remote Desktop Services Server assigned to the Display Client on the Overlay

### Lightning Bolts

Icons with lightning bolts indicate the connection status.


**Figure 34 - Lightning Bolts**

Icon	Represents
Green Lightning Bolt	Active connection that is visible in the foreground
Yellow Lightning Bolt	An active connection that is not displayed, usually running in the background. An Instant Failover display client will show servers with a green and a yellow to show the main and secondary session.
Red Lightning Bolt	Defined connection that is not active.



ThinManager Users

Figure 35 - ThinManager Users Tree




Icon	Represents
Light Blue Person	The ThinManager User Tree Branch
Two People	A ThinManager User Group
Red Person	A ThinManager User
Red Person with Blue Monitor	A ThinManager User that is logged in to a Terminal or Location. The Terminal is displayed in parentheses.

Locations

The Globe icon represents the Locations Tree Branch, Locations, Parent Locations, and Sub-Locations.


Figure 36 - Locations Tree





VCenter Servers

Figure 37 - VCenter Servers



Icon	Represents
Green and Yellow Squares	Either the VCenter Tree Branch or a VCenter Server
Gray Building	A VCenter Server Datacenter
Blue Virtual Squares	A Virtual Machine, both server and workstation

**Notes:**

## Licenses


ThinManager has two license modes, ThinManager Master License and FactoryTalk Activations.

To choose the licensing mode, follow these steps.

7. Choose Install>License Mode from the ThinManager menu.

The License Mode dialog box appears.

**Figure 38 - License Mode**



- a. To choose ThinManager Master License Mode, click ThinManager Master License.
  - b. To choose FactoryTalk Activations License Mode, click FactoryTalk Activations.
8. Click OK.

## ThinManager Master License

ThinManager Master License is the traditional ThinManager license, which is comprised of three components.

Component	Description
Product License	Provides permission for terminals to connect, and controls which features and functions the terminals have. Purchase from a ThinManager distributor.
Master License	A container for the Product Licenses, which is created by the user on the ThinManager License site and has the Product Licenses added to it. Activated with the Installation ID from the Licensing dialog box of the ThinManager application.
Activated License File	A file generated from the Master License and Installation ID on the ThinManager License site. Download and apply to ThinManager.

Product Licenses are connection licenses purchased from ThinManager distributors. V-FLEX licenses, which are flexible volume licenses, are available.



Greater detail on ThinManager licenses can be found in the ThinManager Knowledge Base at [https://kb.thinmanager.com/index.php/License\\_Activation](https://kb.thinmanager.com/index.php/License_Activation). Another good reference can be found here, [https://rockwellautomation.custhelp.com/app/answers/answer\\_view/a\\_id/1090218/loc/en\\_US#\\_\\_highlight](https://rockwellautomation.custhelp.com/app/answers/answer_view/a_id/1090218/loc/en_US#__highlight).

## ThinManager Redundancy

Standard product licenses are available with redundancy. Enterprise server licenses include full redundancy.

Redundancy Type	Description
Full Redundancy	Licenses a synchronized pair of ThinManager servers so that one ThinManager server is available if the other is offline. Both synchronized ThinManager servers have the administrative console available.
Mirrored Redundancy	Licenses a synchronized pair of ThinManager servers so that one is available if the other is offline, but this option only activates the administrative console on one ThinManager server—the one designated as the primary ThinManager server. The other ThinManager server is designated as the secondary ThinManager server. From the secondary server, terminals can boot, but the ThinManager console is view-only.
Stand-Alone ThinManager	Licenses one stand-alone ThinManager. If the stand-alone ThinManager goes offline, the terminals continue to run. However, if a terminal reboots, it waits until the ThinManager server is online before it can rejoin the system.

## Auto-synchronization for Redundancy


To have a Redundant ThinManager system, configure Auto-synchronization as described in the following steps.

1. From the menu bar on your Primary ThinManager Server, choose Manage>ThinManager Server List.

The ThinManager Server List Wizard Introduction page appears.

2. Click Next.

The Auto-synchronization Selection page appears.

**Figure 39 - Auto-synchronization Select Page**


**ThinManager Server List Wizard**

**Auto-synchronization Selection**  
Check Automatic Synchronization to automatically synchronize the configuration of two ThinManager servers.

Check the box if you want to use Automatic Synchronization between two ThinManager servers. Leave the box unchecked if you want to use manual synchronization.


If you have mirrored licenses, then you must use Automatic Synchronization.

☒ Automatic Synchronization

< Back   Next >   Finish   Cancel   Help

3. Check Automatic Synchronization and click Next.

The Auto-synchronization Configuration page appears.

**Figure 40 - Auto-synchronization Configuration Page**


**ThinManager Server List Wizard**

**Auto-synchronization Configuration**  
Define the primary and secondary ThinManager servers. These servers will be synchronized.

Primary ThinManager Server Edit

Name

IP Address

Secondary ThinManager Server Edit

Name

IP Address

Additional ThinManager Servers

< Back   Next >   Finish   Cancel   Help

4. Click Edit in the Primary ThinManager Server section.

The Enter the Primary ThinManager Server Information dialog box appears.

**Figure 41 - Enter the ThinManager Server Information**

Enter the Primary ThinManager Server Information

ThinManager Server: Documentation

ThinManager Server IP: 255 . 255 . 255 . 255

Buttons: OK, Cancel, Discover

- a. Enter the name of your Primary ThinManager Server in the ThinManager Server field.
- b. Click Discover to automatically populate the IP address in the ThinManager Server IP field. However, this field can be completed manually.



Do not click Discover to complete the ThinManager Server IP field manually.

- c. Click OK.
5. Repeat step 4 for the Secondary ThinManager Server.

**Figure 42 - Auto-synchronization Configuration Page**

ThinManager Server List Wizard

**Auto-synchronization Configuration**  
Define the primary and secondary ThinManager servers. These servers will be synchronized.

Primary ThinManager Server

Name: Documentation

IP Address: 10.3.10.153

Secondary ThinManager Server

Name: Engineering\_120

IP Address: 10.3.10.120

Additional ThinManager Servers

Buttons: < Back, Next >, Finish, Cancel, Help


6. On the Auto-synchronization Configuration page, click Finish to begin auto-synchronization.

---

**IMPORTANT** With a Mirrored Redundancy License, it is important to select the Primary and Secondary ThinManager Servers carefully because only the Primary ThinManager Server has an administrative console. The Secondary ThinManager Server administrative console is view-only.

---

7. Highlight the ThinManager Server.

**Figure 43 - Synchronization Tab**

- a. On the Synchronization tab, verify that the server's Synchronization State indicates 'Synchronized'.

## Manual Synchronization for Redundancy

Follow these steps to use manual synchronization with a redundant ThinManager system.


1. On your Primary ThinManager Server, in the ThinManager Server tree, highlight the green ThinManager icon.
2. From the menu bar, choose Manage>ThinManager Server List.

The ThinManager Server List Wizard Introduction page appears.


3. Click Next.

The Auto-synchronization Selection page appears.

**Figure 44 - Clear Automatic Synchronization Checkbox**




4. For manual synchronization, clear the Automatic Synchronization checkbox.

 With mirrored licenses, you must use Automatic Synchronization.

5. Click Next.

The ThinManager Server List page appears with your network ThinManager Servers displayed.

**Figure 45 - ThinManager Server List Page**




6. (Optional) Highlight a server and use the up and down arrows to change the order of the servers in the list.



7. (Optional) Highlight a server and click Remove Server to eliminate it from the ThinManager server list.
8. (Optional) Click Add Server to add a server to the list.

A dialog box appears, in which you can define a new ThinManager server.

**Figure 46 - ThinManager Server Definition Dialog**



The dialog box is titled "Enter the new ThinManager Server Definition" with a close button (X) in the top right corner. It contains two input fields: "ThinManager Server" and "ThinManager Server IP". The "ThinManager Server" field is empty. The "ThinManager Server IP" field contains the text "255 . 255 . 255 . 255". Below the "ThinManager Server IP" field is a "Discover" button. To the right of the input fields are two buttons: "OK" and "Cancel".

- a. Enter a ThinManager Server name.
  - b. Click Discover to automatically populate the ThinManager Server IP field. Also, this field can be completed manually.
  - c. Click OK.
9. Click Finish to complete your changes.


## ThinManager License Process

Follow these steps to license ThinManager.

1. Purchase a Product License from a ThinManager distributor.
2. If you have a redundant product license, synchronize two ThinManager Servers. See [Auto-synchronization for Redundancy on page 40](#).
3. Go to the ThinManager Licensing site at <https://thinmanager.com/licensing/>.
4. Log in to the site or register as a new user, and log in with the new user account.
5. Click the Create Master License link on the License Site menu bar.
6. Enter a description and complete the other fields.
7. Click Create.

The License site displays the Master License.


Figure 47 - Master License



- 8. Click Add Product License and enter the Product License.
- 9. Once the Product License is added, click Activation.

The Licensing dialog box appears.

Figure 48 - Stand-alone ThinManager Installation ID



- 10. Enter the Installation IDs, which are found in the Licensing dialog box when you choose Install>Licenses.

A stand-alone ThinManager has a single Installation ID at the bottom of the Licensing dialog box.

A synchronized ThinManager system displays both the Primary and Secondary Installation IDs at the bottom of Licensing dialog box.

**Figure 49 - Primary and Secondary Installation IDs**

The screenshot shows the 'Licensing' dialog box. At the top, there is a 'Master License Number' field and two buttons: 'Install License' and 'Delete License'. Below this is a table with columns: License Number, Description, Location, Redundancy, and Expiration. The 'Expiration' column contains the text 'Never'. Below the table is an 'Installation Id' section with two entries: 'EMERALD (primary)' with ID '1F40-EE2E-86CF-A995-007E-3E50' and 'LAPIS' with ID '1F40-7923-3D44-F830-A8DB-76B2'. A red box highlights these two entries. To the right of the 'Installation Id' section is a 'Show All' button. At the bottom of the dialog are five buttons: 'License Details', 'Delete Demo Code', 'Install Demo Code', 'Show Old Licenses', and 'Done'.


11. Once the Installation IDs are added, scroll down and click Create at the bottom of the Master License form.
12. Click the Download License link and save the license file.
13. Move the license file to the ThinManager Server but not into the ThinManager folder.
14. Choose Install>Licenses in the ThinManager menu to open the Licensing dialog box.

**Figure 50 - Install License**

This screenshot shows the 'Licensing' dialog box with a different state. The 'Master License Number' field is empty. The 'Installation Id' section now contains one entry: 'DOCUMENTATION (primary)' with ID '1234-1234-1234-1234-1234'. The 'Install License' button at the top right is highlighted with a red box. The 'Show All' button is also visible. The bottom buttons remain the same: 'License Details', 'Delete Demo Code', 'Install Demo Code', 'Show Old Licenses', and 'Done'.


15. Click Install License.

Figure 51 - File Browser



16. Browse to the License file and click Open.


Figure 52 - Install Master License



A properly installed license is indicated.

17. Click OK.

Figure 53 - Installed License



A successfully installed license is shown in the Master License Number field, the Product Licenses are listed in the center section, and the Installation ID shows in the bottom field.

18. Click Done.


## FactoryTalk Activations

The other license mode—besides ThinManager Master License—is FactoryTalk Activations.

Follow these steps to enter FactoryTalk Activations mode.

1. From the ThinManager menu, choose Install>License Mode to open the License Mode dialog box.

**Figure 54 - License Mode**




2. Click FactoryTalk Activations and OK.

## FactoryTalk Activation Files

FactoryTalk Activation binds Rockwell Automation software product licenses to specific devices. Without activation, some Rockwell Automation products do not run, run with less than full functionality, or they run for a limited time and shut down. Therefore, before you can proceed with FactoryTalk Activations in ThinManager, you must create activation files via the FactoryTalk Activation Manager.


**Figure 55 - FactoryTalk Activation Manager Home**



When FactoryTalk Activation Manager is started, it detects whether an Internet connection exists. Available options for obtaining new activations differ depending on your Internet connectivity status. In FactoryTalk Activation Manager, click Help to find instructions on activation options.

- 3. Return to ThinManager and choose Install>Licenses to open the FactoryTalk Activations dialog box.


Figure 56 - FactoryTalk Activations



- 4. Click Add Activations.


The Add Activations to ThinManager dialog box appears, searches for and displays FactoryTalk activations.

Figure 57 - Add Activations to ThinManager



- 5. Highlight the license to use with ThinManager, and, when enabled, in the Enter the number of activations to add to ThinManager field, specify how many licenses to add.
- 6. Click OK.

The FactoryTalk Activations dialog box appears and shows the FactoryTalk licenses transferred.

**Figure 58 - FactoryTalk Activations**

7. Click OK.

**Notes:**



## ThinManager System

There are three types of ThinManager system users: Windows™ Users, ThinManager Security Group Users, and ThinManager Users. The Windows Users may be local or domain accounts.

### Windows Users

Windows Users are the Microsoft™ accounts created in Windows that allow access to the Windows Remote Desktop Servers. These are configured within, and authenticated by, Windows. They can be given varying levels of access and power using Windows User Groups and Group Policies.

All users and terminals need a Windows account to log in to a Remote Desktop Server. These accounts need to be members of the Remote Desktop User Group.



As a Microsoft best practice, each Terminal or Location needs a unique Windows account.



It is always a best practice to follow the principle of least privilege. Provide accounts used for auto-login of Windows sessions only with the privilege required to access the desired applications. For example, never use a Domain Administrator for auto-login.

ThinManager 8 introduced Active Directory integration to the ThinManager system, which is covered in [Active Directory User Login Account on page 301](#).

### ThinManager Security Group Users

ThinManager Security Group Users are Windows User Group members who were configured, in the ThinManager Server Configuration Wizard, to have varying levels of access and control within the ThinManager program. This pertains to access to the administrative console of ThinManager, not access to a Windows application.

ThinManager Security Groups are configured on the ThinManager Security Groups page of the ThinManager Server Configuration wizard. See [ThinManager Server Configuration Wizard on page 573](#).

### ThinManager Users

ThinManager Users can go to a ThinManager-ready thin client and receive access to specific display clients based on their membership in an Access Group. ThinManager performs authentication a level above the Windows login. Formerly called TermSecure, this feature is currently integrated into the Relevance suite of functions.

ThinManager User Services give additional powers to grant or deny access to Windows applications but still rely on a Windows user account to log in to a Remote Desktop Server.

The following are various strategies for ThinManager Users.

- For a Terminal-specific Application, a user does not need a Windows account; but permission from an Access Group is required to open a hidden application.
- If a user is accessing their own User-specific Applications, they need a Windows account associated with them so they can log in and start these sessions. The ThinManager User can be created:
  - From an Active Directory account
  - To match the name of a Windows account, and use that Windows account without using Active Directory
  - With one name and be associated to a Windows account of a different, aliased name

See [Active Directory User Login Account on page 301](#) for details.

## ThinManager User Manual Unlock


Locked ThinManager User accounts that are not Active Directory accounts can be manually unlocked in the ThinManager Admin Console. Typically, user accounts are locked after excessive unsuccessful login attempts. The number of attempts allowed is set by the Account Lockout Policy setting in ThinManager. Locked ThinManager ThinManager User accounts can be unlocked at any time, regardless of the Account Lockout Period duration.



When Active Directory user accounts are locked due to excessive incorrect login attempts, the account must be unlocked in Active Directory.


Locked ThinManager User accounts are indicated by a dialog box displayed on the terminal. See [Figure 59](#).

**Figure 59 - ThinManager User Account Locked**




To manually unlock a ThinManager User account, follow these steps.

1. Click OK in the dialog box on the terminal.

**Figure 60 - ThinManager Users Pane**

2. In ThinManager Admin Console, click Users to display the non-Active Directory user account.
3. Right-click on the locked user account, and then click Modify.


The ThinManager User Information page of the ThinManager User Configuration Wizard appears.

**Figure 61 - ThinManager User Information page**


The screenshot shows the 'ThinManager User Configuration Wizard' window. The title bar says 'ThinManager User Configuration Wizard'. The main heading is 'ThinManager User Information' with the instruction 'Enter username, password and permission information.' Below this, there is a section for 'ThinManager User Information' with fields for 'User Name' (containing 'NonAD\_User'), 'Password' (masked with dots), and 'Verify Password' (masked with dots). There are buttons for 'Customize', 'Password Options' (highlighted with a red box), and 'PIN Options'. Below this is a 'Group' section with a dropdown menu and a 'Change Group' button. Then there is a 'Copy Settings' section with a checkbox 'Copy Settings from another User' and a 'Copy From' button. At the bottom of the main content area is a 'Permissions' button. The bottom of the window has navigation buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

4. Click Password Options.

The Password Maintenance Options page appears.

**Figure 62 - Password Maintenance Options page**


The screenshot shows the 'Password Maintenance Options' dialog box. It has several sections: 'Password Complexity Requirements' with a 'Minimum Password Length' field set to 3 and checkboxes for 'Must contain numbers', 'Must contain upper and lower case letters', and 'Must contain symbols'. The 'Password Maintenance' section has checkboxes for 'Allow User to change password', 'Force User to change password at next login', and 'Force User to change password periodically', along with a field 'User must change password every' followed by 'days'. The 'Account Lockout Policy' section has fields for 'Failed Login Attempts Threshold' (set to 3) and 'Account Lockout Period' (set to 100 minutes), and an 'Unlock' button (highlighted with a red box and a red circle with the number 1). The 'Authorization Caching' section has a checkbox 'Cache authorization is disabled' and a 'Change' button. At the bottom, there is an 'OK' button (highlighted with a red box and a red circle with the number 2) and a 'Cancel' button.

5. Click Unlock, and then click OK to close the wizard.

The user account is unlocked. Return to the terminal and attempt to log in to the user account again.

## TLS Certificates

Complete management of a thin client solution sometimes requires connections to outside applications, logs, or servers. To secure those connections, certificates can be installed into the system or generated by ThinManager.


The Browser Custom CA Certificate allows for installation of a certificate to secure the communications with web-based applications. When you leverage a web browser container display client on a terminal, ThinManager must be made aware of the web server's certificate to which the client connects.

The Docker Server CA Certificate is required to establish a connection to a Docker server-hosted container. For more information, see [Install the TLS Certificates on page 100](#).

ThinServer hosts an internal HTTPS server, which is leveraged for delivery of some larger modules when enabled. The HTTPS server must be enabled in order to use the API endpoints. When connecting to the API, the HTTPS server certificate must be installed to have a secure communication. The certificate can be generated in ThinManager and installed in the directory where your web browser is directed to look for certificates. The default for many web browsers is the Trusted Root Certification Authorities directory.

The Syslog Client Certificate allows for secure connections when the syslog logging is enabled. For more information, see [SysLog Configuration Page on page 577](#).


**Figure 63 - Manage TLS Certificates**



## API

Representational State Transfer (REST)-conforming API can be used to assist in deployment and maintenance of the ThinManager system.

The API can be enabled during ThinManager installation, or post-installation, via the ThinManager Server Configuration Wizard for versions 13 and later. An optional checkbox appears in the installer.

**Figure 64 - Enable API checkbox**

API endpoint documentation is intended to be accessed via a web browser, which can be found at [https://\[thinserverhostIP\]:\[HTTPS port\]/api/documentation](https://[thinserverhostIP]:[HTTPS port]/api/documentation). For example, to connect with the default port when ThinServer is installed on the local host, navigate to <https://localhost:8443/api/documentation>. The API supports GET, POST, PUT, and DELETE methods.

See [HTTPS Server Settings Page on page 592](#) for more details.

## Sources

There are three possible ThinManager sources: Remote Desktop Servers, IP Cameras, and VNC Server.

### Remote Desktop Servers

Microsoft servers with Remote Desktop Services, formerly known as Terminal Services, provide the foundation of thin client computing, which consolidates management of the Windows environment to mainframe architecture. In this document, Remote Desktop Server refers to the computer and operating system, while Remote Desktop Services refers to the connection using the Remote Desktop Protocol.

To configure Remote Desktop Servers as sources:

- First, you need to build and configure the server using standard Microsoft practices.
- Second, you need to define the server as a Display Server in ThinManager.

### Microsoft Configuration



Refer to Microsoft for instructions on the use and configuration of a Microsoft server.




Here are a few common tips.

- Build a Remote Desktop Server with Microsoft 2008, 2008R2, 2012, 2016 or 2019 Server operating system. Enable Terminal Services in 2008 Server or Remote Desktop Services in 2008R2, 2012, and 2016 Server. The 2012 and 2016 Servers usually require a domain.
- Create a Microsoft Licensing Server and add a Remote Desktop Services Client Access License (RDS CAL) for each thin client. These are called Terminal Services Client Access Licenses (TS CALs) in Server 2008 and earlier. This does not need to be a separate physical server but can be a role added to an existing server. The servers also require a normal CAL.
- Create a unique Microsoft user profile for each Terminal on the Remote Desktop Server. Make sure that the user is a member of the Remote Desktop Users Windows group.
- Apply appropriate security to each user profile using the standard Microsoft techniques.
- Install all applications in the Install Mode. This can be done by typing `change user /install` in a command window or by using the Install Application on Remote Desktop Server in the Control Panel.

### Defining Remote Desktop Servers in ThinManager

Once the Remote Desktop Servers are built, you must define them as Display Servers in ThinManager.

**Display Servers Branch of the ThinManager Tree**

Perform the following to define Remote Desktop Servers as Display Servers.

1. Right-click RDS Servers in the Display Servers branch of the ThinManager tree.



2. Choose Add Remote Desktop Server to launch the Remote Desktop Server Wizard Introduction page, which provides instruction about DNS servers.


---

**IMPORTANT** If you are using a DNS server, click Cancel to close the Remote Desktop Server Wizard. Click Manage>DNS Configuration. The Domain Name Server Wizard appears where you define a DNS server.

---

3. Click Next.

**Figure 65 - Introduction - Remote Desktop Server Wizard**



### *Non-Domain Remote Desktop Server*

The Remote Desktop Server Name page allows you to define the Remote Desktop Server.

**Figure 66 - Remote Desktop Server Name Page - Non-Domain**

To define the Remote Desktop Server, perform the following steps.

1. Enter the Remote Desktop Server Name.
2. Click Discover to validate the server name and auto-populate the IP address.
3. Complete the Log In Information fields to add an administrative account on the Remote Desktop Server.

This step is required for SmartSession load balancing and server management from ThinManager as the Microsoft server only provides information to an administrator. The ThinServer connects to the Remote Desktop Server to retrieve CPU, Memory, and Session status for load balancing.

4. Click Change Group to add the Remote Desktop Server into a Remote Desktop Server Group.
5. Run the Remote Desktop Server Wizard for each Remote Desktop Server you want to add to the system.

#### *Domain Member Remote Desktop Server*

On the Remote Desktop Server Name page, the Search function allows you to search for a domain user account for the administrative login.

**Figure 67 - Remote Desktop Server Name Page - Domain**

**Remote Desktop Server Wizard**

**Remote Desktop Server Name**  
Enter the Remote Desktop Server Name and Log In information.

Remote Desktop Server Name

Name: TM-2016-RDS-C1

IP Address: 10 . 3 . 10 . 104

Discover

Change Group

Log In Information

User Name: administrator@lab

Password:

Domain:

Search

Verify

Password Options

Schedule

< Back Next > Finish Cancel Help

Perform the following to search for an administrative account.

1. Click Search.

The Search for AD User dialog box appears, which allows you to select an Active Directory user.

This adds an administrative account to the Log In Information fields of the Remote Desktop Server Name page.

**Figure 68 - Search for AD User**

**Search for AD User**

Locations ...

Recurse ☐

Filter: Contains

Search

Name	User Principal Name
------	---------------------


OK Cancel

Feature	Description
Locations	Click and the Select AD Location to Search dialog box appears, where you choose which Organizational Unit (OU) to search
Recurse	Check this option to set the Search function to look in nested Windows Security Groups. To enable this function, set Choose AD Synchronization Mode to Security Group on the Active Directory System Settings dialog box to work. To open the Active Directory System Setting dialog box, click Manage>Active Directory>Settings.
Search	Searches the selected OU and populates the Name field with the OU members
Filter	Filters the results with either the Contains or Starts with function and the entry of the text box

2. Click Locations.

The Select AD Location to Search dialog box appears.


Figure 69 - Select AD Location to Search



- 3. Choose the branch of the Active Directory tree that contains the administrative user account.
- 4. Click OK.

The location appears in the Search for AD User dialog box with the list of domain users from that branch.

Figure 70 - Search for AD User



5. Choose the desired user and click OK.

The domain user is populated to the User Name field of the Remote Desktop Server Name page.

**Figure 71 - Remote Desktop Server Wizard - Log In Information**

Remote Desktop Server Wizard

**Remote Desktop Server Name**  
Enter the Remote Desktop Server Name and Log In information.

Remote Desktop Server Name

Name: TM-2016-RDS-C1

IP Address: 10 . 3 . 10 . 104

Discover

Change Group

**Log In Information**

User Name: administrator@lab

Password: \*\*\*\*\*

Domain:

Search

Verify

Password Options

Schedule

< Back Next > Finish Cancel Help

6. Complete the Password field.
7. Click Verify to check whether the password is valid.

If correct, the Account Verify dialog box indicates that the password is valid.

**Figure 72 - Account Verify Dialog**


Account Verify

Account information is valid

OK


8. Click OK to return to the Remote Desktop Server Name page.
9. Click Next to continue in the wizard.

The Terminal Server Capabilities page appears.

**Figure 73 - Terminal Server Capabilities - Terminal Server Options**

10. To use the Remote Desktop Server with SmartSession, check Available for Display Clients using SmartSession and click Next.

The Data Gathering page appears.

**Figure 74 - Data Gathering**

11. On the Data Gathering page, set the speed and frequency with which ThinManager polls Remote Desktop Servers. This covers both SmartSession and the data on the Users, Sessions, and Processes tabs of

the server. Fast is the default Data Gathering Interval, but the interval can be changed for less frequent polling or to a custom value.

**Figure 75 - SmartSession Configuration**

If Available for Display Clients using SmartSession was checked to load balance on the Remote Desktop Server Capabilities page, then the wizard shows the SmartSession Configuration page.



Values are not prevented from exceeding the maximum or minimum. The values represent the levels that 'No Utilization' or 'Full Utilization' is reached.

See [SmartSession on page 146](#).

12. Click Finish to accept the changes and close the wizard.
13. Repeat this process for each Remote Desktop Server in use.

### Citrix Servers



Citrix™ StoreFront is fully supported with ThinManager 12.1 and later when using container images with the embedded ICA client. See [Containers on Thin Clients on page 84](#).

Support for Citrix ICA was deprecated starting with ThinManager Server 9.0. By default, the ability to configure a Remote Desktop Services Display Client to use Citrix ICA was removed. This was deprecated because ICA is a proprietary protocol that prevents it from being fully supported by all of the latest features of ThinManager such as mobile clients, Tiling, Virtual Screens, and so on. With that said, it is still possible to enable ICA in ThinManager.

To allow ICA configuration for ThinManager 9.0 and newer, follow these steps.

1. Open the registry editor and navigate to the option for your deployment.

32-bit Windows, or 64-bit ThinManager on 64-bit Windows:

- HKEY\_LOCAL\_MACHINE\SOFTWARE\Automation Control Products\ThinManager

32-bit ThinManager on 64-bit Windows:

- HKEY\_LOCAL\_MACHINE\SOFTWARE\Wow6432Node\Automation Control Products\ThinManager

2. Add a new DWORD value named SupportICA with a value of 1
3. Restart the ThinServer service.
4. For redundant systems, make this change on both servers.

This is a one-time change that does not need to be made again; for example, after an upgrade.




ThinManager only supports the Citrix PNAgent on direct connections. Therefore, Citrix 7.x and later installations must enable PNAgent since it is no longer enabled by default. Citrix StoreFront is supported with containers in ThinManager version 12.1 and later.

### *Automatically Find Remote Desktop Servers*

ThinManager has a search function that finds Remote Desktop Servers on the network to speed your configuration.

**Figure 76 - Remote Desktop Server Branch - Display Servers Tree**




To find Remote Desktop Servers on the network, follow these steps.

1. Go to the Remote Desktop Server branch of the Display Server tree.
2. In the Display Server tree, right-click RDS Servers and choose Edit Remote Desktop Server List.


The Remote Desktop Server List Wizard appears.



**Figure 77 - Remote Desktop Server List Wizard**

3. Click Find Servers.

The Available Remote Desktop Servers dialog appears.

**Figure 78 - Available Remote Desktop Servers**

The Available Remote Desktop Servers list shows all Remote Desktop Servers that ThinManager can communicate with in a workgroup.

4. Choose the Remote Desktop Server to add and click OK.


The Remote Desktop Server Wizard appears, displaying the name and IP address.

5. Use the WorkGroup to search field to expand the search. Enter the workgroup and click Find to search again.

## Remote Desktop Server Graph

The Remote Desktop Server Graph allows you to see the performance levels of the server.

Figure 79 - Remote Desktop Server Performance Graph



To view the performance levels of a Remote Desktop Server, highlight a Remote Desktop Server in the RDS Servers branch of the Display Servers tree and click the Graph tab.


CPU Usage, Memory Usage, and Total Sessions are the values that ThinManager uses to calculate the SmartSession resource load.



This graph is only displayed for Remote Desktop Servers that have a valid administrative account on the Remote Desktop Server Name page, have Available for Display Clients using SmartSession checked, and have an active connection (green-light status) to the ThinManager Server.

Remote Desktop Server Status

Remote Desktop Server Status shows the connection status between ThinManager and the servers.

**Figure 80 - Remote Desktop Server Status**

To show the connection status between ThinManager and the servers, highlight the RDS Servers branch of the Display Servers tree and click the Status tab.

Ideally, the Remote Desktop Servers are configured properly so that ThinManager communicates with them and is able to pull load status into ThinManager for use in management and SmartSession load balancing.

**Figure 81 - Remote Desktop Server Status Lights**

Status Color	Meaning
Green	ThinServer can talk to the Remote Desktop Server and pull data using the administrative account you are using. "OK" is displayed as the Value on the Status tab.
Red	The server is offline or the administrative account failed to connect to the server.
Gray	The administrative account was left blank, and the ThinManager Server is not trying to communicate with the server. "No login information supplied" is the Value displayed on the Status tab.



A Red or Gray status does not mean that the Terminals cannot log in and run on the servers. These colors only indicate the ability of ThinManager to access the resources on the server.


### Solutions to Failed or No Connection

- For a gray status, reopen the Remote Desktop Server Wizard and enter an administrative account in the Log In Information fields on the Remote Desktop Server Name page.
- For a red status with a Value of “User specified does not have permission to connect,” re-open the Remote Desktop Server Wizard and correct the administrative account in the Log In Information fields on the Remote Desktop Server Name page.
- For a red status with a Value of “The RPC Server is unavailable” or “WTSAPI32.dll failed,” then the Remote Desktop Server is offline or missing the Terminal Services/Remote Desktop Protocol role.

### Local Administrative Login for ThinServer


Sometimes, large domains have issues where the connection times out before the domain controller validates the user name. To correct this issue, create a local administrative user account on each server, then have the ThinServer log in with this account. This speeds up data retrieval.

**Figure 82 - Services in Windows 2016**



To change the ThinServer service login in Microsoft Services on your ThinManager Server, follow these steps.


1. To access the Windows Services dialog box, choose Control Panel>System and Security>Administrative Tools>Services, or choose Server Manager>Tools>Services.
2. Double-click on the ThinServer service. The ThinServer Properties dialog box appears.

**Figure 83 - ThinServer Properties**

3. Click the Log On tab.
4. To change the log in account from the Local System account, click This account and specify the local administrative account. Make sure it is a member of the Administrative Group.
5. Click OK and restart the ThinServer service to apply the changes to the login.

### *Disable Remote Desktop Servers*

ThinManager allows you to disable a Remote Desktop Server, which is useful for failover tests and updates. This feature allows you to move servers offline, one at a time, for updating. This action forces ThinManager-controlled thin clients to drop their connections and switch to an alternate server. This is useful for testing Failover and Instant Failover because the Terminals should switch to a back-up server. The network card on the server is not disabled—you can make RDP connections from a PC; but ThinManager thin clients stop using the server.

**Figure 84 - Disabled Remote Desktop Servers in Display Clients**


To disable a Remote Desktop Server, follow these steps.

1. Highlight the Remote Desktop Server icon in the Display Servers tree and choose Tools>Disable.
2. Once the Remote Desktop Server is disabled, reset the sessions on the Sessions tab. Right-click a session and choose Reset Session. Once the server is clear of sessions, patch and update the server and applications, and even reboot it if necessary. This does not impact production as all the Terminals are using a backup server.
3. Once the task is complete, choose Tools>Enable to allow the Terminals to use the server again.

## Remote Desktop Server Group

A Remote Desktop Server Group can be created to speed configuration by selecting a pool of servers instead of an individual server.

**Figure 85 - Add a Remote Desktop Server Group**




To add a Remote Desktop Server Group, follow these steps.

1. In the Display Servers branch, right-click RDS Servers and choose Add Remote Desktop Server Group.

The Remote Desktop Server Wizard appears.

**Figure 86 - Remote Desktop Server Name Page**




2. Enter a name for the Remote Desktop Server Group.
3. Click Gateway.

The RDP Gateway dialog box appears.


The RDP Gateway allows Remote Desktop Servers to use the Microsoft RDP Gateway to connect to resources on other subnets.

**Figure 87 - RDP Gateway**

The image shows a dialog box titled "RDP Gateway" with a blue header bar and a red close button in the top right corner. Inside the dialog, there are three text input fields labeled "Gateway Name", "Username", and "Password". At the bottom right of the dialog, there are two buttons: "OK" and "Cancel".

4. Enter the Gateway Name, Username, and Password.
5. Click OK.

The Remote Desktop Server Group is created as an empty group as shown on the Remote Desktop Server Order page.

The image shows a window titled "Remote Desktop Server Wizard" with a blue header bar and a red close button in the top right corner. The main area of the window is titled "Remote Desktop Server Order" and has a subtitle "Set the Remote Desktop server priority". Below this, there is a section labeled "Server Priority" which contains a large empty rectangular box. To the right of this box are two buttons: "Up" and "Down". At the bottom of the window, there is a row of five buttons: "< Back", "Next >", "Finish", "Cancel", and "Help".


The Remote Desktop Servers are added individually in the Remote Desktop Server Wizard.

6. Double-click on the server under RDS Servers in the Display Server branch.



The Remote Desktop Server Name page of the Remote Desktop Server Wizard appears.


**Figure 88 - Remote Desktop Server Name Page**



7. Click Change Group.

The Select Parent Remote Desktop Server Group dialog box appears.


**Figure 89 - Select Parent Remote Desktop Server Group**



8. Choose the desired Remote Desktop Server and click OK to accept the changes.

The chosen Remote Desktop Server is populated to the Change Group field.


Figure 90 - Remote Desktop Server Name Page with RDS Group Membership




The Remote Desktop Server is now a member of the Remote Desktop Server Group.

- 9. Repeat as needed.

Figure 91 - Remote Desktop Server Group with Member Remote Desktop Servers



The tree shows the member Remote Desktop Servers in the RDS Servers group.

**Figure 92 - Remote Desktop Server Order Page**

Button	Description
Up	Moves a highlighted Remote Desktop Server up in the priority list.
Down	Moves a highlighted Remote Desktop Server down in the priority list.

10. Open the Remote Desktop Server Group wizard and navigate to the Remote Desktop Server Order page to view the members of the Remote Desktop Server Group.

The Remote Desktop Servers are used in the order listed.

11. Highlight a member server to move, then use the Up and Down buttons to change the order.
12. Click Finish.


### *Remote Desktop Server Groups and Display Clients*

The Display Client Wizard appears differently when Remote Desktop Server Groups are configured versus not configured. The following steps depict when no Remote Desktop Server Groups are configured.

1. In the Display Clients branch, double-click a Display Client.


The Display Client Wizard appears.

2. Click Next until the Display Client Members page appears.

**Figure 93 - Display Client Members Page**

3. Click Add.


The Select Remote Desktop Server or Group dialog appears, from which you may select a Remote Desktop Server Group, an individual Remote Desktop Server, or a Remote Desktop Server that is a member of a Remote Desktop Server Group.

**Figure 94 - Select Remote Desktop Server or Group**

4. Highlight the desired Remote Desktop Server or group and click OK.
5. Repeat as needed.

Once a Remote Desktop Server or group is selected, it appears in the Selected Remote Desktop Servers list.

**Figure 95 - Display Client Wizard - Display Client Member Page**



Feature	Description
Use RD Gateway	Prompts the Display Client to use the Microsoft RD Gateway.
Bypass RD Gateway server for local address	Allows the Display Client to use a Remote Desktop Server without going through the RD Gateway if the Terminal and Remote Desktop Server are on the same subnet.

Navigation through the remaining Display Client Wizard pages follows those displayed when no Remote Desktop Server Groups are configured.

## Containers

ThinManager version 12 introduced Containers as a method of delivering content, leveraging Docker\ container technology. Containers allow web-based applications to be decoupled from Remote Desktop Services. Linux Images that only contain the necessary files to run an application are installed in ThinManager. These available Images include Chrome, Firefox, Chrome with Citrix (.ica support), and Firefox with Citrix (.ica support). Instances of these Images are called Containers. Terminals are then able to display and interact with the Container running the specific application.

There are two methods to deliver content with Containers:


1. Containers on thin clients (released with ThinManager version 12.1)
2. Containers on servers (released with ThinManager version 12.0)

## Containers on Thin Clients

Hosting Containers on thin clients is new with ThinManager version 12.1. Previously, all web-based content required Windows servers using (Docker) Containers or Remote Desktop Services. These methods required resources such as RAM and CPU to be consumed locally on these designated servers. When electing to run containers on thin clients, the required resources to run the web-based session is sourced from the designated thin client.

These steps illustrate how to create a Container Host Display Client to run on a thin client. For containers running on thin clients, a Display Server does not need to be created.

**Figure 96 - Add a Display Client**



1. Under the Display Client tree, right-click Container Host and choose Add Display Client.

The Client Name page of the Display Client Wizard appears.


Figure 97 - Client Name Page

2. Type the Client Name.
3. From the Container Application pull-down menu, choose a container application.

Container Application	Description
firefox	Launches the application with a Firefox browser.
chrome	Launches the application with a Chrome browser.
chrome_with_citrix_client	Launches the application with a Chrome browser with the capability to launch .ica files. This is compatible with Citrix StoreFront.
firefox_with_citrix_client	Launches the application with a firefox browser with the capability to launch .ica files. This is compatible with Citrix StoreFront.

4. Click Next through the wizard until the Select Container Hosts page appears.

Figure 98 - Select Container Hosts Page




5. Choose the method to run a container on a thin client.

Container Application	Description
Run container on thinclient	Check to run the container on the thin client where the display client is assigned. The application uses resources from the local thin client. Clear this checkbox to make the Available Container Hosts/Selected Container Hosts option available.
Available Container Hosts/ Selected Container Hosts	Use the arrows to choose a thin client to host the Display Client. The container utilizes the Selected Container Hosts' resources to run the application rather than the resource of the terminal on which the Display Client is applied. This option is available when the Run container on thinclient checkbox is cleared.

6. Click Next.

The Container Properties page appears.


Figure 99 - Container Properties Page





7. Type the number of gigabytes of memory to allocate to the container in the Memory field. Adjust as needed. At least 1 GB is recommended, but it may need to be increased based on a specific application.
8. Check the Preserve browser cookies checkbox to store browser cookies in ThinServer and restore cookies when a new container is created for the terminal or user.
9. Click Next.

**Figure 100 - AppLink Path Page**



10. Type the application URL.
11. Click Finish to close the wizard.
12. Apply the Display Client to the terminal.
13. Restart the terminal.

## Terminal Profile Setup for Containers

There are a few configuration requirements for terminals that are Container Hosts. Also, it is recommended that a terminal have at least 8 GB of RAM to host containers. This varies based on the application that runs inside the container.

Figure 101 - Terminal Hardware Page

Terminal Configuration Wizard

**Terminal Hardware**  
Select the manufacturer and model of this terminal.

Use this to configure the type of hardware for this terminal.

Make / OEM  
Model  
OEM Model  
Video Chipset

Terminal Firmware Package: 9.2

Terminal ID and IP Address  
Terminal ID: None  
Clear  
Edit

< Back Next > Finish Cancel Help

1. For terminals that are Container Hosts, you must run at least Terminal Firmware Package 12.1.O-9.2 (shown as 9.2 in the Terminal Firmware Package drop-down menu). When this firmware is selected, an additional setting appears on the Terminal Mode Selection page of the wizard. Additional download and installation of terminal firmware package 12.1.O-9.2 or greater may be required.

Figure 102 - Terminal Mode Selection Page

Terminal Configuration Wizard

**Terminal Mode Selection**  
Select the operating modes for this terminal

Terminal Mode

☐ Enable Relevance User Services  
☐ Enable Relevance Location Services  
☐ Enable MultiMonitor  
☐ Enable MultiStation

Container Hosting Group Setting ☐


☐ Enable Container Hosting  
☐ Enable Container Hosting for other Terminals  
Settings

< Back Next > Finish Cancel Help

2. Complete the Container Hosting section of the Terminal Mode Selection page per these descriptions.

Setting	Description
Group Setting	Check to allow Enable Container Hosting and Enable Container Hosting for other Terminals settings to be applied to all terminals in the Terminal Group. This can be applied at the Terminal Group level only.
Enable Container Hosting	Check to enable Container Host Display Clients to run on this terminal.
Enable Container Hosting for other Terminals	Check to allow this terminal profile to appear in the Container Host Display Client Wizard to host containers for other thin clients.
Settings	Click to launch the Container Host Settings dialog, where you can change Ram Disk Size.

**Figure 103 - Container Host Settings**



3. Type the Ram Disk Size in gigabytes into the field and click OK.

Setting	Description
Ram Disk Size (GB)	This value is the total write space of the container. The required minimum RAM Disk Space allocated is at least 4 GB. The default value is also 4 GB. This value varies per the application. It can be determined by the following formula: <b>[RAM Disk Size (GB)] = [Installed Container Image] + [Compressed Container Image] + [300 MB Docker Engine] + [Swap and Temporary Files Space]</b> , where RAM Disk Size (GB) cannot exceed the total RAM of the thin client.



The RAM Disk Size and container Memory size are independent settings. The sum of RAM Disk Size and container Memory may not exceed the total physical memory (RAM) available on the thin client.

## Containers on Servers using Windows Server 2019

ThinManager leverages open-source Docker container technology for running Containers on servers. Container Deployment is similar to the deployment of Remote Desktop Services Servers.

1. Create a Windows 2019 Server and install Docker.
2. Install the Container image in ThinManager.
3. Define the Container Host as a Display Server.
4. Define the Container as a Display Client and add the Container Image to the Container Display Client.
5. Apply the Container Display Client to the Terminal.

The Container Host needs two TLS Certificates and a TLS key installed, which provides secure authentication between the Container Host and the ThinServer service. The certificates can be generated with the TLS Certificate tool in ThinManager.

6. Generate the two certificates and the key, and move them to the Docker Container Host.

On boot, the thin client requests a connection to the container from ThinManager, which starts a container instance, if not already running, and returns the connection details to the thin client. Then, the thin client establishes a connection directly to the container.

This section shows the steps to configure the Container system in ThinManager, then covers the Certificate process once ThinManager is configured. It is possible to create the certificates during the ThinManager configuration process, but it is easier to understand if it is done as one procedure.

## Container Host Server Installation


To make the selected server a Docker Container server, the script **Install-Docker.ps1** installs Hyper-V and Containers Roles. Windows Server 2019 with Internet connection is required for the Docker Container Server solution in ThinManager. Offline installation is not available as the Internet is necessary to download files from Microsoft Servers and Rockwell Automation Servers.

If a virtual machine is not used, skip to Running the Script. To prepare your virtual machine, follow these steps to enable nested virtualization.

If a Hyper-V virtual machine is used, this setting can be set using PowerShell.


1. Power off the Docker Container Server virtual machine.
2. On the Hyper-V host, open PowerShell as an Administrator.

**Figure 104 - Windows PowerShell**



3. Type the following command:  
`Set-VMProcessor -VMName [VM Name]  
 -ExposeVirtualizationExtensions $True`  
 where [VM Name] is replaced by the Docker Container virtual machine name. See [Figure 105](#).


**Figure 105 - Type Command into PowerShell**



4. Press Enter to run the command.

If you use a VMware virtual machine, this setting can be configured under Virtual Machine Settings.

1. Power off the Docker Container Server virtual machine.
2. Navigate to Virtual Machine Settings.

**Figure 106 - Virtual Machine Settings**

3. Click the Hardware Tab, and select Processors.
4. Under the Virtualization engine properties section, check Virtualize Intel VT-x/EPT or AMD-V/RVI.
5. Click OK.

### *Run the Script*

Once the designated Server 2019 has Internet connectivity, run the script **Install-Docker.ps1** located in the installer files at:  
 \Common\12.0.0-ThinManager\Install-Docker.ps1  
 or at [downloads.thinmanager.com](https://downloads.thinmanager.com).

The **Install-Docker.ps1** script has two components: the Installation of Hyper-V and the installation of Container roles. The virtual machine restarts during the installation processes of the Hyper-V and Containers roles, as required.



You must manually initiate the script a second time during this installation process as detailed below.


1. Open PowerShell as an Administrator.

Figure 107 - Windows PowerShell



- 2. Change the file directory as necessary to match the location of Install-Docker.ps1.

Figure 108 - Install Script



- 3. Type:  
".\Install-Docker.ps1 -AllowFirewall -Restart".  
and press Enter to run the script. See [Figure 108](#).


Switch	Description
-AllowFirewall	Creates a Windows firewall rule, Docker SSL Inbound, to allow TCP2376, the default port for Docker. If this is not specified in this PowerShell command, it must be added manually to the Windows firewall rules.
-Restart	Automatically restarts the server after the installation of Hyper-V and Docker Containers. If it is omitted, the script prompts if a restart is required.
-Verbose	Enables more in-depth information about command processing.

- 4. Once the server restarts, repeat steps 1 through 3 to initiate the Install-Docker.ps1.
- 5. To complete the installation, restart the Docker service in Windows Services or restart the server.

For more information on the script, type the command:  
Get-Help .\Install-Docker.ps1

### Install Container Images

The Container images are included as part on the ThinManager installation. Additional containers can be installed into ThinManager similarly to firmware packages.

**Figure 109 - Install Container Images**

To install container images, follow these steps.

1. Choose Install>Container Images.

The Install Container Image dialog box appears.

2. Click Install.


The File Browser appears.

3. Selecting the Container Image **\*tar.gz** file
4. Click Open.

The Container Image is installed.

## Define the Container Host Display Server

The Container Host is a new branch of the Display Server branch of the ThinManager tree.

**Figure 110 - Container Hosts in Display Server Branch**

1. Right-click on the Container Hosts icon and choose Add Container Host.

The Container Host Wizard appears.

**Figure 111 - Container Host Wizard**

2. Type the name of the Container Host in the Name field.
3. Type the IP address in the IP Address field.
4. Type the port number that is used for the container connection. Port 2376 is the default port number, but it can be changed in the wizard if it was changed on the Container Host.
5. Click Finish to exit the Container Host Wizard.




You must click TLS Certificate to open the TLS Certificate dialog box, which allows you to save the Server Certificate and Server Key. See [Install the TLS Certificates on page 100](#).

## Define the Container Host Display Client

The Container Host is a new branch of the Display Clients branch of the ThinManager tree.



**Figure 112 - Container Host in Display Clients Branch**

1. Right-click on the Container Host icon and choose Add Display Client.


The Display Client Wizard appears.

Figure 113 - Display Client Wizard

2. Type the name of the display client in the Client Name field.
3. Choose an installed Container Image from the Container Application pull-down menu. The Firefox browser is the default Container Image. See [Install Container Images on page 92](#) for more information on installed Container Images.
4. Click Next.


The Display Client Wizard continues with the typical pages and settings.

The Select Container Hosts page of the Display Client Wizard allows the selection of a Container Host much like Remote Desktop Servers are selected in Remote Desktop Server Display Clients.

**Figure 114 - Select Container Hosts Page**

5. Select the Container Host of your choice for the Display Client.
6. Click Next to continue with the wizard.

The Container Properties page shows the maximum size the Docker Container uses. By default, the maximum size is 1 GB, but it can be changed.

**Figure 115 - Container Properties**

7. Click Next to continue.

8. The final page of the Container Display Client Wizard, which uses the Firefox web browser Container Image, allows you to specify the web content to be displayed through the Start URL field.

**Figure 116 - AppLink Path Page**

Display Client Wizard

AppLink Path

Start URL

`https://kb.thinmanager.com/index.php/Main_Page`

Other Command Line Options

`--kiosk`

< Back   Next >   Finish   Cancel   Help

9. Type the URL of the desired web content to display.
10. In the Other Command Line Options field, type `--kiosk`.


The Firefox browser is put into Kiosk Mode, which prevents user access to the address bar. The content is displayed without the toolbar, menu, and URL field.

11. Click Finish to close the Wizard.

## Apply the Container Display Client to a Terminal

Container Host Display Clients are added to thin clients, or terminals, like any other Display Client.


The Container Display Client is added on the Display Client Selection page with the other Display Clients.

**Figure 117 - Display Client Selection Page**

1. Expand the Container Host branch, highlight the Container Display Client, and click the right arrow.

The selected Container Display Client launches when the terminal boots.

[Figure 118](#) shows the ThinManager Knowledge Base launches in the container on a thin client.

**Figure 118 - ThinManager Knowledge Base in Container**

## Install the TLS Certificates


A TLS Certificate is needed to provide secure authentication between the Container Host and the ThinServer service. There are two certificates and one key that must be generated in ThinManager and copied to the Container Host.

When Docker is installed, a configuration folder that contains the file **daemon.json** is created, which contains the names and locations of the keys and certificates. This file is found at: C:\ProgramData\docker\config.

Three files are needed to add the two certificates and one key to the Container Host.

By default, the certificates and keys are saved at C:\ProgramData\docker\certs.d. You must manually create the certs.d folder.

**Figure 119 - JSON File**




### *Certificate Authority Certificate*

The first certificate needed is the Certificate Authority (CA) Certificate, which is generated in the Certificate Authority Window.

1. Choose Manage>TLS Certificate.

The Certificate Authority dialog box appears.

Figure 120 - Certificate Authority




Setting	Description
Generate New Certificate	Click if you want to invalidate existing certificates, which ThinServer generates automatically during installation.
Import	Click if your site's IT department already uses Docker and generated a CA certificate that they want to use.
Certificate Length (days)	The number of days the CA certificate is valid. Change as needed from the default 7,300 days, or 20 years.
Save	Click to save the certificate so you can export it to the Container Host.

Figure 121 uses docker-ca-cert.pem as the CA certificate name. You must use the file name that was specified in the Docker configuration folder.

There is only one CA certificate needed per ThinManager system. However, this also means that a Docker Host cannot be shared by two independent ThinManager systems.

Figure 121 - CA Certificate Name




2. Click OK to exit the wizard.

Server Certificate

The second certificate is the Server Certificate, which is generated in the Container Host Wizard.

Figure 122 - TLS Certificate Button



1. Click TLS Certificate.

The TLS Certificate dialog box appears.




**Figure 123 - TLS Certificate**

The TLS Certificate dialog box does not show the Certificate and the Certificate Key until the Generate New Certificate button is clicked. The Certificate and the Certificate Key must be saved and moved to the Container Host.


2. Click Save for the Certificate.

By default, the Server Certificate is saved with a file name of `docker-server-cert.pem`, which must match the name specified in the Docker configuration folder.

**Figure 124 - Save Server Certificate**

3. Click Save for the Certificate Key.

Figure 125 - Save Certificate Key




*Install the Certificates*

1. Open the Docker Container Host server.
2. Copy the three files to the default location, C:\ProgramData\docker\certs.d, or the location you specified in the Docker config file. You must create the **certs.d** folder manually.
3. Restart the Docker service to register the new certificates.

[Figure 126](#) shows the three certificate files, generated through ThinManager, installed on the Container Host.

Figure 126 - Certificate Files on Container Host



**IP Cameras**

ThinManager supports cameras in the ThinManager system. Cameras, either IP or USB, can be configured to provide the camera feed to display clients on Terminals. This section covers how to define the camera as a Display Server. Delivery of the video to a Camera Display Client is covered in [Camera Display Clients on page 155](#).

There are three steps in integrating an IP camera into the ThinManager system.

1. Configure the camera and add it to your network using the guidelines from the camera manufacturer.
2. Add the configured camera to ThinManager as a Display Server source.
3. Deploy the content of the cameras by creating a camera display client and applying it to the Terminals.

USB cameras are added to a Terminal and configured. See [Define the IP Camera as a Display Server on page 105](#).

## Configure the IP Camera

Each camera manufacturer distributes their cameras with a default IP address and a default administrative account. These need to be configured to add the camera to your network. Methods vary between vendors, but a web interface is common.

**IMPORTANT** Please follow the instructions from the camera manufacturer to configure your camera for use.

**Figure 127 - Browser-based Camera Configuration**

Product: DCS-910 Firmware Version: 1.00

**D-Link**

DCS-910 // LIVE VIDEO SETUP MAINTENANCE STATUS HELP

**Wizard**

- Network Setup
- Dynamic DNS
- Image Setup
- Video
- Mail
- FTP
- Time and Date
- Logout

**NETWORK SETUP**

You can configure your LAN and Internet settings here.

Save Settings Don't Save Settings

**LAN SETTINGS**

☐ DHCP Connection
 ☒ Static IP Address
 ☐ PPPoE

IP Address: 10.7.10.71
 User ID:

Subnet Mask: 255.255.255.0
 Password:

Default Gateway: 10.7.10.1

Primary DNS: 68.87.68.162

Secondary DNS: 8.8.8.8

**PORT SETTINGS**

Second HTTP Port: ☐ Enable ☒ Disable

Port Number: 81

**UPnP SETTINGS**

**Helpful Hints..**

Select "DHCP Connection" if you are running a DHCP server on your network and would like an IP address assigned to your camera automatically. You may choose to manually enter a Static IP Address and all the relevant network information or select PPPoE if you connect your DCS-910 directly to the Internet that uses a PPPoE service. If you choose PPPoE you must enter the user ID and password that was given by your Internet Service Provider.


**DNS** (Domain Name System) server is an Internet service that translates domain names (i.e., www.dlink.com) into IP addresses (i.e., 192.168.0.20). The IP addresses can be obtained from your ISP.

**Primary DNS:** Primary domain name server that translates names to IP.

## Define the IP Camera as a Display Server

The Camera Configuration Wizard is launched from the Camera branch of the Display Servers tree.

1. To open the Display Servers tree, click the Display Servers icon at the bottom of the ThinManager tree.

**Figure 128 - Camera Branch of the Display Servers Tree**

2. Right-click on the Cameras branch and choose Add Camera to launch the Camera Configuration Wizard.

**Figure 129 - Camera Name Page**

The screenshot shows the 'Camera Configuration Wizard' window, specifically the 'Camera Name' page. The title bar says 'Camera Configuration Wizard'. The page header says 'Camera Name' and 'Enter the camera name and network location'. There is a 'Camera Name' text box containing 'Camera76' and a 'Change Group' button. Below this is the 'Camera Network Setup' section with a 'Type' dropdown set to 'IP Camera', an 'IP Address' field containing '10 . 6 . 10 . 76', and a 'Port' field containing '554'. At the bottom is the 'Camera Connection' section with a 'Streaming Protocol' dropdown set to 'RTSP - TCP'. Navigation buttons at the bottom are '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

3. Complete the Camera Name field.
4. In the Camera Network Setup section, chose either USB Camera or IP Camera from the Type pull-down menu.

## IP Camera

ThinManager supports IP cameras added to the network. A thin client that has a camera added makes a connection to the camera and streams the video feed directly. The video does not go through the ThinManager Server. ThinManager only tells the thin client to stream the video feed.

Choose a protocol that the camera uses from the following choices.

### *Legacy Motion JPEG*

Legacy Motion JPEG is the original protocol configuration for IP cameras in ThinManager.

For this option, choose the make and model from a list contained in the TermCap database. ThinManager populates the necessary URL.

### *Motion JPEG*

This protocol provides flexibility of camera choices because it does not require the use of a camera from the TermCap database.

Each camera uses a specific Motion JPEG URL, usually specified in the camera manufacturer's documentation.

Enter the Motion JPEG URL in the Custom URL field on the Camera Authentication page.

### *Real Time Streaming Protocol (RTSP)*


RTSP is preferred as it is most widely supported by camera companies.

RTSP has several transport layers—HTTP, TCP, UDP, and UDP multicast. Specify the URL that specific camera uses for the video stream.

For this option, follow these steps.

1. Choose IP Camera from the Type pull-down menu.
2. Enter the IP address of the camera in the IP Address field.
3. Choose the desired transport method from the Streaming Protocol pull-down menu.
4. Click Next.


The Camera Authentication page appears.

**Figure 130 - Camera Authentication Page**


The dialog box is titled "Camera Configuration Wizard" and "Camera Authentication". It prompts the user to "Enter the camera username and password". It contains three input fields: "Username" (with "admin" entered), "Password" (with four asterisks), and "Verify Password" (with four asterisks). Below these is a "Custom URL" section with a text area containing "rtsp://admin:\*\*\*\*@10.7.10.76:554/". At the bottom are buttons for "< Back", "Next >", "Finish", "Cancel", and "Help".

5. Enter the Username and Password of the account for the camera that allows streaming. The thin client is unable to access the video feed without an account unless the camera allows anonymous access.
6. Enter the RTSP URL specified by the camera manufacturer in the Customer URL field.
7. Click Finish.

The wizard closes and camera configuration is complete.

**Figure 131 - Camera Management Dialog**


The screenshot shows the ThinManager application window. On the left is a tree view under "Display Servers" containing "RDS Servers", "Cameras" (with "Camera71" selected), and "VNC Servers". The main pane shows the configuration for "Product: DCS-910" (a D-Link camera). It has tabs for "Config", "Connect", and "Event Log". The "Config" tab is active, showing sections for "Wizard" (with "Network Setup" selected), "Dynamic DNS", "Image Setup", "Video", "Mail", "FTP", and "Time and Date". The "Network Setup" section has "Save Settings" and "Don't Save Settings" buttons. The "LAN SETTINGS" section shows "Static IP Address" selected, with "IP Address" set to "10.7.10.71" and "User ID" set to "admin".

To access the camera's browser control panel, highlight the camera in the ThinManager tree and click the Connect tab. Make changes as needed.



- If a camera uses a 32-bit ActiveX, then it can be connected and viewed within a 32-bit ThinManager, but not a 64-bit ThinManager.
- If a camera uses a 64-bit ActiveX, then it can be connected and viewed within a 64-bit ThinManager, but not a 32-bit ThinManager.

The network settings and configuration are available, but not the live video feed.


## Define the USB Camera as a Display Server

USB cameras can be attached to ThinManager thin clients, and the video feed sent to display clients, on any ThinManager thin client.

To define the USB camera as a display server, follow these steps.

1. To open the Display Servers tree, click the Display Servers icon at the bottom of the ThinManager tree.

**Figure 132 - Camera Branch of the Display Servers Tree**



2. Right-click the Cameras branch and choose Add Camera.

The Camera Configuration Wizard appears.

**Figure 133 - USB Camera on Camera Name Page**

3. Complete the Camera Name field.
4. Select USB Camera from the Type pull-down menu.

The Terminal field appears dynamically.

5. Click Select.

The Choose Terminal dialog appears.

**Figure 134 - Choose Terminal Dialog**

6. Choose the correct Terminal and click OK.

The Terminal appears in the Terminal field of the Choose Terminal dialog.



**Figure 135 - Terminal Name in the Camera Name Page**

7. Click Next.


The Camera Authentication page appears.

**Figure 136 - Camera Authentication Page**

8. Enter the administrative account Username and Password information if your USB cameras use authentication.
9. Click Finish.

The camera appears in the Display Servers tree.

Figure 137 - Cameras in Display Servers Tree



A USB camera cannot be connected to and managed from the Connect detail pane in the ThinManager console.


VNC Servers

ThinManager uses Virtual Network Computing (VNC) to shadow thin clients in various ways.

- From within the ThinManager Server console
- From another Terminal using a Terminal Shadow Display Client
- Through a connection to any VNC Server to shadow from the administrative console or through a display client

All of these options are useful in shadowing PanelView Plus panels.

Figure 138 - VNC Servers Branch of the Display Servers Tree



To define the VNC server, follow these steps.

1. Click the Display Servers icon at the bottom of the ThinManager tree.

The Display Servers tree is displayed.

2. Right-click the VNC Servers branch and choose Add VNC Server.

The VNC Server Configuration Wizard dialog appears.

**Figure 139 - VNC Server Name Page of the VNC Server Configuration Wizard**

Required Settings	Description
VNC Server Name	Name of the device that is acting as the VNC server.
VNC Server IP Address	IP address of the device that is acting as the VNC server.
Port	The port that the VNC server is using. The default is 5900.
Password	Password for the VNC server, if needed.

3. Complete the fields on the VNC Server Name page.
4. Click Finish.

You must create a VNC Display Client to deploy the VNC shadow. See [VNC Shadow on page 190](#) for details.

## Workstations


ThinManager takes advantage of Microsoft Remote Desktop Protocol (RDP) to allow you to port a workstation to a thin client. Use RDP connectivity to connect to physical or virtual workstations and transfer the desktop to another computer.

To activate the remote desktop function on the workstation, follow these steps.

1. Right-click the My Computer icon and choose Properties, or double-click the System icon in Control Panel.

The System Properties dialog appears.


**Figure 140 - Workstation System Properties**



2. Under the Remote Desktop section, click Allow remote connections to this computer.
3. Click Select Users to specify which users can access the workstation.

The Remote Desktop Users dialog appears.

**Figure 141 - Remote Desktop Users**



4. To grant permission to users, click Add.

This makes the workstations sources. You deliver the workstation to the thin client by defining Workstation Display Clients as shown in the Content section.

See [Workstation Deployment on page 180](#) for details.

## VCenter Servers

VCenter Server support is deprecated with ThinManager version 13. If a VCenter Server is configured prior to an update from an earlier version to version 13 or later, then the configuration is retained. VCenter Server configuration is not visible or available if the system is initially installed as version 13 or later, or if there is no existing configuration prior to an upgrade.

ThinManager is compatible with virtual machines, just as it is compatible with physical machines. The easiest way to handle virtual machines is to treat them as physical machines.


If you use VMware ESXi™, you can connect using the ThinManager interface to access several of the management features provided by VMware VCenter®.

To add a VCenter Server, follow these steps.

1. Click the VCenter Servers icon at the bottom of the ThinManager tree.

The VCenter Servers tree appears.

**Figure 142 - VCenter Servers Tree**



2. Right-click the VCenter Servers branch and choose Add VCenter Server.

The VCenter Server Property Wizard appears.

Figure 143 - VCenter Server Property Wizard

**Virtual Machine Host Name**  
Enter VM Host name and IP Address

VCenter Server Name: V\_2012

VCenter IP Address: 10 . 7 . 10 . 50 [Discover]

**Log In Information**

User Name: admin

Password: [masked]

Verify Password: [masked]

< Back   Next >   Finish   Cancel   Help

- 3. Complete the VCenter Server Name and VCenter IP Address fields.
- 4. Enter the administrative account information into the Log In Information fields.
- 5. Click Finish.

After it connects and populates, highlight the newly added VCenter Server for it to appear in the Summary tab.

Figure 144 - Populated VCenter Servers Tree

**ThinManager**

Menu: Edit, Manage, Install, Tools, View, Remote View, Help

Toolbar: Restart, Reboot, Power On, Power Off, Calibrate Touchscreen, Send Message, Enable, Disable, Clear

**VCenter Servers**

- VCenter Servers
  - V\_2012
    - ha-datacenter
      - 2012\_1\_DC
        - 2012\_RDS\_2a

**Summary**

Attribute	Value
<b>Virtual Machine Summary</b>	
Name	2012_RDS_2a
Host Name	
IP Address	
Guest OS	Microsoft Windows Server 2012 (64-bit)
Memory Size	3972 MB
CPU Count	1
Provisioned Storage	64.14 GB
Committed Storage	60.00 GB

6. In the VCenter Servers tree, right-click the VCenter Server for a list of the following options.

VCenter Server Function	Description
<b>Power Operations</b>	
• Power On	Turns on a stopped or suspended virtual machine
• Power Off	Turns off a stopped or suspended virtual machine
• Suspend	Suspends a running virtual machine and stores the state
• Reset	Cycles power to the virtual machine to restart it
<b>Snapshot</b>	
• Take Snapshot	Captures and stores the state of the virtual machine
• Revert to Current Snapshot	Reapplies the stored state of a previously saved virtual machine
• Snapshot Manager	Launches the Snapshot management tool
<b>Rename</b>	Allows the virtual machine to be renamed
<b>Remove from Inventory</b>	Removes the virtual machine from the tree without deleting the files
<b>Delete</b>	Removes the virtual machine from the tree and deletes the file system

## Snapshots

Snapshots save the state of the virtual machine in a file, which allows you to preserve a working status before applying new applications, programs or updates. If the changes fail or are undesired, then the snapshot can be restored, allowing the virtual machine to return to the state it was in prior to the changes.


### Create a Snapshot

To take a snapshot of the state of the virtual machine, follow these steps.

1. In the VCenter Servers tree, right-click the virtual machine and choose Snapshot>Take Snapshot.

The Create Snapshot dialog appears.

**Figure 145 - Create Snapshot**



2. Enter the Snapshot Name and Snapshot Description.
3. Click OK to save the snapshot.


Multiple snapshots of a virtual machine can be taken.

Use a Snapshot

To make use of a snapshot, follow these steps.

- 1. In the VCenter Servers tree, right-click on the virtual machine and choose Snapshot>Snapshot Manager to launch the Snapshot Manager dialog box.

Figure 146 - Snapshot Manager




Snapshot Manager Buttons	Description
Revert To	Applies the selected saved snapshot
Delete	Deletes a highlighted snapshot
Delete All	Deletes all saved snapshots
Edit	Opens the Create Snapshot dialog to allow changes to the name and description
OK	Closes the Snapshot Manager

The Snapshot Manager dialog box displays all saved snapshots for the selected virtual machine, including the name, description, and creation date of a highlighted snapshot.

- 2. Click an action to take regarding a snapshot.

A confirmation dialog box appears.

Figure 147 - Revert to Current Snapshot Warning



- 3. Click Yes to confirm the action.



The dialog box is dependent upon the snapshot action taken. The one shown above is only one example.




## Adding a Virtual Server

Virtual Remote Desktop Servers that reside on a VCenter Server can be defined using a wizard.

To define a Virtual Remote Desktop Server that resides on a VCenter Server, follow these steps.

1. Click the Display Servers icon at the bottom of the ThinManager tree to open the Display Servers tree.


**Figure 148 - Remote Desktop Servers Tree**



2. Right-click the RDS Servers branch and choose Add Virtual Remote Desktop Server.

The Virtual Machine Selection page appears.

Figure 149 - Virtual Machine Selection Page




- 3. Choose your VCenter Server from the pull-down if you have multiple servers defined.

The VCenter Server tree populates the selection box.

- 4. Choose the virtual Remote Desktop Server you want and click Next.

The Terminal Server Name page appears.

Figure 150 - Remote Desktop Server Name Page



5. Complete the Log In Information fields with the administrative account information as you do other Remote Desktop Servers. The IP address populates automatically.
6. (Optional) Click Next and check Available for Display Clients using SmartSession for load balancing.
7. Click Finish.


The tree displays a different icon for a Remote Desktop Server when it is configured as a virtual Remote Desktop Server. A virtual Remote Desktop Server created as a physical Remote Desktop Server displays the same icon as a physical Remote Desktop Server.

**Figure 151 - Remote Desktop Server Icons**



Virtual Remote Desktop Servers can be used in display clients just like physical Remote Desktop Servers.

**Figure 152 - Display Servers Tree**



**Notes:**

## Content

Content is sent to devices through Display Clients. This chapter discusses the various display clients through which content is delivered.

### Remote Desktop Services Display Clients


The most common content sent to a device is a Windows application. Applications are sent as Remote Desktop Services display clients. You can either give a user a full desktop, or limit them to a specific application with AppLink.

With MultiSession, ThinManager allows you to deploy several applications to a device at once. Use the Display Client Configuration Wizard to define applications.

To launch the Display Client Wizard, follow these steps.

1. Launch the Display Client Configuration wizard by selecting the Display Client icon at the bottom of the ThinManager tree.

**Figure 153 - Launch the Display Client Configuration Wizard**



2. Right-click Remote Desktop Services, and choose Add Display Client.

The Display Client Wizard appears.

## Desktop

You can present a Desktop to a terminal for a user. The device can log in automatically with the terminal account. Alternatively, you can allow the user to log in manually so that they receive the desktop that is associated with their user account.

**Figure 154 - Client Name Page of the Display Client Wizard**

Display Client Wizard

**Client Name**  
Enter the Display Client name.

Display Client Name

Client Name

☐ Set a Display Name

Type of Display Client

Display Client Group

Change Group

Permissions

< Back Next > Finish Cancel Help


1. Enter a name for the display client in the Client Name field.

The Type of Display Client field automatically populates when you open the Display Client Wizard as we did in the previous step. When you open the Display Client Wizard from the top-level Display Clients branch, you must choose the Type of Display Client you want from the pull-down menu.

2. Click Next.

The Display Client Options page appears.

Figure 155 - Display Client Options Page




Setting	Description
<b>Client Options</b>	
Allow Display Client to be tiled	Allows the display client to be tiled.
Allow Display Client to be moved (MultiMonitor)	When using MultiMonitor, this setting allows the display client to be moved from screen to screen. A movable display client can be anchored with a setting on the Screen Options page of the Terminal Configuration Wizard.
Include Camera Overlays	Allows an IP camera overlay to be added to this display client.
Include Virtual Screen Overlays	Allows a display client overlay to be added to this display client. See <a href="#">Virtual Screens on page 195</a> for details.
Delay until ThinManager User present	Hides the display client until a ThinManager user logs in. When the display client launches, it uses the credentials of the ThinManager user to start the session.
<b>Connection Options</b>	
Always maintain a connection	Keeps a session active—it reconnects and restarts if it is closed. Clear the checkbox so the user can close a session and another session does not start automatically.
Connect at boot-up	Starts a session for the display client at boot-up. Clear the checkbox so a user action is required to start the session.
Disconnect in the background	In a MultiSession configuration, disconnects once it is moved into the background. Use to require fewer resources.

3. Check the options that apply to the Display Client and click Next.

The Remote Desktop Services and Workstation Options page appears.

Figure 156 - Remote Desktop Services and Workstation Options Page



The Remote Desktop Services and Workstation Options page of the Display Client Wizard is key to Display Client configuration. These settings control how Remote Desktop Server content is deployed to the Terminal.


Setting	Description
Allow Auto-Login	Automatically logs in to the session when a user account is applied to the Terminal. Clearing this checkbox displays the login window and forces a manual login, which is useful to provide a user with a login based on their group policy.
Application Link	Launches a single application instead of a Desktop. The session lacks the Explorer shell and does not show Desktop icons or the Start menu. Close the AppLink program to end the current session and starts a new session with the application running. This setting allows the administrator to control content to the user in a simple manner without the need to use group policies. <b>Note:</b> This setting is not valid with workstations after Windows XP.
SmartSession	Adds SmartSession to the display client, which provides load balancing between member Remote Desktop Servers. SmartSession uses CPU availability, memory, and the number of sessions on the member Remote Desktop Servers to determine the load on the servers. Thin clients connect to the Remote Desktop Server with the most available resources.
Enforce Primary	Makes a thin client reconnect to its original Remote Desktop Server if the RDS fails and recovers. Disabled when SmartSession is checked.
Instant Failover	Allows you to specify at least two Remote Desktop Servers. On startup, the Terminal connects and initiates sessions on two Remote Desktop Servers, but displays one session only. If the first Remote Desktop Server fails, the session of the second Remote Desktop Server session is immediately displayed, eliminating any downtime due to Remote Desktop Server failure. With this setting, the display client looks for two active sessions; so, if one Remote Desktop Server fails, the display client starts a session on a third Remote Desktop Server if there is one in the server list.

- 4. (Optional) Clear the Allow Auto-Login checkbox if you want to provide the login prompt and force manual login.
- 5. Clear the Application Link checkbox to deploy to Desktop.
- 6. Click Next.

The Session Resolution/Scaling Options page appears.



Figure 157 - Session Resolution/Scaling Options Page




The Session Resolution/Scaling Options page sets the ability of the display client to scale the session. This page has parameters that can be configured:.

Setting	Description
<b>Session Scaling Options</b>	
Maintain Aspect Ratio	Keeps the aspect ratio of the session constant when scaling. With the checkbox cleared, the session fits the available display size.
Scale Down Only	Allows a session to be shrunk for a thumbnail, but does not expand it beyond the original size designation.
<b>Screen Resolution Options</b>	
Don't Use Screen Resolution	Overrides the session resolution and enables the Resolution settings for configuration of a new display resolution.
Resolution	Pull-down menus allow you to select a new resolution for the display when Don't Use Screen Resolution is checked.

7. Click Next.

The Display Client Members page appears.

**Figure 158 - Display Client Members Page**

The Display Client Members page allows you to select the Remote Desktop Servers on which to run the application.

8. Click a server to highlight it, and use the left and right arrows to move the Remote Desktop Servers between the Available and Selected Remote Desktop Servers lists.



If your defined Remote Desktop Servers do not show in the list, it is likely you checked SmartSession on the Remote Desktop Services and Workstation Options page without checking Available for Display Clients using SmartSession on the Remote Desktop Server Capabilities page of the Remote Desktop Server Wizard.

To get your defined Remote Desktop Servers to appear in the list, follow these steps.

- a. Click Edit Server List to open the Remote Desktop Server List Wizard.
- b. Double-click or highlight the servers you want to appear in the list, and click Edit Server to open the Remote Desktop Server Wizard.
- c. Click Next until you reach the Remote Desktop Server Capabilities page and check Available for Display Clients using SmartSession.
- d. Click Finish.

Adding two Remote Desktop Servers to the Selected Remote Desktop Servers list provides failover. In normal failover, the terminal connects to the first Remote Desktop Server. If the connection fails, it connects to the second RDS.

SmartSession load balancing does not follow the list order. Instead, the terminal connects to the Remote Desktop Server with the most resources available.


9. Click Finish.

The Display Client Wizard closes, and the new Display Client appears in the Remote Desktop Services branch Display Clients navigation pane.

## Display Client Using Remote Desktop Server Groups


The Display Client Wizard appears differently when Remote Desktop Server Groups are used to speed selection of Remote Desktop Servers.

**Figure 159 - Remote Desktop Server Groups Defined in the RDS Servers Tree**



This example has two RDS Groups: OfficeServers and ProductionServers.

**Figure 160 - Display Client Members Page with RDS Server Groups**




The Display Client Members page has a different format to select the Remote Desktop Servers.

1. Click Add.

The Select Remote Desktop Server or Group dialog box appears.

**Figure 161 - Select Remote Desktop Server or Group**



- 2. Highlight the desired RDS Group and click OK.

The Display Client Members page appears with the desired RDS Group populated to the Selected Remote Desktop Servers field.

**Figure 162 - Display Client Members Page with RDS Server Groups**



Two RD Gateway Settings control the use of the Microsoft RDP Gateway.

Setting	Description
Use RD Gateway Server	Prompts the Display Client to use the Microsoft RD Gateway. See <a href="#">Remote Desktop Server Group on page 77</a> .
Bypass RD Gateway server for local address	Allows the Display Client to use a Remote Desktop Server without going through the RD Gateway if the Terminal and Remote Desktop Server are on the same subnet.

3. Click Finish.

## Single Application Deployment with AppLink

ThinManager uses its AppLink function to launch a single application, instead of a Desktop, which allows you to control what the user sees and interacts with.

The application is launched instead of the Windows Explorer Desktop. Closing the application causes the terminal to disconnect and launch a new connection to the server with the application running.

To create a single application display client, launch the Display Client Configuration Wizard.

1. Click the Display Clients icon at the bottom of the ThinManager tree.
2. Right-click the Remote Desktop Services branch, and choose Add Display Client.

The Client Name page of the Display Client Wizard appears.

**Figure 163 - Client Name Page**

3. Enter a name for the display client in the Client Name field.

- 4. (Optional) Check Set a Display Name to enable the Display Name field and enter a simplified Display Client name in the tree.




The Type of Display Client is automatically chosen when you right-click the Remote Desktop Services branch. However, when you right-click the top-level Display Clients branch, you must choose the type from the Type of Display Client pull-down menu.

- 5. Click Next.

The Display Client Options page appears.

Figure 164 - Display Client Options Page



Setting	Description
<strong>Client Options</strong>	
Allow group to be tiled	Allows the Display Client Group to be tiled.
Allow Group to be moved (MultiMonitor)	Allows the Display Client to be moved from one MultiMonitor screen to another. A display client that allows it to be moved can be anchored with a setting on the Screen Options page of the Terminal Configuration Wizard.
Include IP Camera Overlays	Allows an IP Camera overlay to be added to this display client.
Include Virtual Screen Overlays	Allows a virtual screen overlay to be added to this display client. See <a href="#">Virtual Screens on page 195</a> for details.
<strong>Connection Options</strong>	
Always maintain a connection	Keeps a session active—restarts and reconnects—if it is closed. Clear this checkbox to allow the user to close a session and not have another session start automatically.
Connect at boot-up	Starts a session for this display client at boot-up. When the checkbox is clear, a user action is required to start the session.
Disconnect in background	A display client being used in a MultiSession configuration disconnects once it is moved into the background. Use this option to require fewer resources.


- 6. Choose the desired Client Options and click Next.

The Terminal Services Display Client Type page appears.



This page is not shown unless you upgrade from a system with Citrix ICA, or you have added a registry entry as shown in [Citrix Servers on page 69](#).

**Figure 165 - Remote Desktop Services Display Client Type Page**




ThinManager thin clients can use the default Microsoft Remote Desktop Protocol (RDP) or Citrix ICA (Independent Computing Architecture).

7. Click the terminal server type to use with the display client and click Next.

The Remote Desktop Services and Workstation Options page appears.

**Figure 166 - Remote Desktop Services and Workstation Options**




The Remote Desktop Services and Workstation Options page is the key page in Display Client configuration. These settings control how Remote Desktop Server content is deployed to the Terminal.

Connection Options	Description
Allow Auto-Login	Automatically logs in to the session if a user account is applied to the terminal, which is the typical setting. Clear this checkbox to display the log in window and force a manual login, which is useful in order to provide a user with a login based on their group policy.
Application Link (AppLink)	Launches a single application instead of a Desktop. The session lacks the Explorer shell and does not show Desktop icons or the Start menu. Closing the AppLink program terminates the session and starts a new one as the application runs. This allows the administrator to control content sent to the user in a simple manner without needing to use group policies.
SmartSession	Adds SmartSession to the display client, which provides load balancing between member Remote Desktop Servers. SmartSession uses CPU availability, memory, and the number of sessions on the member Remote Desktop Servers to determine the load on the servers. Thin clients connect to the Remote Desktop Server with the most available resources.
Enforce Primary	Tells a thin client to reconnect to its original Remote Desktop Server if that Remote Desktop Server failed and recovered. Not available when SmartSession is selected.
Instant Failover	Activates Instant Failover, in which you specify at least two Remote Desktop Servers. On boot the Terminal, it connects and starts sessions on two Remote Desktop Servers, but only displays one session. If the first Remote Desktop Server fails, the session of the second Remote Desktop Server session is immediately displayed, which eliminates any downtime due to Remote Desktop Server failure. An Instant Failover display client requires two active sessions in case one Remote Desktop Server fails, then the display client starts a session on a third Remote Desktop Server if one is in the server list. Instant Failover is free for ThinManager but requires a second application license as two active sessions are running the application.

8. Check Application Link to deploy a single AppLink application.
9. (Optional) Clear the Allow Auto-Login checkbox to provide the log in prompt and force manual login.
10. Click Next.

The Session Resolution/Scaling Options page appears.

**Figure 167 - Session Resolution/Scaling Options Page**






The Session Resolution/Scaling Options page sets the ability of the display client to scale the session. This page has parameters that can be configured.

Options	Description
<b>Session Scaling Options</b>	
Maintain Aspect Ratio	Keeps the aspect ratio of the session constant when scaling. Clear the checkbox for the session to fit the available display size.
Scale Down Only	Allows a session to be shrunk for a thumbnail, but does not expand it beyond the original size designation.
<b>Screen Resolution Options</b>	
Don't Use Screen Resolution	Allows for override of the session resolution and to set a new resolution for the display.
Resolution	Allows you to select a new resolution for the display when Don't Use Screen Resolution is checked.

11. Click Next.

The Display Client Members page appears.

**Figure 168 - Display Clients Members Page**



The Display Client Members page of the Display Client Wizard allows the selection of Remote Desktop Servers on which you want the application.

12. Highlight the Remote Desktop Servers you want to use in the Available Remote Desktop Servers list and click the right arrow to move them to the Selected Remote Desktop Servers list.



If your defined Remote Desktop Servers do not appear in the Available Remote Desktop Servers list, it is likely you checked SmartSession on the Remote Desktop Services and Workstation Options page without checking Available for Display Clients using SmartSession on the Remote Desktop Server Capabilities page of the Remote Desktop Server Wizard.

To get your defined Remote Desktop Servers to appear in the list, follow these steps.


- a. Click Edit Server List to open the Remote Desktop Server List Wizard.
- b. Double-click or highlight the servers you want to appear in the list, and click Edit Server to open the Remote Desktop Server Wizard.
- c. Click Next until you reach the Remote Desktop Server Capabilities page and check Available for Display Clients using SmartSession.
- d. Click Finish.

Adding two Remote Desktop Servers to the Selected Remote Desktop Servers list provides failover. In normal failover, the terminal connects to the first Remote Desktop Server. If that fails, it connects to the second.

SmartSession load balancing does not follow the list order. Instead, the terminal connects to the Remote Desktop Server with the lightest load.

Alternatively, if Remote Desktop Server Groups are used to speed the selection of Remote Desktop Servers, then the Display Client Members page displays the Selected Remote Desktop Servers list only.

**Figure 169 - Display Client Members Page**




a. Click Add.

The Select Remote Desktop Server or Group dialog box appears.

- b. Choose the Remote Desktop Servers or Groups and click OK.
- c. Click Next.

The AppLink page appears.


**Figure 170 - AppLink Page**

The screenshot shows a window titled "Display Client Wizard" with a close button in the top right corner. Inside the window, there is a section titled "AppLink" with the instruction "Enter the linked application path." and a small icon of a person. Below this, there is a group box labeled "AppLink Path" containing three text input fields. The first field is labeled "Program Path and Filename" and has a "Browse" button to its right. The second field is labeled "Command Line Options" and also has a "Browse" button to its right. The third field is labeled "Start in the following folder" and has a "Browse" button to its right. At the bottom of the window, there are five buttons: "< Back", "Next >", "Finish", "Cancel", and "Help".

The AppLink Page contains a field for the path to the executable to launch the desired application.


13. Enter the path to the application in the Program Path and Filename field, or click Browse, which launches a file browser.

Figure 171 - File Browser



a. If browsing to the file location, click Open to populate the Program Path and Filename field.

Figure 172 - Filled Program Path and Filename Field



14. Click Finish to complete the wizard and save the configuration.

Here are a few considerations for when you enter the application in the Program Path and Filename field.

- The file browser is on the ThinManager Server and not the Remote Desktop Server unless you installed ThinManager on your Remote Desktop Server.
- The path to the application needs to be the same on each Remote Desktop Server.
- If the file is different on different servers, you may need to use a batch file to launch the application using different paths.

Create a batch file in the same location on each Remote Desktop Server. The batch file can be as simple as 3 lines, as follows.

```
CD "C:\Program Files\Microsoft Office\Office14"  
  
Start EXCEL.EXE  
  
CD\
```

The batch file may need different paths on different servers. The first line is changed to reflect the location on that particular Remote Desktop Server.


```
CD "C:\Program Files (x86)\Microsoft  
Office\Office14"  
  
Start EXCEL.EXE  
  
CD\
```

This first line uses Program Files (x86) instead of Program Files to reflect the location on that particular Remote Desktop Server.

When a terminal connects to a Remote Desktop Server, it is directed to the batch file.


The batch file directs the terminal to the right location.

Figure 173 - Batch File as the Program Path



The batch file must be in a consistent location when using multiple Remote Desktop Servers.

Figure 174 - Created Display Clients in ThinManager Tree




Once you have created a display client, it appears in the Display Clients branch of the ThinManager tree.

## Connection Options

Remote Desktop Services Display Clients have a variety of Connection Options, which are controlled on the Remote Desktop Services and Workstation Options page of the Display Client Wizard.

**Figure 175 - Remote Desktop Services and Workstation Options Page**



**Table 1 - Connection Options**

Connection Options	Description
Allow Auto-Login	Automatically logs in to the session if a user account is applied to the terminal, which is important for instant failover so that the backup session is immediately displayed without user intervention. This is the default setting. Clearing this checkbox displays the login window and forces a manual login, which is useful to provide a user with a login based on their group policy.
Application Link (AppLink)	Launches a single application instead of a Desktop icons or a Start menu, which allows you to control a user's access. Closing the AppLink program ends the current session and starts a new session with the application running, which allows the administrator to control content to the user in a simple manner without needing to use group policies.
SmartSession	Adds SmartSession to the display client, which provides load balancing between member Remote Desktop Servers.
Enforce Primary	Causes a thin client to reconnect to its original Remote Desktop Server if that Remote Desktop Server fails and recovers. Thin Manager uses a list of assigned Remote Desktop Servers to which the terminal can connect. The top RDS is considered primary. Not available when SmartSession is selected.
Instant Failover	Allows you to specify at least two Remote Desktop Servers. On startup, the terminal connects and initiates sessions on two Remote Desktop Servers, but displays one session only. If the first Remote Desktop Server fails, the session of the second Remote Desktop Server session is displayed immediately, which eliminates any downtime due to Remote Desktop Server failure. With this setting, the display client looks for two active sessions; so, if one Remote Desktop Server fails, the display client starts a session on a third Remote Desktop Server if there is one in the server list.

1. Check the desired connection options and click Next.


### *Allow Auto-Login*

See the description of this connection option in [Table 1](#).

Application Link (AppLink)

The following is information additional to the Deployment Option descriptions regarding Application Link in [Table 1 on page 141](#).

Figure 176 - AppLink Page



- 1. Complete the required fields on the AppLink page.


Field	Description
Program Path and Filename	Enter the path to the desired application in the field, or click Browse to navigate to the executable file using a browser. <sup>(1) (2)</sup>
Command Line Options	This field provides a space for command line options and switches. This field may not be required.
Start in the following folder	This field is provided in order to specify the working directory for the program when using a relative path for the initial program. Click Browse to navigate to the executable file using a browser. <sup>(2)</sup> This field may not be required.

(1) Double-quotation marks may be needed when there is a space in the path.

(2) If a Remote Desktop Services Display Client contains several Remote Desktop Servers, the path must be valid on all Remote Desktop Servers. If different Remote Desktop Servers have different paths to the desired program, write a batch file to open the program.




**Figure 177 - Command Prompt Shortcut Properties**



The AppLink fields can be explained by looking at the properties of a shortcut.

The Command Prompt shortcut property has a Target field and a Start in field. The Target field contains the path to the executable. The Start in field contains the home directory for the application.

**Figure 178 - AppLink Path**



[Figure 178](#) shows how the path data from the shortcut is used in AppLink.

The Target field from [Figure 177](#) is equivalent to the Program Path and Filename field in [Figure 178](#).

The Start in field in [Figure 177](#) is equivalent to the Start in the following folder field in [Figure 178](#).



Usually, the Start in the following folder is not needed.

**Figure 179 - Website Deployment**

- a. To launch a browser, include the URL of the desired site in the Command Line Options field.




Windows Server 2008, 2012, and 2016 need the AppLink path to be on the allow list in the Server Manager>Collections>RemoteApp Programs of the Remote Desktop Server.

Alternatively, follow these steps to configure the group policy to allow any initial program.


- a. Open the Group Policy.
- b. Navigate to Computer Configuration>Administrative Templates>Windows Components>Remote Desktop Services>Remote Desktop Session Host>Connections.
- c. Set the Restrict Remote Desktop Services user to a single Remote Desktop Services session parameter to Enabled.

Figure 180 - RemoteApp Programs Allow List



2. Include the application in your allow list by using the Publish RemoteApp Programs task.
3. Once the application is published, right-click the application in your allow list to open the properties.

Figure 181 - Allow Any Command-line Parameters Setting




4. Under Command-line Parameters, click Allow any command-line parameters, which lets you pass specific files or URLs to the display client.
5. Click Apply and then OK.

SmartSession

The SmartSession Configuration page allows for the adjustment of SmartSession values by adjusting the weights of SmartSession settings. ThinManager multiplies the CPU utilization, memory (RAM) utilization, and number of sessions on the Remote Desktop Server by the weight shown to define the SmartSession Remote Desktop Server’s available resources. The higher the weight value for a parameter, the greater importance that parameter has in the load determination for SmartSession.

Figure 182 - SmartSession Load Balancing Graph



ThinManager uses the following formula to calculate SmartSession load balancing.

$$\text{SmartSession Load} = (\text{CPUwt} \times \text{CPU}\%) + (\text{RAMwt} \times \text{RAM}\%) + (\text{SessionWt} \times \text{Session}\%)$$

$$\text{The load} = (\text{CPU weight} \times \text{the CPU Use}\%) + (\text{Memory weight} \times \text{Memory Use}\%) + (\text{Session weight} \times \text{Session Number}\%)$$

The Weight is configurable in the Display Client Wizard. The % range is configurable in the Remote Desktop Server Wizard.

SmartSession Weights

The Weight of the SmartSession parameter—processor, memory, or sessions—can be adjusted to make it a larger influence in the final calculation in total SmartSession load. The Weights can be changed on the SmartSession Settings page of the Display Client Wizard.

**Figure 183 - SmartSession Settings Page of the Display Client Wizard**

Field	Description
CPU Utilization Weight	The CPU multiplier.
Memory Utilization Weight	The Memory multiplier.
Session Weight	The Session multiplier.
Queue Time Min (s)	Time a terminal waits in the queue before being sent to a Remote Desktop Server that has another terminal connecting. The terminal may wait longer than this value to connect if the CPU of the Remote Desktop Server exceeds the Maximum CPU Utilization defined on the SmartSession Configuration page of the Remote Desktop Server Configuration wizard.
Queue Time Max (s)	Maximum time a terminal waits in the queue before being sent to the Remote Desktop Server to log in regardless of the load.
Infinite	When checked, ThinManager waits until the CPU utilization of the Remote Desktop Server regains an acceptable range before sending other terminals to it to log in.

The SmartSessions Settings page only appears before the AppLink page if SmartSession is checked on the Remote Desktop Services and Workstation Options page, see [Figure 175](#). The SmartSession Settings page allows you to change the weight of each SmartSession load balancing component.

Increasing the weight of one of the components increases its value and makes it more sensitive to overload of that resource. For example, if you are concerned with the CPU being taxed on the servers, you can increase the CPU Utilization Weight to make that value increase the SmartSession Load.

### SmartSession Ranges

Normally, ThinManager uses the full ranges of CPU and RAM to determine the SmartSession load. You can adjust those ranges in the Remote Desktop Server Wizard.


To open the Remote Desktop Server Wizard and adjust ranges, follow these steps.

- 1. Double-click the desired server on the Remote Desktop Servers branch of the Display Servers tree.

The Remote Desktop Server Wizard appears.

- 2. In the Remote Desktop Server Wizard, click Next until the SmartSession Configuration page appears.

**Figure 184 - SmartSession Configuration Page**



Field	Description
CPU Utilization	The percentage of CPU usage on the Remote Desktop Server.
Memory Utilization	The percentage of Memory usage on the Remote Desktop Server.
Sessions	The number of sessions on a Remote Desktop Server.
Minimum	The value that ThinManager uses as the starting point of the load. A value below the Minimum is considered to be unused.
Maximum	The value that ThinManager considers the parameter as reaching 100% utilized and is unavailable.

Each resource that ThinManager measures for SmartSession load balancing has an adjustable range. The CPU Utilization and the Memory Utilization fields use a scale of 0...100%. The Sessions resource is based on 50 sessions, where 0 sessions is 0%, 25 sessions is 50%, and 50 sessions is 100% utilization.

If you are concerned about using all your resources on a server, you can lower the Maximum setting. For example, if you change the Sessions Maximum to 25, that means 25 sessions is 100% utilization, and ThinManager considers the server less available. Likewise, if you change the CPU Utilization Maximum to 75%, that tells ThinManager that the server is loaded at 75% CPU utilization, which leaves some spare CPU available.

These numbers can be left at the default settings unless you notice a performance problem. The Weights or Ranges can be adjusted through trial and error to determine the best performance.



Values are not prevented from exceeding the maximum or minimum. The values represent the levels that 'No Utilization' or 'Full Utilization' is reached.

3. Set the Minimum and Maximum values accordingly, and click Finish.

## Queuing

During failover, Queuing smooths the transition from one server to another.

At startup, a session usually requires more resources to initialize than it needs to run. If a server fails and all of its terminals switch to a back-up server, the many session startups may overload and strain the new server. This scenario is especially true with HMIs, SCADAs, and other applications that demand resources.

When a terminal first starts an application that uses SmartSession, ThinManager checks the resources of the member servers and sends the terminal to the server with the lightest load—the one with the most available resources.

Queuing acts like an intelligent bottleneck. When ThinManager detects all the servers have depleted their resources, it waits until the loads drop and resources become available before the server assignments are given to the terminals. Without Queuing, the terminals switch immediately, which places a demand on the system that greatly slows performance until all the sessions initialize and reach stable load levels.

**Figure 185 - SmartSession Settings Page of the Display Client Wizard**

Queuing is automatically applied to SmartSession Display Clients. The default settings provide a minimum wait time of 0 seconds and let terminals connect after 120 seconds even if the load does not decrease.


If the server is hindered by the default settings, try a longer interval. Check Infinite to keep the terminal waiting until the load decreases to an acceptable level. However, if the server has a problem, such as a memory leak, then the resources may never decrease enough to allow the terminals to connect. It is better to increase the Max field to a longer interval.

SmartSession load balancing and Queuing can be applied to a display client with a single member Remote Desktop Server. This configuration allows the single server to have the terminals connect in an orderly fashion, spreading the demand for start-up resources instead of all connecting at the same time and overloading the server.

### *Enforce Primary*

ThinManager uses a list of Assigned Remote Desktop Servers to which the terminal can connect. The top Selected Remote Desktop Server is considered the primary Remote Desktop Server.

**Figure 186 - Primary Remote Desktop Server**



The thin client connects to the Remote Desktop Servers in the order of the Selected Remote Desktop Servers list. If the terminal fails to connect to the first one, it tries the second one, then the third one, until it finds a listed server that allows a connection.

With Enforce Primary, the top Remote Desktop Server in the list is considered the Primary Remote Desktop Server, and the terminal always tries to connect to this server. If the terminal is running on the primary server, and the server fails, then the terminal switches to a back-up server. However, the terminal



monitors the primary Remote Desktop Server. If the primary Remote Desktop Server becomes available, then the terminal switches back to its assigned Primary Remote Desktop Server.

## Failover

Failover in ThinManager is configured when two or more Remote Desktop Servers are assigned to a terminal. If the first server fails, the terminal detects it and switches to the back-up server, which prevents downtime and loss of productivity.




It is a best practice to use Failover in every ThinManager system.

Here are the requirements for Failover.

- Two or more Remote Desktop Servers
- The same applications installed in identical locations on each Remote Desktop Server
- The same Windows accounts on each Remote Desktop Server

**Figure 187 - Display Clients Without Failover and With Failover**




To configure Failover, follow these steps.

1. Define multiple Remote Desktop Servers using the Remote Desktop Server Wizard. For more information, see [Defining Remote Desktop Servers in ThinManager on page 61](#).
2. Add two or more servers to the Selected Remote Desktop Servers list on the Display Client Members page of the Display Client Wizard.

**Figure 188 - Terminal Connected to First Remote Desktop Server**

The Terminal connects to the first Remote Desktop Server in the Selected Remote Desktop Server list.

**Figure 189 - Terminal Connected to Second Remote Desktop Server**

If the first Remote Desktop Server fails, the terminal detects it, disconnects, and tries the next server in the Selected Remote Desktop Servers list. It launches the same display client with the same credentials.

The speed in which server failure is detected can be modified on the Monitoring Configuration page of the Terminal Configuration Wizard.

To open the Terminal Configuration Wizard, follow these steps.

1. Click the Terminals icon at the bottom of the ThinManager navigation pane.
2. Right-click a terminal in the Terminals branch, and choose Modify.

The Terminal Configuration Wizard appears, opened at the first page.

3. Click Next until the Monitoring Configuration page appears.

**Figure 190 - Monitoring Connection Page of Terminal Configuration Wizard**

Field	Description
<b>Pre-set Monitor Intervals</b>	
Custom	Allows administrator to change settings from defaults.
Fast/Medium/Slow	A set rate for the frequency with which the Remote Desktop Server status is checked.
Monitor Interval (s)	Time the terminal waits before it attempts to reconnect.
Monitor Timeout	Time interval between reconnection attempts.
Monitor Retry	Number of times the terminal tries to reconnect before failover.
Primary Up Delay Multiplier	A constant used to generate the Primary Up Delay time.
Primary Up Delay	A delay—usually, 30...60 seconds—added to allow a Remote Desktop Server to fully boot before the terminal tries to log in. Equal to the Monitoring Interval multiplied by the Primary Up Delay Multiplier. Prevents a terminal that uses Enforce Primary from a return to its primary Remote Desktop Server before it is ready.

When a ThinManager Ready thin client or ThinManager Compatible thin client connects to a Remote Desktop Server and starts a session, it forms a secure socket connection with a heartbeat. If the connection is lost, the terminal tries to reconnect. If it fails, it connects to the next Remote Desktop Server in the Selected Remote Desktop Servers list.

Using the Fast setting, a terminal waits five seconds, tries to reconnect; waits one second, tries to reconnect a second time; waits a second, tries to reconnect a third time; then switches to the other server. This takes 10...20 seconds in a real-world scenario.

There are other settings, which include a custom setting; but the slower settings are usually not needed with today's fast networks.

The terminal can switch to a backup in 10...20 seconds, but the applications need to load. If you do not want to wait for the application to load, you can use Instant Failover. See [Instant Failover on page 154](#) for more information.

## Instant Failover

A Display Client configured with Instant Failover (see [Figure 175 on page 141](#)) sends the terminal to connect to two Remote Desktop Servers at startup, which gives it two active sessions.




You may need a second license from your application vendor in order to use Instant Failover.

**Figure 191 - Instant Failover with Two Active Sessions**



If the first Remote Desktop Server fails, the session of the second Remote Desktop Server session is immediately displayed, which eliminates any downtime due to Remote Desktop Server failure.

**Figure 192 - Terminal with Instant Failover and Backup Sessions**



An Instant Failover display client has two active sessions; so, if one Remote Desktop Server fails, the display client starts a session on a third Remote Desktop Server if there is one in the Selected Remote Desktop Servers list.

These are the requirements for Instant Failover.

- Two or more Remote Desktop Servers
- The same applications installed in identical locations on each Remote Desktop Server
- The same Windows accounts on each Remote Desktop Server
- The Display Client needs Instant Failover checked on the Remote Desktop Services and Workstation Options page Display Client Wizard



Check Allow Auto-Login (see [Figure 175 on page 141](#)) so switching is automatic and does not require a user to log in to start the session. Also, see [Enforce Primary on page 150](#).

## Camera Display Clients

Camera video feed can be displayed on ThinManager Ready thin clients and ThinManager Compatible thin clients.


- Configure the camera device according to the camera vendor guidelines.
- Define the camera as a Camera Display Server.
- Create a Camera Display Client and add camera output as overlays. See [Camera Display Clients on page 155](#).
- Add the Camera Display Client to a Terminal. See [Terminal Configuration Wizard in ThinManager on page 221](#).

Camera Display Client applications for the Terminal are defined using the Display Client Configuration Wizard.

To define a Camera Display Client application for the terminal, follow these steps.

1. Click the Display Clients icon at the bottom of the ThinManager navigation pane.

**Figure 193 - Add Camera Display Client**



2. Right-click on the Camera branch and choose Add Display Client.

The Display Client Wizard appears, opened at the Client Name page, which sets the name and type of Display Client.

**Figure 194 - Camera Display Client Name Page of the Display Client Wizard**

Display Client Wizard

**Client Name**  
Enter the Display Client name.

Display Client Name  
Client Name: Camera\_2  
☐ Set a Display Name

Type of Display Client  
Camera

Display Client Group  
 Change Group

Create at least one camera overlay


< Back   Next >   Finish   Cancel   Help

3. Complete the required fields.

Field/Setting	Description
Client Name	Use to name the Display Client.
Set a Display Name	Allows assignment of a different name to display in the ThinManager tree.
Type of Display Client	Choose Camera, which creates a Display Client that allows the use of IP cameras.
Change Group	Launches the Select Display Client dialog box, which allows you to add this Display Client to a Display Client Group.
Permissions	Launches the Permissions dialog box, which allows Relevance permissions to be set.

The wizard starts like the Remote Desktop Services Display Client Wizard but changes at the Overlay Layout page.

Figure 195 - Overlay Layout Page



4. Complete the required settings.

Camera feeds are laid out on the Overlay Layout page of the Display Client Wizard.

Setting	Description
Choose Camera Overlay	Choose a setting from the pull-down menu to set the layout of the displays from a single overlay to multiple overlays on the Display Client. Choices include formats from a single camera to 16 camera displays.
Display Size	Sets the display resolution size.
Add Overlay	Launches the Custom Overlay dialog box, which allows you to define the name, size, and location of the camera display.
Remove Overlay	Removes a highlighted overlay from the Display Client.
Permissions	Launches the Permissions dialog box, which allows Relevance permissions to be set.
Reset Scale	Adjusts all Overlays to fit within the screen.
Snap	Check to align the edges of the overlays, side by side.

You can either use a camera overlay template or lay out a custom overlay.


Camera Overlay Template

The wizard provides a number of layouts.

1. Choose a camera grid from the Choose Camera Layout pull-down menu.




Figure 196 - 2x1 and 3x3 Grid Templates



- 2. Once a template is selected, click Next.

The Overlay Cameras page appears, where the wizard lets you add a camera per grid.

Figure 197 - Overlay Cameras Page



- 3. Complete the required fields on the Overlay Camera page for each overlay.

Setting	Description
Overlay Name	Automatically generated, but can be changed as needed.
<b>Position/Size</b>	
Left	Sets the left edge location of the overlay (in pixels).
Top	Sets the top edge location of the overlay (in pixels).
Width	Sets the overlay width (in pixels).
Height	Sets the overlay height (in pixels).




Setting	Description
<b>Cameras to Show</b>	
All Cameras Available	Makes all cameras available. Clear the checkbox to add specific cameras via Add.
Add	Use to add a camera to the overlay.
Delete	Deletes a camera from the overlay.
Set Initial Camera	Sets the initial camera from a series of cameras.
Overlay Options	Launches the Overlay Options dialog box.

The gray-shaded area represents the overlay to which you are assigning cameras. By default, All Cameras Available is checked, which makes all cameras available in that overlay.


- Click Set Initial Camera.

The Select Initial Camera dialog box appears with a list of cameras from which to select.

**Figure 198 - Select Initial Camera Window**




- Choose the camera to be displayed first, and click OK.

**Figure 199 - Overlay Cameras Page**


6. To limit the overlay to a smaller set of cameras, clear the All Cameras Available checkbox and click Add.

The Select Camera or Group dialog box appears.

**Figure 200 - Select Camera or Group**

7. Choose a camera and click OK.
8. Repeat until all the desired cameras are chosen.

Figure 201 - Selected List of Cameras




If multiple cameras are chosen, the top-listed camera appears first.

*Overlay Options*

1. Once the cameras for the overlay are added, click Overlay Options.

The Overlay Options dialog box appears.

Figure 202 - Overlay Options



2. Choose the Overlay Options for the camera display, and click OK.


Option	Description
<b>General Options</b>	
Enable Overlay	Makes the overlay visible at startup. Clear this setting to start the display client with the camera in a disabled, nonvisible state. The TermMon ActiveX Control can be used by an application to enable the overlay.
Interactive	Allows user on the terminal to interact with the overlay. If the user clicks in the overlay area, they can perform functions such as switching cameras and making the overlay full screen.
Scale	Scales camera frames to the size of the overlay window. Aspect ratio is maintained.
Crop	Crops the camera frame if it is larger than the camera overlay. When combined with the Scale option, the overlay area is entirely filled.
Show Complete Camera Name	Allows the entire path of the camera to be displayed. The path includes any groups of which the camera is a member.
Border Size	Determines the size of the overlay outside border.
<b>Title Options</b>	
Title Position	Position of the camera name within the overlay.
Title Size	Size of the camera name when displayed within the overlay. Choose Don't Show Title to display no camera name.
<b>Cycling Options<sup>(1)</sup></b>	
Enable Cycling	Cycles between the cameras assigned to the overlay.
Cycle Time	Time (in seconds) that the overlay displays each camera before switching to the next camera.

(1) Cycling Options are not available when All Cameras Available is checked on the Overlay Cameras page of the Display Client Wizard.

3. On the overlay Cameras page, click Finish.

Once a Terminal has a Camera Display Client added and is rebooted, the camera images become visible.

**Figure 203 - Shadow of a Terminal with a Camera Display Client**



When the Camera Display Client is selected, the Terminal makes a connection to the camera and requests the feed using the administrative account entered when the camera was defined as a display server. This connection is active only if the camera display client is active. If you switch to another display client, then the Terminal drops the connection to the camera.

The overlays and cameras are shown with green lightning bolts when active and red lightning bolts when inactive.

### Custom Overlays


You can create custom overlays instead of using the templates.

To create a new Camera Display Client, follow these steps.

1. Right-click on the Camera branch of the Display Client tree and choose Add Display Client.

The Add Overlay dialog box appears.


**Figure 204 - Add Overlay**



2. Click Add Overlay.

The Custom Overlay dialog box appears.


**Figure 205 - Custom Overlay**



The Custom Overlay dialog box defines the boundaries of the overlay.

- 3. Type the position of the overlay, in pixels, into the Left and Top fields.
- 4. Define the size of the overlay, in pixels, in the Width and Height fields.
- 5. Click OK.


**Figure 206 - Overlay Layout Page of the Camera Display Client Wizard**




Once the Custom Overlay dialog box is closed, the Overlay Layout page shows the boundaries of the custom overlay.

- 6. Click Add Overlay to add another overlay.


**Figure 207 - Second Overlay**



- 7. Repeat [step 6](#) as needed.


**Figure 208 - Overlay Cameras Page**

The Display Client Wizard continues to add a camera or cameras to the overlays as it did for the configured templates.

**Figure 209 - Multiple Custom Camera Overlays**

The wizard allows you to add cameras to each overlay in turn. The Overlay Cameras page also allows you to edit the Left and Top positions and the Height and Width.

8. Click Finish when done.

**Figure 210 - Two Custom Overlays in One Display Client**

Once the Camera Display Client is assigned to a Terminal and the Terminal is restarted, the display client with the custom overlays is shown on the Terminal.

### *Adding a Camera to an Existing Application*

Camera overlays are added to an application using the Remote Desktop Services Display Client Wizard. An overlay covers the screen of that display client in the area you define. You can hide and reveal the overlay with the TermMon ActiveX from ThinManager. See [Cameras and the TermMon ActiveX on page 170](#).

To add a camera to an existing application, follow these steps.

1. Double-click on a Remote Desktop Services Display Client to open the Remote Desktop Services Display Client Wizard and click Next to navigate to the Display Client Options page.



**Figure 211 - Display Client Options Page**

2. Check Include Camera Overlays, which adds an Overlay Layout page to the end of the wizard.
3. Click Next to navigate to the Overlay Layout page of the wizard.
4. Click Add Overlay.

The Custom Overlay dialog box appears.


**Figure 212 - Overlay Layout Page of the Display Client Wizard**

5. Enter the position of the overlay, in pixels, using the Left and Top fields.
6. Define the size of the overlay, in pixels, in the Width and Height fields

7. Click OK.

The Overlay Layout page shows the boundaries of the custom overlay.


**Figure 213 - Overlay Layout Page**



8. Click Next to continue the wizard.


The Overlay Cameras page appears.

**Figure 214 - Overlay Cameras Page**




9. Specify the cameras—check All Cameras Available or click Add to launch the Select Camera or Group dialog box to select a camera for the overlay.

**Figure 215 - Select Camera or Group**



- a. Highlight the desired camera and click OK.
- b. Repeat as needed.


**Figure 216 - Overlay Cameras Page**



10. When the cameras are chosen and the options configured, click Finish to close the wizard.

The camera is displayed in the display client when it is added to a Terminal configuration and the Terminal is restarted.

Figure 217 - Embedded Camera in Application



*Cameras and the TermMon ActiveX*

Camera overlays added to an application cover the screen of that display client in the area you defined via the Overlay Cameras page. You can hide and reveal the overlay with the TermMon ActiveX from ThinManager.

The TermMon ActiveX Control file (termmon.ocx) is on the ThinManager CD. It is also available in the Download section at <http://downloads.thinmanager.com/>.

The Control must be registered before it can be used. Copy the termmon.ocx file to the computer where you want to use it. Register the file by executing

```
regsvr32 <path\termmon.ocx>
```

Once registered, it can be added to the application and used to control the camera overlays.

**Available Commands for Use with Cameras**

Commands	Description
CameraOverlayEnable	Used to enable a camera overlay. This method requires two parameters: the first parameter is the name of the Display Client the overlay is on, and the second parameter is the name of the overlay.
CameraOverlayDisable	Used to disable a camera overlay. This method requires two parameters: the first parameter is the name of the Display Client the overlay is on, and the second parameter is the name of the overlay.
CameraOverlayCycleStart	Used to start camera cycling for a camera overlay. This method requires two parameters: the first parameter is the name of the Display Client the overlay is on, and the second parameter is the name of the overlay.
CameraOverlayCycleStop	Used to stop camera cycling for a camera overlay. This method requires two parameters: the first parameter is the name of the Display Client the overlay is on, and the second parameter is the name of the overlay.
CameraOverlaySwitchNext	Used to switch to the next camera in a camera overlay list. This method requires two parameters: the first parameter is the name of the Display Client the overlay is on, and the second parameter is the name of the overlay.

**Available Commands for Use with Cameras**

Commands	Description
CameraOverlaySwitchPrev	Used to switch to the previous camera in a camera overlay list. This method requires two parameters: the first parameter is the name of the Display Client the overlay is on, and the second parameter is the name of the overlay.
CameraOverlayFullscreenEnter	Used to make the current camera in a camera overlay enter full screen. This method requires two parameters: the first parameter is the name of the Display Client the overlay is on, and the second parameter is the name of the overlay.
CameraOverlayFullscreenExit	Used to make the current camera in a camera overlay exit full screen. This method requires two parameters: the first parameter is the name of the Display Client the overlay is on, and the second parameter is the name of the overlay.
CameraOverlaySwitchByName	Used to change cameras in a camera overlay. This method requires three parameters: the first parameter is the name of the Display Client the overlay is on; the second parameter is the name of the overlay; and the third parameter is the name of the camera. The camera name must include the full path if the camera is in a camera group.
CameraOverlayMove	used to change the position of a camera overlay. This method requires four parameters; the first parameter is the name of the Display Client the overlay is on; the second parameter is the name of the overlay; the third parameter is the x location; and the fourth parameter is the y position.
CameraOverlayResize	Used to change the size of a camera overlay. This method requires four parameters: the first parameter is the name of the Display Client the overlay is on; the second parameter is the name of the overlay; the third parameter is the width; and the fourth parameter is the height.
CameraOverlayResizeMove	Used to change the size and position of a camera overlay. This method requires six parameters: the first parameter is the name of the Display Client the overlay is on; the second parameter is the name of the overlay; the third parameter is the x position; the fourth parameter is the y position; the fifth parameter is the width; and the sixth parameter is the height.

## Terminal Shadow

The Terminal Shadow display client allows one ThinManager thin client to shadow another. You can shadow one specific thin client or have a menu of Terminals to shadow at will.


Terminal Shadow is valuable because it allows a user to shadow another Terminal without needing to launch ThinManager to use the ThinManager shadow function.

The ThinManager Terminal Shadow sends the screen display from the shadowed Terminal to the other Terminal. It does not redirect the display from the Remote Desktop Server, but sends the images from the actual shadowed Terminal.

The Terminal Shadow feature is set up and configured as a Terminal Shadow Display Client.

## Shadow Any Terminal

The Terminal Shadow display client can be created with a list of Terminals that can be shadowed. This is a great troubleshooting tool because a station can be given a chance to view other Terminals to monitor problems or to analyze problems without the need to travel to the specific problem area.

**Figure 218 - Display Client Tree of ThinManager**

1. To launch the Display Client Wizard, right-click on the Terminal Shadow branch of the Display Clients tree and select Add Display Client.

The Client Name page appears.

**Figure 219 - Client Name Page of the Terminal Shadow Display Client Wizard**

 The screenshot shows the 'Display Client Wizard' window, specifically the 'Client Name' page. The title bar says 'Display Client Wizard'. Below the title, it says 'Client Name' and 'Enter the Display Client name.' There are three main sections:
 


- Display Client Name:** A text box labeled 'Client Name' containing 'Shadow\_Any'.
- Set a Display Name:** A checkbox labeled 'Set a Display Name' is checked. Below it is a text box labeled 'Display Name' containing 'Shadow'.
- Type of Display Client:** A dropdown menu showing 'Terminal Shadow'.
- Display Client Group:** An empty text box with a 'Change Group' button to its right.

 At the bottom, there are navigation buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

2. Enter a name for the Terminal Shadow display client.
3. (Optional) Click Set a Display Name to configure the display client to display an alternative name in the ThinManager Server tree.
4. Click Next.

The Display Client Options page appears.

Figure 220 - Display Client Options Page




5. Check the following options as needed.

Setting	Description
<b>Client Options</b>	
Allow Display Client to be tiled	Allows the display client to be tiled.
Allow Display Client to be moved	Allows a Display Client to be moved from screen to screen. A movable display client can be anchored with a setting on the Screen Options page of the Terminal Configuration Wizard.
Include Camera Overlays	Allows an IP camera overlays to be added to this display client.
Include Virtual Screen Overlays	Allows a virtual screen overlay to be added like a camera overlay.
<b>Connection Options</b>	
Always maintain a connection	Keeps a session active, reconnecting and restarting if it is closed. Clear the checkbox to allow the user to close a session without an automatic start of another session.
Connect at boot-up	Starts a session for the Display Client at boot up. Clear the checkbox so a user action is required to start the session.
Disconnect in the background	In a MultiSession configuration, disconnects once it is moved into the background. Use to require fewer resources.

6. Click Next.

The Terminal Shadow Display Client appears.

**Figure 221 - Terminal Shadow Display Client Page**

The Terminal Shadow Display Client page of the Terminal Shadow Display Client wizard is unique.

7. (Optional) Check All Terminals Available to add all of the Terminals to the Shadow menu.
8. (Optional) Clear the All Terminals Available checkbox and click Add to launch the Select Terminal or Group dialog box to select specific Terminals. See [Shadow a Specific Terminal](#).

## Shadow a Specific Terminal

You can use the Terminal Shadow Display Client to shadow a specific Terminal, duplicating the display to another thin client. This can be helpful to provide a worker access to the HMI in various places in a large station, like a commercial oven at a baking line.

To shadow a specific terminal, follow these steps.

1. Right-click on the Terminal Shadow branch of the Display Clients tree and choose Add Display Client.

The Client Name page appears.




**Figure 222 - Client Name Page**

2. Enter a name for the display client in the Client Name field.
3. Click Next.

The Display Client Options page appears.

**Figure 223 - Display Client Options Page**


The Terminal Shadow Display Client page appears.

**Figure 224 - Terminal Shadow Display Client Page**

The Terminal Shadow Display Client page of the Terminal Shadow Display Client wizard is unique.


4. Clear the All Terminals Available checkbox and click Add.

The Select Terminal or Group dialog box appears.

**Figure 225 - Select Terminal or Group Window**

5. Highlight a single group or a Terminal to add to the Shadow menu and click OK. For a Terminal, repeat as needed to select all the Terminals you want.


The selected Group or Terminals are displayed in the Terminal to Shadow frame.

**Figure 226 - Terminal Shadow Display Client Page**

6. Check Interactive Shadow to allow the shadowing user to interact with the shadowed Terminal. Clear the Interactive Shadow checkbox to allow the shadow user read-only access.
7. Choose which screen of a MultiMonitor thin client to shadow from the Screen to Shadow pull-down menu.
8. Click Finish.

## Shadow of the Terminal


The Terminal Shadow display clients are added to the Terminal like other display clients.

**Figure 227 - Display Client Selection Page of the Terminal Configuration Wizard**

The Terminal Shadow display clients have an icon of a Terminal and a monitor session.

1. Move the desired Terminal Shadow display clients to the Selected Display Clients list. Double-click on them or use the arrows to move a highlighted display client.
2. Click Finish to save the configuration and restart the Terminal to send the configuration to the Terminal.

The Select Terminal to Shadow dialog box appears when there are Terminal Shadow Display Clients with multiple Terminals.

**Figure 228 - Shadow Menu**

3. Highlight the Terminal you want to shadow and click OK.

You are connected to the Terminal and display the screen from the shadowed thin client.

### Display Client Group Selector During Shadow

The Terminal Shadow display client is displayed in the Group Selector Menu of the Terminal to which it is assigned. The group selector shows the local display clients assigned to the Terminal.


When the local Group Selector menu is shown, the Group Selector of the remote Terminal is hidden.

**Figure 229 - Local Terminal Menu Selector**




To use the remote Terminal's Group Selector, choose Hide on the Local Group Selector, which hides the local selector and shows the Remote Group Selector.

**Figure 230 - Remote Terminal Menu Selector**



Once the Remote Group Selector menu is used, the local Terminal reverts to the Local Group Selector.

**Figure 231 - ThinManager Interface Showing Group Selector Menus**



[Figure 231 on page 179](#) shows the Group Selector menus for both the Local and the Remote Group Selectors.

## Workstation Deployment

Microsoft built Remote Desktop Protocol, RDP, into their workstation operating systems so that a permitted user can make a connection to a workstation and transfer the desktop session to another computer. RDP allows ThinManager to capture a session on a Windows XP Pro, Vista Pro, Windows 7, or Windows 10 computer and transfer it to a thin client. This ability is very helpful as it allows applications that are not RDS-compliant to be run on a workstation, but the user can receive the session on a hardened industrial thin client instead of a PC.

To transfer a workstation session to a thin client, the following are required.

- Turn on the Remote transfer on the PC
- Create a Workstation Display Client
- Apply the Workstation Display Client to a Terminal


The workstation can be a physical computer or a virtual desktop.

### Step 1 - On the PC

To enable the Remote Desktop function on the workstation, follow these instructions. This example uses Windows XP. Consult Microsoft instructions for more detail.

1. Go to the workstation Control Panel and open the System Properties, or right-click My Computer and choose Properties.
2. Click the Remote tab.


**Figure 232 - System Properties for XP Workstation**



3. In the Remote Desktop section, check Allow users to connect remotely to this computer.
4. Click Select Remote Users.

The Remote Desktop Users dialog box appears, which shows the users authorized to connect to the computer to transfer the session.


**Figure 233 - Remote Desktop Users Window**



5. Click Add.

The Select Users dialog box appears, from which you can authorize users.

**Figure 234 - Select Users Window**




6. Enter the desired users to the text box.
7. Click Check Names to validate the users you entered.
8. Click OK to add the users.
9. Close all the windows to finish the tasks.

## Step 2 – Workstation Display Client

Create a Workstation Display Client to act as a template for workstation deployment. The Workstation Display Client gets assigned to a specific workstation when it is applied to a terminal.

1. Open ThinManager to the Display Clients tree.

**Figure 235 – Access the Workstation Display Client Wizard**



2. Right-click on the Workstation branch of the Display Clients tree of ThinManager and choose Add Display Client.

The Client Name page of the Workstation Display Client Wizard appears.



**Figure 236 - Client Name Page**

Display Client Wizard

**Client Name**  
Enter the Display Client name.

Display Client Name  
Client Name Legacy\_HMI

☒ Set a Display Name  
Display Name HMI

Type of Display Client  
Workstation


Display Client Group  
Change Group

< Back Next > Finish Cancel Help

The Client Name Page of the Workstation Display Client wizard is similar to other Display Client Option pages.


3. Enter a unique name and select the Next button.
4. (Optional) Check Set a Display Name to show an alternative name in the ThinManager Server tree.
5. Click Next.

The Display Client Options page of the Workstation Display Client Wizard appears, which is similar to other Display Client Options pages except for the Start Virtual Machine if necessary checkbox.

**Figure 237 - Display Client Options Page**

6. (Recommended) Check Start Virtual Machine if necessary.
7. Click Next.

The Remote Desktop Services and Workstations Options page of the Workstation Display Client appears, which is similar to other display clients wizards.


**Figure 238 - Remote Desktop Services and Workstation Options Page**

8. Leave the Application Link checkbox cleared in order to deploy the workstation as a desktop.

- Click Finish to close the wizard.

The completed display clients are displayed in the Workstation branch of the Display Clients tree.


**Figure 239 - Workstations in the Display Client Tree**



## Add the Workstation Display Client to the Terminal

- Double-click on the Terminal in the Terminal branch of the ThinManager tree to open the Terminal Configuration Wizard.
- Click Next until the Display Client Selection page appears.

**Figure 240 - Display Client Selection Page**



3. Highlight the workstation to be added and click the right-facing arrow to add it to the Selected Display Clients list.
  - a. If the workstation uses a different Windows account than the Terminal, highlight the workstation in the Selected Display Clients list, and then click Override to change the Windows account that is used for logging in.

The Override Settings dialog box appears.

**Figure 241 - Override Settings**

Override Settings for 'Legacy\_HMI' Display Client

Display Name:  Override: ☒

Windows Login Settings: Username:  Password:  Verify Password:  Domain:  Search:  Override: ☒

AppLink Command Line: Command Line Options:  Override: ☐

Video Settings: Resolution:  Color Depth:  Override: ☒


OK Cancel

- b. Check Override in the Windows Login Settings section and enter the workstation's correct user account credentials to the Username and Password fields. Enter the credentials manually or click Search.

The Search for AD User dialog box appears. Search pulls a user account from the Active Directory as shown on [page 65](#).


- c. Check Override in the Video Settings section to choose Resolution and Color Depth from the pull-down menus.
  - d. Click OK to return to the Display Client Selection page.

Display Clients with an override display a yellow plus sign on their icon.

**Figure 242 - Override Indicator**

4. Click Next.


The Workstation Display Client shows a new page—the Complete the Workstation Display Client Configuration Page appears, where you add the workstation you want to transfer to the Terminal. There are two options, using a physical workstation or a VCenter virtual workstation.

**Figure 243 - Complete the Workstation Display Client Configuration Page**

5. Click Add Workstation to add a physical workstation.

The Add Workstation dialog box appears, which allows you to specify a workstation by IP address and name.

**Figure 244 - Add Workstation**




6. Complete the Workstation IP Address and Workstation Display Name fields.

You may also use this dialog box to point to a virtual workstation. Complete the fields with the virtual machine's IP address and name.

7. Click Add.
8. (Optional) If your virtual machines are on a vCenter Server that is defined in ThinManager, click Add Virtual Workstation button on the Complete the Workstation Display Client Configuration page.

The Add Virtual Workstation dialog box appears, which is populated by any VCenter Servers you have defined in ThinManager.


**Figure 245 - Add Virtual Machine**



- a. Choose the vCenter Server from the Select vCenter Server pull-down menu.
- b. From the Available Virtual Workstations pane, expand the VCenter tree.
- c. Highlight the desired virtual workstation and click Add.

The workstation appears in the Selected Workstations pane on the Complete the Workstation Display Client Configuration page.

**Figure 246 - Complete the Workstation Display Client Configuration Page**




d. (Optional) Add a second workstation as a backup, if desired.

Workstations can have only one connection to a remote user as they use a one-to-one model instead of the one-to-many model of Remote Desktop Services.


ThinManager has an error check system that prevents a workstation from being deployed twice. A dialog box appears if a duplicate workstation is added.

**Figure 247 - Duplicate Workstation Warning**



A workstation can be added multiple times as a backup but only once as the primary workstation.

Once the Workstation Display Client is added to a Terminal and the Terminal is restarted, the Terminal connects to the workstation and transfers the workstation display to the Terminal.

**Figure 248 - XP Workstation on a Thin Client**

## VNC Shadow

ThinManager can connect to a VNC Server and send the VNC shadow to a Terminal as a VNC Display Client.


In order to do so, follow these steps.

1. Define the VNC Server as a Display Server source as shown in [VNC Servers on page 112](#).
2. Create a Display Client to deploy the source on a client.

## Shadow Any VNC Server

A VNC Display Client can be created that allows the user to select from a list of all the VNC Servers.



**Figure 249 - Display Clients Tree**

To shadow any VNC server, follow these steps.


1. Right-click on the VNC branch of the Display Clients tree and choose Add.

The Display Client Wizard appears.

**Figure 250 - VNC Display Client**

2. Enter a Client Name and follow the wizard like other display clients.
3. (Optional) Click Set a Display Name to configure the display client to display an alternative name in the ThinManager Server tree.

- Click Next until the VNC Display Client page appears.




- Click All VNC Servers Available to make all VNC servers available to shadow.
- (Optional) Clear the Interactive Shadow checkbox to turn it off.
- Click Finish to create the display client.

Once the VNC Display Client is added to a Terminal and the Terminal is restarted, the VNC Display Client is available.

When you choose a VNC display client with multiple VNC servers, a menu that lists all available VNC servers appears.

**Figure 251 - VNC Server Menu**



- Highlight the desired VNC server and click OK.

The VNC server you chose is shadowed.

## Shadow a Specific VNC Server

The VNC Display Client can be configured to show the output from a specific VNC server.

To configure a VNC Display Client to shadow a specific VNC server, complete these steps.

1. Right-click on the VNC branch of the Display Clients tree and choose Add Display Client.

The Display Client Wizard for Terminal Shadow appears.

**Figure 252 - VNC Display Client Wizard**

Display Client Wizard

**Client Name**  
Enter the Display Client name.

Display Client Name  
Client Name   
☐ Set a Display Name


Type of Display Client

Display Client Group  
  
Change Group

< Back Next > Finish Cancel Help

2. Complete the Client Name field.
3. (Optional) Click Set a Display Name to configure the display client to display an alternative name in the ThinManager Server tree.
4. (Optional) Click Change Group to put the display client into a group.
5. Click Next to follow the wizard like other display clients.


**Figure 253 - VNC Display Client Page**



- 6. Clear the All VNC Servers Available checkbox.
- 7. Click Add.


The Select VNC Server or Group dialog box appears.

**Figure 254 - Select VNC Server of Group**



- 8. Highlight the VNC server you want to shadow and click OK.

The chosen VNC server is added to the list to shadow on the VNC Display Client page.

**Figure 255 - Chosen Server Added to VNC Display Client Page**

9. (Optional) Click Add to repeat the process and add other VNC servers.
10. Click Finish to create the display client when done.
11. Clear the Interactive Shadow checkbox to turn it off. This puts the shadow in a read-only mode.

Once the VNC Display Client is added to a Terminal and the Terminal is restarted, the VNC Display Client is available.

If you have a single VNC server listed, the display client automatically shows you that shadow. If you add multiple VNC servers to the list, the VNC display client presents the menu with all the listed servers in it.

## Virtual Screens

This is a feature that allows you to divide a screen into separate overlays. It allows you to deliver MultiMonitor functionality to a single physical monitor.

The method of creating the Virtual Screen overlays follows the methods of the Camera Display Clients.


### Virtual Screen Display Client Wizard

Virtual Screens are defined using the Display Client Configuration Wizard.

To define Virtual Screens, follow these steps.

1. Click the Display Clients icon at the bottom of the ThinManager tree.


Figure 256 - Launch the Virtual Screen Wizard



2. Right-click on the Virtual Screen branch, and choose Add Display Client.


The Client Name page of the Display Client Wizard appears.

The wizard starts like the Remote Desktop Services Display Client Wizard, but changes at the Select or Create the Virtual Screen Layout page.

**Figure 257 - Client Name Page of the Display Client Configuration Wizard**

The screenshot shows the 'Display Client Wizard' window with the 'Client Name' tab selected. The title bar reads 'Display Client Wizard'. The main heading is 'Client Name' with the instruction 'Enter the Display Client name.' Below this, there is a text field labeled 'Display Client Name' containing 'QuadScreen01'. A checkbox labeled 'Set a Display Name' is unchecked. Below the text field is a dropdown menu labeled 'Type of Display Client' with 'Virtual Screen' selected. At the bottom of the main area is a text field labeled 'Display Client Group' and a 'Change Group' button. The bottom of the window has navigation buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

3. Complete the Client Name field to name your display client.
4. Click Next to continue through the wizard until the Select or Create the Virtual Screen Layout page appears.

**Figure 258 - Select or Create the Virtual Screen Layout Page**

The screenshot shows the 'Display Client Wizard' window with the 'Select or Create the Virtual Screen Layout' tab selected. The title bar reads 'Display Client Wizard'. The main heading is 'Select or Create the Virtual Screen Layout' with the instruction 'Select a pre-configured virtual screen layout or create a custom layout'. Below this, there is a dropdown menu labeled 'Choose Layout' with 'Custom' selected. Below the dropdown is a dropdown menu labeled 'Display Size' with '1024x768' selected. In the center is a large blue square representing the virtual screen. To the right of the square are three buttons: 'Add', 'Remove', and 'Set Order'. The bottom of the window has navigation buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.


5. Complete the page per the following descriptions.

Setting	Description
Choose Layout	Use the pull-down menu to choose from templates or Custom, which requires the addition of at least one overlay via Add. See <a href="#">Predefined Templates on page 198</a> and <a href="#">Custom Overlays on page 206</a> for more information.
Screen Resolution	Use the pull-down menu to choose the of the Virtual Screen display client.
Add	Launches the Custom Overlay dialog box, which allows customer overlays to be defined.
Remove	Removes a highlighted overlay.
Set Order	Launches the Set Stacking Order of Virtual Screens dialog box, which allows the screens to be prioritized.

## Predefined Templates

The Choose Layout drop-down has a number of templates that allow you to add anywhere from one to sixteen virtual screens.


**Figure 259 - Select or Create the Virtual Screen Layout Page**



1. Choose a template from the Choose Layout pull-down menu.
2. Choose a display resolution from the Screen Resolution pull-down menu.
3. Click Next.

The Virtual Screen Configuration page appears.




**Figure 260 - Virtual Screen Configuration Page**

The wizard allows display clients to be added to each overlay.

4. Click Add to add a Display Client to the overlay.


The Select Display Client dialog box appears, which lists all display clients.

**Figure 261 - Select Display Client Dialog**

5. Highlight the desired Display Client and click OK.
6. Repeat as needed for the overlay.

The Display Client appears in the Selected Display Clients field. Each overlay may have one or more display clients in the overlay.


**Figure 262 - Virtual Screen Configuration Showing Applied Display Client**



- 7. Click Add to add more display clients.
- 8. (Optional) Highlight a display client and click Screen Options to apply virtual screen options.

The Virtual Screen Options dialog box appears.

**Figure 263 - Virtual Screen Options**




## 9. Choose the Virtual Screen Options per the following descriptions.

Option	Description
Allow Display Clients to move to/from screen	Allows movement of a display client from one overlay to the other, much like the movement of display clients between monitors on a MultiMonitor thin client.
Show Display Client Selector	Shows the pull-down selector at the top of the overlay. Click Selector Options to configure.
Selector Options	Use to configure selector options.
Enable Tiling	Allows tiling of Display Clients within the overlay if you have multiple display clients.
Tiling Options	Use to configure tiling options.
Virtual Screen Specific Mouse Button Mapping	Enables Mouse Button Mapping to configure the mouse with use with the Virtual Screens.
Mouse Button Mapping	Use to define mouse buttons as hotkeys.
<b>Virtual Screen Display Options</b>	
Show Virtual Screen Border	Shows a border between the overlays.
Virtual Screen Always Visible	If the user switches to a different display client, this overlay remains visible even though its display client is hidden.
Hide Virtual Screen at Startup	Hides the Virtual Screen at startup. It is intended to be used with the TermMon ActiveX, which toggles the overlay visibility.
Virtual Screen is view only	Displays the Display Client in the Virtual Screen, but makes it view-only and not interactive.
Allow Full-screen	Allows a Display Client to appear full screen and not show the sidebar.
Show Messages	Allows for control of the status message shown in the upper-left corner of the Terminal display.
Use Terminal Setting	Sets the Virtual Screen to follow the configuration of the Terminal.
Yes	Turns on the status messages.
No	Turns off the status messages.
<b>Swap Options</b>	
Swap Destination	Allows the location of the Virtual Screen, moved during a swap, to be specified.
Swap on empty Virtual Screen	Move the highlighted Virtual Screen to an empty Virtual Screen when selected from the pull-down Selector.
Show "Swap" in Selector Menu	Adds the Swap option to the pull-down Selector menu.
Enable Single-swap mode	Allows a single mouse click in a Virtual Screen window to initiate the swap.

## 10. Click Selector Options to configure the selector options.

The Display Client Selector Options dialog box appears.

Figure 264 - Display Client Selection Options




Choose from the following Display Client Selector options.

Option	Description
Auto-hide Selector	Hides the pull-down menu Display Client selector unless the mouse is positioned over it. Clear this checkbox to show the selector at the top-center of the screen.
Tile on Selector activation	Adds the tiling command to the pull-down menu when Auto-hide Selector is checked.
Selector Menu Size	Use this pull-down menu to set the font size of the text in the Display Client selector.

- 11. Click OK to close the Display Client Selector Options dialog box.
- 12. Click Virtual Screen Specific Mouse Button Mapping to activate the Mouse Button Mapping button.
  - a. Click Mouse Button Mapping.

The Mouse Button Mapping dialog box appears.

Figure 265 - Mouse Button Mapping Dialog Box




13. Complete the Mouse Button Mapping dialog box per the following settings. Each mouse button can be configured with a different function. Use Button 1 (Left Mouse) for touch screens without a mouse.

Setting	Description
Default	Leaves the button with its original action.
Calibrate Touch Screen	Initiates the touch screen calibration program.
Tile	Initiates the tiling of display clients.
Swap	Exchanges display clients in Virtual Screens.
Full Screen	Expands an overlay to Full Screen.
Go to next display client	Navigates to the next display client in the list.

14. Click Next to continue to the next overlay once all the dialog windows are closed.

The Display Client Wizard navigates from overlay to overlay, which allows you to add display clients to each one.

**Figure 266 - Virtual Screen Configuration Page**



15. Click Finish when the configuration is done.


## Add a Virtual Screen to a Terminal

Virtual Screen Display Clients are added to a Terminal as any other Display Client.

1. Double-click on the Terminal in the Terminal tree.


The Terminal Configuration Wizard appears.

2. Click Next until the Display Client Selection page appears.

**Figure 267 - Display Client Selection Page of the Terminal Configuration Wizard**

3. Double-click or highlight the Virtual Screen Display Client in the list of Available Display Clients and click the right-facing arrow to move it to the Selected Display Clients pane.


Once the Virtual Screen Display Client is in the Selected Display Clients list it is added to the Terminal.

**Figure 268 - Selected Display Clients**

- Click Finish and restart the Terminal to apply the change.

[Figure 269](#) shows the QuadScreen01 Virtual Screen Display Client on a Terminal.


**Figure 269 - Virtual Screen on the Terminal**



The screen has four virtual screens added and showing.

If Enable Tiling is checked on the Virtual Screen Options dialog box, [Figure 285 on page 214](#), then the display clients in an overlay are tiled as shown here.

**Figure 270 - Tiling within an Overlay**



## Custom Overlays


ThinManager provides the option of building and defining custom overlays instead of using the predefined templates. This section shows an example of a custom Virtual Screen display client with four custom overlays.

Define Virtual Screens with the Display Client Configuration Wizard.

1. Click the Display Clients icon at the bottom of the ThinManager tree.
2. Right-click on the Virtual Screen branch and choose Add Display Client.

The Client Name page of the Display Client Wizard appears.


**Figure 271 - Display Client Wizard for Virtual Screens**



3. Complete the Client Name field to name your display client.
4. Click Next until the Select or Create the Virtual Screen Layout page appears.



Figure 272 - Custom Overlay Layout




The initial Virtual Screen is a blank canvas and needs at least one overlay added.

- 5. Click Add.

The Custom Overlay dialog box appears.

Figure 273 - Custom Overlay Layout



Complete the Custom Overlay field settings per the following descriptions to set the size and location of the custom overlay.


Setting	Description
Overlay Name	Provides a name to the overlay.
<b>Position/Size</b>	
Left	Sets the position of the left edge of the overlay.
Top	Sets the position of the top edge of the overlay.
Width	Sets the width of the overlay.
Height	Sets the height of the overlay.

This example creates a 1440 x 1080 overlay that is touching the upper-left corner.

- 6. Click OK to accept the settings.

The created Overlay is shown in Overlay window when done.


Figure 274 - Created Overlay



- 7. Click Add.


The Custom Overlay dialog box appears again. The example in [Figure 275](#) uses an overlay that is 1440 pixels from the left edge and has a screen resolution of 480 x 360 pixels.

**Figure 275 - Custom Overlay #2**



8. Click OK to accept the settings.


**Figure 276 - Display of Created Overlay**



9. Click Add.

The Custom Overlay dialog box appears for the next overlay.


**Figure 277 - Custom Overlay #3**




This example uses an overlay that is 1440 pixels from the left edge, 360 pixels from the top, and has a screen resolution of 480 x 360 pixels.

- 10. Click OK to accept the settings and return to the Select or Create the Virtual Screen Layout page.

**Figure 278 - Display of Created Overlay**



- 11. Click Add to launch the Custom Overlay dialog box for the next overlay.


**Figure 279 - Custom Overlay #4**


The **Custom Overlay** dialog box is shown. It has a title bar with a close button (X). The main area contains the following fields and buttons:

- Overlay Name:** A text box containing "Side03".
- Buttons:** "OK" and "Cancel" buttons are located to the right of the Overlay Name field.
- Position / Size:** A section containing four input fields:
  - Left:** 1440
  - Top:** 720
  - Width:** 480
  - Height:** 360

[Figure 279](#) uses an overlay that is 1440 pixels from the left edge, 720 pixels from the top, and has a screen resolution of 480 x 360 pixels.

12. Click OK to accept the settings and return to the Select or Create the Virtual Screen Layout page.

**Figure 280 - Display of Created Overlay**


The **Display Client Wizard** dialog box is shown. It has a title bar with a close button (X). The main area contains the following fields and buttons:


- Select or Create the Virtual Screen Layout:** A section with the instruction "Select a pre-configured virtual screen layout or create a custom layout" and a blue icon of a person.
- Choose Layout:** A dropdown menu showing "Custom".
- Display Size:** A dropdown menu showing "1920x1080".
- Layout Preview:** A large blue rectangle representing the virtual screen layout.
- Buttons:** "Add", "Remove", and "Set Order" buttons are located to the right of the layout preview.
- Navigation Buttons:** "< Back", "Next >", "Finish", "Cancel", and "Help" buttons are located at the bottom.

[Figure 280](#) shows the completed layout of the overlays.

13. Click Set Order.

The Set Stacking Order of Virtual Screens dialog box appears. This is important when the overlays overlap.

**Figure 281 - Set Stacking Order of Virtual Screens**




14. Highlight the virtual screen and click Top, Up, Down, or Bottom per their respective descriptions to set the priority of stacked overlays.


Field/Buttons	Description
Virtual Screens	Lists the overlays added to the virtual screen.
Top	Moves a highlighted overlay to the top of the list.
Up	Moves a highlighted overlay higher on the list.
Down	Moves a highlighted overlay lower on the list.
Bottom	Moves a highlighted overlay to the bottom of the list.

15. Click OK to return to the Select or Create the Virtual Screen Layout page.  
16. Click Next.

The Virtual Screen Configuration page appears, where you add display clients to the overlays. Each custom overlay needs a display client.

**Figure 282 - Adding Display Clients to the Virtual Screens**


The wizard shows one overlay at a time. Display clients can be added as shown in [Predefined Templates on page 198](#).

**Figure 283 - Adding Display Clients to the Virtual Screens**

17. Click Add.

The Select Display Client dialog box appears, where you can select a display client from a list of all display clients.


Figure 284 - Select Display Client



- 18. Highlight the desired Display Client and click OK to return to the Virtual Screen Configuration page.
- 19. Click Screen Options.

The Virtual Screen Options dialog box appears.

Figure 285 - Virtual Screen Options






## 20. Choose the Virtual Screen Overlay options per the following descriptions.

Option	Description
Allow Display Clients to move to/from screen	Allows movement of a display client from one overlay to the other, much like the movement of display clients between monitors on a MultiMonitor thin client.
Show Display Client Selector	Shows the pull-down selector at the top of the overlay. Click Selector Options to configure.
Selector Options	Use to configure selector options.
Enable Tiling	Allows tiling of Display Clients within the overlay if you have multiple display clients.
Tiling Options	Use to configure tiling options.
Virtual Screen Specific Mouse Button Mapping	Enables Mouse Button Mapping to configure the mouse with use with the Virtual Screens.
Mouse Button Mapping	Use to define mouse buttons as hotkeys.
<b>Virtual Screen Display Options</b>	
Show Virtual Screen Border	Show a border between the overlays.
Virtual Screen Always Visible	If the user switches to a different display client, this overlay remains visible even though its display client is hidden.
Hide Virtual Screen at Startup	Hides the Virtual Screen at startup. It is intended to be used with the TermMon ActiveX, which toggles the overlay visibility.
Virtual Screen is view only	Displays the Display Client in the Virtual Screen, but makes it view-only and not interactive.
Allow Full-screen	Allows a Display Client to appear full screen and not show the sidebar.
Show Messages	Allows for control of the status message shown in the upper-left corner of the Terminal display.
Use Terminal Setting	Sets the Virtual Screen to follow the configuration of the Terminal.
Yes	Turns on the status messages.
No	Turns off the status messages.
<b>Swap Options</b>	
Swap Destination	Allows the location of the Virtual Screen, moved during a swap, to be specified.
Swap on empty Virtual Screen	Move the highlighted Virtual Screen to an empty Virtual Screen when selected from the pull-down Selector.
Show "Swap" in Selector Menu	Adds the Swap option to the pull-down Selector menu.
Enable Single-swap mode	Allows a single mouse click in a Virtual Screen window to initiate the swap.

## 21. Click Mouse Button Mapping.


The Mouse Button Mapping dialog box appears, where you configure actions for the mouse buttons through pull-down menus.

**Figure 286 - Mouse Button Mapping**



22. Click OK to return to the Virtual Screen Options dialog box.
23. Click OK on the Virtual Screen Options dialog box to return to the Virtual Screen Configuration page, which repeats for each overlay.

**Figure 287 - Each Overlay is Configurable**




24. Click Next to go to the next overlay. The wizard navigates to each overlay, which allows the selection of display clients and settings.
25. Click Finish button when done.

Once the Virtual Screen wizard is finished, the Virtual Screen can be added to a Terminal. The Terminal shows the Virtual Screens once it is restarted.


[Figure 288 on page 216](#) shows the main overlay with an HMI and the three smaller overlays along the side, each with their own display client. These overlays could have multiple display clients and be tiled, if desired.

**Figure 288 - Custom Overlay in Action**



## Display Client Override on Virtual Screens


Virtual Screens do not allow an override in the Terminal Configuration Wizard.

**Figure 289 - Display Client Selection Page Error**

Virtual Screens do not allow an override on the Display Client Selection page of the Terminal Configuration Wizard. It is done from the ThinManager tree instead.

1. Double-click on the Virtual Screen under the Terminal in the Terminal tree of ThinManager.

The Display Client Wizard appears.

**Figure 290 - Virtual Screen Configuration Page**

2. Click Next until the Virtual Screen Configuration page appears. The Terminal Override button is enabled.

3. In the Selected Display Clients pane, highlight the display client you want to alter and click Terminal Override.

The Override Settings dialog box for that display client appears, which allows normal display client overrides. See [Display Client Selection Page on page 232](#) for details.

**Figure 291 - Override Settings Page**


The screenshot shows a dialog box titled "Override Settings for 'Desk43' Display Client". It contains three main sections, each with an "Override" checkbox:

- Windows Login Settings:** Includes input fields for Username, Password, Verify Password, and Domain. There is also a "Search" button.
- AppLink Command Line:** Includes a text box for "Command Line Options".
- Video Settings:** Includes dropdown menus for "Resolution" (set to 240x320) and "Color Depth" (set to 256 Colors).

At the bottom right, there are "Cancel" and "OK" buttons.

4. Click Override in the sections to which the changes apply and click OK.

On Virtual Screen Configuration page, a yellow plus sign on the Display Client indicates that it has a changed setting.

**Figure 292 - Virtual Screen Configuration Page Showing Override**

5. Click Finish.

**Notes:**

## Devices

### Terminal Configuration

There are five types of Terminals that can be used in a ThinManager system.

- ThinManager-ready thin client
- ThinManager-compatible thin client
- aTMC for Android Devices
- iTMC client for iOS, iPads, and iPhones
- WinTMC client for Windows PCs and Surface tablets

Two steps are required to add a device. First, the device must be pointed to the ThinManager Server to receive a configuration. Second, a configuration must be created in ThinManager for the device to download.


In this section, we explain the configuration of the device in ThinManager, then show how to connect each hardware device to ThinManager.

### Terminal Configuration Wizard in ThinManager

To configure the device in ThinManager, follow these steps.

1. Click the Terminals icon at the bottom-left of ThinManager to display the Terminals tree.

**Figure 293 - Terminal Branch of the ThinManager Tree**




2. Right-click on the Terminals branch and choose Add Terminal.

The Terminal Configuration Wizard appears, opened at the Terminal Name page.

*Terminal Name Page*

The first page of the Terminal Configuration Wizard is the Terminal Name page.

**Figure 294 - Terminal Name Page**



1. Complete the Terminal Name page per the following descriptions.


Field/Button	Description
Terminal Name	Specifies the terminal name in ThinManager. Enter a name for the Terminal in 15 characters or less.
Description	Launches the Terminal Description dialog box, where you can add extra information about the Terminal.
Terminal Group	Adds the terminal to a group of terminals via Change Group.
Change Group	Launches tree from which to select group for terminal to join. See <a href="#">Use Groups for Organization on page 261</a> for details.
Copy Settings from another Terminal	Click to activate Copy From.
Copy From	Allows quick creation of terminal in that it launches the Select Terminal dialog box with a tree that allows you to apply a terminal configuration that already exists to the new terminal. See <a href="#">Copy Settings from another Terminal on page 259</a> for details.
Permissions	Applies Relevance permissions to the Terminal. See <a href="#">Permission-deployed Applications in ThinManager on page 323</a> for details.

a. (Optional) Click Description.

The Terminal Description dialog box appears.



**Figure 295 - Terminal Description Dialog Box**



b. Complete the Terminal Description dialog box per the descriptions that follow.

Field/Button	Description
Terminal Description	Allows an extensive description to be added to the Terminal when the Terminal names are industrialized, like "USP_MX10_L1_qty" or "Prod_TrayPkgShrkWrp_OIT".
Custom Variables	Allow a variable to be applied for advanced functionality.
Add	Opens the Custom Variable dialog box for adding a custom variable.
Delete	Deletes a highlighted custom variable.
Edit	Click to change the settings for the highlighted variable in the Custom Variable dialog box.


Custom variables allow a single display client to be created with a custom variable as part of the path. Each user, Terminal, or location has specific data in the custom variable to modify the content that the display client delivers, which allows one display client to do the work of many.

Additionally, a custom variable can pass specific data to an application through the TermMon ActiveX.

2. (Optional) Add a Custom Variable.
  - a. Click Add.

The Custom Variable dialog box appears.

**Figure 296 - Custom Variable Dialog Box**



b. Complete the Custom Variable dialog box per these steps.

Field/Button	Description
Name	Assigns the name to the custom variable.
Value	Assigns the value or content to the custom variable.
Hide Value	Obscures the text in the Value field. Clear the checkbox to display the value.
OK	Accepts the changes and closes the dialog box.
Cancel	Closes the dialog box without changes saved.

c. Click OK to close the Custom Variable dialog box.


- d. At the Terminal Description dialog box, click OK.
- e. At the Terminal Name page, click Next.

The Terminal Hardware page appears.

*Terminal Hardware Page*

The Terminal Hardware page allows you to specify the make and model of the Terminals you are adding.

**Figure 297 - Terminal Hardware Page of the Terminal Configuration Wizard**



- 1. Complete the Terminal Hardware page per the descriptions that follow.

Field/Button	Description
Make/OEM	Choose the make of the hardware from the pull-down menu.
Model	Choose the model of the hardware from the pull-down menu.
OEM Model	Displays the actual model as listed in the TermCap.
Video Chipset	Displays the video chipset used once the terminal connects to ThinManager as listed in the TermCap.
Terminal Firmware Package	Use the pull-down menu to change the firmware package that the terminal uses. Must be enabled in Package Manager (Manage>Packages).
Clear	Removes the Terminal ID identifier from the configuration of an active terminal. The MAC address of the terminal is used for the Terminal ID. Clearing the Terminal ID frees hardware that is already tied to a configuration and allows the terminal to be tied to a different configuration without deleting its original configuration. It also allows the make and model of the hardware to be changed.
Edit	Launches the Edit Terminal ID dialog box that allows for the manual change of the MAC address of the configuration. Allows for the replacement of an old terminal by entering the MAC address of the replacement. Entering the new MAC address allows the new terminal to boot and retrieve its configuration without selecting the terminal from the list. Once a MAC address is registered within ThinManager, you can assign a static IP address to it if the Terminal is PXE Booting and if the ThinManager PXE Server is set to Not Using Standard DHCP Server. See <a href="#">Figure 397 on page 293</a> .

Use the correct Make and Model if you can, which allows you to configure the Terminal to match the capabilities of the hardware used.



When a Terminal connects to its configuration for the first time, ThinManager adjusts the configuration to match the actual hardware used and not the preconfigured hardware selected to prevent errors. The default model, the ACP DC-40-100, is used because it has limited video resolutions that every modern Terminal can use. If a different model is assigned to this configuration, it may end up with the lower video resolutions.

ThinManager uses the MAC address to identify the Terminals. The Terminal ID field is automatically populated when hardware is associated with the configuration.


**Figure 298 - PXE Boot Configuration for ThinManager-compatible Thin Clients**

2. Configure the ThinManager-compatible thin clients as GENERIC/PXE as they use PXE boot to download their firmware.
3. Configure the PXE Server in ThinManager at Manage>PXE Server. See [PXE Server and PXE Boot on page 281](#) for information.
4. Click Next.

The Terminal Options page appears.

## Android Devices

ThinManager has an Android application that allows the Android to run an RDP session that is controlled and managed by ThinManager.

**Figure 299 - Hardware Configuration for Android Devices**

The screenshot shows the 'Terminal Configuration Wizard' dialog box. The title bar is blue with a close button (X) in the top right corner. The main window has a light gray background. At the top, there is a section titled 'Terminal Hardware' with a sub-instruction: 'Select the manufacturer and model of this terminal.' To the right of this text is a small blue icon of a person. Below this, a larger instruction reads: 'Use this to configure the type of hardware for this terminal.' The configuration area contains several fields: 'Make / OEM' is a dropdown menu set to 'GENERIC'; 'Model' is a dropdown menu set to 'Android Device'; 'OEM Model' is a text field containing 'Android'; 'Video Chipset' is a text field containing 'UNKNOWN'. Below these is 'Terminal Firmware Package' with a dropdown set to 'Model Default'. To the right of this dropdown, it says 'Terminal will run Package 7'. At the bottom of the configuration area is a section titled 'Terminal ID and IP Address' which contains a 'Terminal ID' field with the value 'None' and two buttons: 'Clear' and 'Edit'. The bottom of the dialog box features a row of five buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

**Terminal Configuration Wizard**

**Terminal Hardware**  
Select the manufacturer and model of this terminal.

Use this to configure the type of hardware for this terminal.

Make / OEM: GENERIC  
Model: Android Device  
OEM Model: Android  
Video Chipset: UNKNOWN

Terminal Firmware Package: Model Default  
Terminal will run Package 7


Terminal ID and IP Address  
Terminal ID: None  
Clear  
Edit

< Back    Next >    Finish    Cancel    Help

- Choose GENERIC/Android Device as the Make and Model of the client.

## Apple Devices

**Figure 300 - Hardware Configuration for Apple iPad**



The screenshot shows the 'Terminal Configuration Wizard' window. The title bar is blue with a close button. The main window has a light blue header with the text 'Terminal Hardware' and 'Select the manufacturer and model of this terminal.' Below this, a message says 'Use this to configure the type of hardware for this terminal.' The configuration fields are as follows:

Make / OEM	Apple
Model	iOS Device
OEM Model	iOS
Video Chipset	UNKNOWN


Below these fields is a 'Terminal Firmware Package' dropdown set to 'Model Default'. To the right, it says 'Terminal will run Package 7'. A section titled 'Terminal ID and IP Address' contains a 'Terminal ID' field with the value 'None' and two buttons: 'Clear' and 'Edit'. At the bottom are five buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

- For Apple devices, choose Apple/iOS Device as the Make and Model of the client.

## WinTMC Clients

ThinManager has a PC application that allows the PC to run an RDP session that is controlled and managed by ThinManager.

**Figure 301 - Hardware Configuration for WinTMC Clients**



The screenshot shows the 'Terminal Configuration Wizard' dialog box. The title bar is blue with a close button. The main window has a light blue header with the text 'Terminal Hardware' and a sub-instruction 'Select the manufacturer and model of this terminal.' Below this, a grey box contains the text 'Use this to configure the type of hardware for this terminal.' The configuration fields are as follows:

Field	Value
Make / OEM	GENERIC
Model	WinTMC
OEM Model	WinTMC
Video Chipset	UNKNOWN
Terminal Firmware Package	Model Default

Below the firmware package, it says 'Terminal will run Package 7'. There is a section for 'Terminal ID and IP Address' with a 'Clear' button. The 'Terminal ID' field is currently set to 'None' and has an 'Edit' button next to it. At the bottom of the dialog are five buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

- Choose GENERIC/WinTMC as the Make and Model of the client.

## Terminal Options Page

The Terminal Options page starts the configuration process.

**Figure 302 - Terminal Options Page of the Terminal Configuration Wizard**


1. Complete the Terminal Options page per these descriptions.

Setting/Button	Description
<b>Terminal Options</b>	
Allow replacement at the terminal if off line	Allows the terminal to appear in the replacement list during a new terminal connection.
Put Terminal in Admin Mode at Startup	Turns the Terminal on without showing the display clients, which is useful to use as the Terminal to register HID cards or fingerprint scans.
Enforce Boot Priority	Allows you to set an order for the Terminals to boot when many reboot at once.
Priority Settings	Launches the Boot Priority Settings dialog box.
<b>Terminal Schedule</b>	
Set Schedule	Makes Schedule active.
Schedule	Launches the Event Schedule dialog box for the terminal.
<b>Terminal Effects</b>	
Enable Terminal Effects	Allows the desktops in MultiSession to slide smoothly into the desktop instead of appearing instantaneously.
Show terminal status messages	Allows the Terminal to display status messages in the upper-left corner of the screen. Clear the checkbox to hide the messages from the operator.
<b>Shadowing</b>	
Allow terminal to be shadowed	Sets the Shadowing setting, which allows configuration of Shadowing Options.
No	Prevents the Terminal from being shadowed by anyone.
Ask	Asks the user to allow shadowing. The user must click Yes in a message dialog box before shadowing is allowed.
Warn	Displays a dialog box that alerts that the Terminal that it is to be shadowed, but does not require user input before shadowing is allowed.
Yes	Allows shadowing to occur without warning or user input.
Allow Interactive Shadow	Allows users with Shadowing permission to interactively shadow the Terminal. Clearing this checkbox puts it into a read-only mode.

a. Click Priority Settings.

The Boot Priority Settings dialog box appears.

**Figure 303 - Boot Priority Settings**



b. Complete the Boot Priority Settings dialog box per the descriptions that follow.

Setting	Description
Boot Priority	Sets the priority level of the terminal, with 1 as the highest priority and 99 as the lowest. The higher the number, the lower the priority.
Maximum wait time (seconds)	Sets the maximum interval the Terminal waits before starting to reboot.
Reboot Lower Priority Terminals on startup	Reboots lower priority (higher number) Terminals when this Terminal reboots, which is useful if the lower priority Terminals are running an application that has a dependency on the higher priority (lower number) Terminal.

c. Click OK.

2. Click Next to continue the configuration.


The Terminal Mode Selection page appears.



### Terminal Mode Selection Page

The Terminal Mode Selection page sets the modes used by the Terminal.

**Figure 304 - Terminal Mode Selection**



1. Complete the Terminal Mode Selection page per these descriptions.

Setting	Description
Enable ThinManager User Services	Uses Permissions and the membership of an Access Group to grant or deny access to applications, Terminals, or locations. See <a href="#">Permission-deployed Applications in ThinManager on page 323</a> for details.
Enable Location Services	Allows the Terminal to be assigned a Location and use the location features. <a href="#">Location Services on page 413</a> .
Enable MultiMonitor	Allows you to configure the Terminal to use two to five monitors depending on the hardware capability. <a href="#">MultiMonitor on page 599</a> .
Enable MultiSession	An advanced MultiMonitor function that allows multiple users to share a single MultiMonitor Terminal. It is not active unless MultiMonitor is activated. See <a href="#">Select Hotkey Dialog Box on page 240</a> .

ThinManager uses Display Clients to deploy applications. Check Use Display Clients to use them. If you clear the Use Display Clients checkbox, you lose other functions like MultiMonitor, TermSecure, MultiSession, and Instant Failover. See [Figure 404 on page 299](#).


2. Click Next.

The Display Client Selection page appears.

Display Client Selection Page


The Display Client Selection page allows the applications to be assigned to the Terminal.

**Figure 305 - Display Client Selection Page of the Terminal Configuration Wizard**



1. Move created display clients from the Available Display Clients list to the Selected Display Clients list to add them to the Terminal configuration. Double-click or highlight the display client and use the right arrow.

**Figure 306 - Display Client Selection Page of the Terminal Configuration Wizard**



The addition of two or more display clients is MultiSession, which provides the ability to deploy applications from different servers with ease.

2. Click Override.

The Override Settings dialog box appears.


**Figure 307 - Override Settings Dialog Box**

The Override Settings page allows you to change the user account used for logins, add a command line option, or change the resolution.

In a domain environment, you can use the Search button to pull a user account from the Active Directory. See [Active Directory User Login Account on page 243](#).

3. Click OK.

The Override Settings dialog box closes.

**Figure 308 - Override Indicator Icon**

If a Display Client has a setting overridden, then the Display Client shows a Changed icon in the Selected Display Clients list.


4. Click Next on the Display Client Selection page.

The Terminal Interface Options page appears.

#### *Terminal Interface Options Page*

The Terminal Interface Options page sets the methods to switch between display clients when using MultiSession.

**Figure 309 - Terminal Interface Options Page**



A single display client needs no additional navigation on the Terminal. However, if you have multiple display clients on the Terminal, you need to have a method to switch between the sessions. The Terminal Interface Options and Hotkey Configuration pages allow you to configure switching methods.

1. Complete the mouse options for switching as described here.


Setting/Button	Description
<b>Display Client Selection Options</b>	
Show Selector on Terminal	Displays an on-screen pull-down menu that can be activated by mouse.
Selector Options	Launches the Display Client Selector Options dialog box, which contains settings for tiling sessions when using MultiSession.
Enable Tiling	Allows Display Clients to be tiled on the monitor to provide an overview of all sessions at once.
Tiling Options	Launches the Tile Options dialog box, which has the settings for tiling sessions when using MultiSession.
Screen Edge Group Selection	Activates a feature that switches windows if the mouse is moved off screen.
Allow Display Clients to move to/from screen	Allows a display client to be moved to any active screen on a MultiMonitor thin client.
Main Menu Options	Shown when the Enable ThinManager User Services is checked on the Terminal Mode Section page.
Pin Pad Options	Opens the Pin Pad Options dialog box, which allows you to configure the PIN pad when using a Personal Identification Number instead of a password.

- a. Click Selector Options.

The Display Client Selector Options dialog box appears.

The Display Client Selector is hidden in the top center of the Terminal screen and is revealed when the mouse is moved to the center of the top edge.

**Figure 310 - Display Client Selector Options**



b. Complete the Display Client Selector Options dialog box as described.


Setting	Description
Auto-hide Selector	Hides the pull-down Display Client Selector menu until the mouse hovers over the top-center of the screen. Clear the checkbox to show the pull-down Display Client Selector at the top-center of the screen.
Tile on Selector activation	Tiles the sessions when an auto-hid selector is activated.
Selector Menu Size	Sets the size of the text in the Display Client Selector.

c. Click OK to accept changes.

d. Click Tiling Options.

The Tile Options dialog box appears.

**Figure 311 - Tiling Options**



The Tile Options window has several settings for tiling sessions when using MultiSession.

e. Complete the Tile Options dialog box as described.


Setting	Description
Show Grid	Shows tiled sessions in a grid with each grid labeled with the session name while the session is loading.
Tile Inactivity Time (secs)	Sets the length of time that the Terminal screen stays focused on a selected session before reverting to a tiled state due to inactivity.
Tile Display Clients at startup	Shows the sessions tiled when the Terminal first connects to its sessions.
Include Main Menu as tile	Includes a session displaying the TermSecure Main Menu.
Tile Interactive	Allows a user to click into a tiled session and control it interactively without switching focus to a single session. To focus on a single session, use the Display Client Selector pull-down menu or the tiling hotkey (CTRL + T), if enabled.

f. Click OK to accept changes.

g. Click Main Menu Options.

The Main Menu Options dialog box appears.

**Figure 312 - Main Menu Options**



The Main Options dialog box that has the settings for Main Menu when using ThinManager User Services. It is not visible unless ThinManager User Services is chosen on the Terminal Mode Selection page.


2. Complete the Main Menu Options dialog box as described here.

Setting	Description
Allow Reboot/Restart	Adds a terminal Restart and Reboot button on the Main Menu.
Show Main Menu on Selector	Lists the Main Menu as an option on the Display Client Selector pull-down menu.
Show Virtual Keyboard	Launches a virtual keyboard with the Main Menu open so the operator can log in manually.

- a. Click OK.
- b. Click Pin Pad Options.

The Pin Pad Options dialog box appears.

**Figure 313 - Pin Pad Options Window**



The Pin Pad Options dialog box allows you to configure the PIN pad when using a Personal Identification Number instead of a password.

3. Complete the Pin Pad Options dialog box as described here.

Setting	Description
Reverse Pin Pad Button Order	Changes the pin pad from 1-2-3 on the top row like a phone to 7-8-9 on the top row like a calculator.
Pin Pad Size	Sets the size of the pin pad as a percentage of the screen.


4. Click Next on the Terminal Interface Options page.

The Relevance Options page appears.

Relevance Options Page

The Relevance Options page allows the setting of the Relevance options.

Figure 314 - Relevance Options Page



Choose the Options before assigning a location, which locks the Options. If you need to change an option, click Clear to clear the location, change the option, and then reassign the Location.

- 1. Choose the Options as described here.

Setting	Description
<b>Assigned Location</b>	
Change	Launches the Select Location dialog box.
Clear	Clears the Assigned Location.
<b>Enabled Resolver Types</b>	
Enable QR Code Location Ids	Allows the scanning of a QR code to determine the location.
Enable Bluetooth Locations	Allows the use of Bluetooth beacons to determine the location.
Enable GPS Locations	Allows the Global Positioning System of the mobile device to determine the location.
Enable Wi-Fi Locations	Allows the signal strength of Wi-Fi access points to determine the location.
Use Force Transfer to restore Assigned Location	Lets an operator restore a transferred session without asking permission.
Allow Selection of the Location manually	Lets the user select the location manually from a menu on the mobile device. If this checkbox is cleared, then the user must use a Resolver.
Enforce fencing on a manual Location selection	Allows a manual login anywhere from that Terminal, which could be helpful on a control room Terminal. When chosen, this enforces fencing on that Terminal when a location is selected manually.
Confirm before entering a location	Enables a dialog box that is shown each time a user enters an area.
Resolver Update Interval	The frequency that the resolver updates.


Regarding Enable Resolver Types, Relevance has several methods of resolving the location to allow specific applications to get sent to specific locations. Each method selected requires configuration to associate a location with the Resolver data.



2. Click Change.

The Select Location dialog box appears.

**Figure 315 - Select Location Window**




The created Locations are displayed in the Select Location tree.

3. Highlight the desired Location and click OK.

Once the Location is assigned, the Options are locked.

**Figure 316 - Location Assigned**




4. Click Clear to clear the location and make the options available if you need to change an option, then re-assign the Location.
5. Click Next.

Select Hotkey Dialog Box

The Select Hotkey dialog box allows you to configure hotkeys for display client switching.

Figure 317 - Select Hotkey




- 1. Complete the Select Hotkey dialog box per these descriptions.

Setting	Description
Tile	Initiates the Tiling of display clients.
Swap	Exchanges display clients in Virtual Screens.
Full Screen	Expands an overlay to Full Screen.
Go to next display client	Navigates to the next display client in the list.
Go to previous display client	Navigates to the last-used display client.
Instant Failover	Allows hotkey switch between different sessions of a terminal using MultiSession.
Calibrate Touchscreen	Initiates the touch screen calibration program.
Log on ThinManager User	Opens the Relevance Login dialog box.
Log off ThinManager User	Logs off the ThinManager User.
Log in to location	Opens a login dialog box.
Log out of location	Logs off the user from the location.
Set keyboard focus to a screen	Directs the output of the keyboard to the specified screen. <b>Note:</b> to use this setting, the terminal must have MultiMonitor enabled. Set the Hotkey parameter to designate which screen receives the output.
Force failover to next display server	Allows you to fail over the active Remote Desktop Display Server set on a specified Display Client to another listed Remote Desktop Display Server. The failover affects the designated Display Clients only, and it does not disable or fail over the Display Server elsewhere. This setting is effective for Display Clients configured for Failover, instant Failover, and SmartSession. <b>Note:</b> this setting does not work on Display Clients set to Enforce Primary.

- a. (Optional) Choose Enable Instant Failover Hotkey, and then click Change Hotkey, which allows the hotkeys to be changed from the default.


The Select Hotkeys dialog box appears.

**Figure 318 - Select Hotkeys for Instant Failover**

The default hotkey for Instant Failover switching is set to Control+F9.


- b. Click Alt Key or choose another function key from the pull-down menu.
- c. Click OK to accept changes.
- d. (Optional) Click Enable Display Client Hotkeys, and then click Change Hotkeys, which allows the MultiSession switching hotkeys to be changed from the defaults.

The Select Hotkeys dialog box appears.

**Figure 319 - Select MultiSession Switching Hotkeys**

The default hotkey for MultiSession switching is set to Control+Page Up and Control+Page Down.


- e. Click Alt Key or use the pull-down menu to select another hotkey.
- f. Click OK to accept changes or Cancel to close.
- g. (Optional) Choose Enable Tiling Hotkey, and then click Change Hotkey, which allows the hotkey to be changed from the default.

**Figure 320 - Select SessionTiling Hotkeys**

The default hotkey for SessionTiling activation is set to Control+t.

- h. Click Alt Key or use the pull-down menu to select another hotkey.
- i. Click OK to continue or the Cancel button to close without accepting changes.
2. Click Next on the Hotkey Configuration page to continue the configuration.
3. Click Mouse Button Mapping.

The Mouse Button Mapping dialog box appears, which allows you to configure actions for the mouse buttons through pull-down menus.

**Figure 321 - Mouse Button Mapping**

4. Click OK to accept any setting changes and close the window.
5. Click Next on the Hotkey Configuration page.

The Log In Information page appears, which is used to specify a Windows Account that is used to log on to all Display Clients assigned to the Terminal automatically. See [Figure 329 on page 247](#).

# Active Directory User Login Account

A ThinManager Server deployed in a domain can pull an Active Directory account into the Username field of the Log In Information page of the Terminal Configuration Wizard. See [Figure 415 on page 306](#).


## Search for Active Directory User

1. Click Search, which launches a series of dialog boxes that allows you to select a domain user account for the Terminal login account.

The method is the same on Display Servers, Terminals, and ThinManager Users.

A Search for AD User dialog box appears that allows you to select an Active Directory user.

Figure 322 - Search for AD User Dialog Box



Buttons	Description
Locations	Opens the Select AD Location to Search dialog box to select the Organizational Unit (OU) to search.
Search	Searches the selected OU and populates the Name field with the OU members.
Options	
Filter	Filters results with either the Contains or Starts With function and what is entered into the text box.
Recurse	Sets the Search function to search nested Windows Security Groups when searching a Windows Security Group. The Choose AD Synchronization Mode must be set to Security Group on the Active Directory System Settings dialog box to work. Choose Manage>Active Directory>Settings to open the Active Directory System Settings dialog box.


## Search for Active Directory Location

The Search for AD User dialog box has a Location button that allows you to search the Active Directory locations.

2. Click Locations.

The Select AD Location to Search dialog box appears.


**Figure 323 - Select AD Location to Search Dialog Box**




- 3. Highlight the branch of the Active Directory tree that contains your administrative user account and click OK.

The organizational unit is listed as the location.

**Figure 324 - Search Organizational Unit**




- 4. Click Search to populate the dialog box with the users.


**Figure 325 - Search for AD User Dialog Box**

5. Highlight the desired user and click OK.


The domain user is added to the Username field of the Log In Information page.

**Figure 326 - Remote Desktop Server Name–Domain**

6. Type the password in the Password field.
7. Click Verify to check whether the password you entered is valid.
8. Once it is verified, click Next to continue with the wizard.

**Figure 327 - Invalid Account Message**

- a. If the dialog box indicates an invalid password, click OK and try again.

**Figure 328 - Valid Password Message**


- b. If the dialog box indicates a valid user account, click OK to close the Account Verify dialog box.
9. Click Next to continue the configuration wizard.

## User Accounts in the Terminal Configuration Wizard

Each Terminal needs a unique Windows account to start sessions on Windows Remote Desktop Servers.

These Windows accounts can be created locally on each Remote Desktop Server or in an Active Directory for domain accounts using standard Windows procedures. You can apply Microsoft security as desired.



**Figure 329 - Log In Information Page**


The screenshot shows a window titled "Terminal Configuration Wizard" with a close button (X) in the top right corner. Inside the window, the "Log In Information" section is active, featuring a sub-header "Log In Information" and a descriptive text: "Enter the log in information to log in automatically. Leave the log in information blank or fill only some of the fields to force manual log in." To the right of this text is a user icon. Below the text is a group box labeled "Windows Log In Information" containing four text input fields: "Username", "Password", "Verify Password", and "Domain". A "Search" button is located to the right of the "Username" field. At the bottom of the window, there are five buttons: "< Back", "Next >", "Finish", "Cancel", and "Help".

Leaving the Windows Log In Information fields blank forces the user to manually log in to their sessions, which is useful for office settings or shared Terminals. In this case, each user logs in with their personal account and gets the privileges that the administrator granted them.

#### *Local Windows User Accounts*

Complete the Windows Log In Information fields with an established Windows account to allow the Terminal to log in automatically and start sessions without user action. Completing this page is useful in industrial settings, where the Terminals are public and always run.

Figure 330 - Completed Log In Information Page



- 1. Complete the Log In Information page as described here.

Setting	Description
Username	A local Windows account.
Password	The password for the local Windows account. Complete this field if you want the Terminal to log in automatically.
Verify Password	Confirm the password. Complete this field if you want the Terminal to log in automatically.
Domain	Complete this field to use a domain Windows account.

Leave the fields blank to require the user to log in manually each time the Terminal connects.

Individual display clients can be set to require a manual login by clearing the Allow Auto-Login checkbox on the Remote Desktop Services and Workstation Options page of the Display Client Wizard. See [Figure 156 on page 126](#).

Individual display clients can be set to use a different Windows account than the Terminal by using the Override button on the Display Client Selection page of the Terminal Configuration Wizard. See [Figure 240 on page 185](#).

- 2. Click Next to continue the configuration.


*Active Directory User Login Account*

A ThinManager Server in a domain can pull an Active Directory account into the Username field using the Search button. This launches a series of dialog boxes, which allow you to select a domain user account for the Terminal login account.

- 1. Click Search.

The Search for AD User dialog box appears, which allows you to select an Active Directory user.

**Figure 331 - Search for AD User Window**




2. Complete the Search for AD User dialog box per these descriptions.

Button/Setting	Description
Locations	Opens the Select AD Location to Search dialog box to select the Organizational Unit (OU) to search.
Search	Searches the selected OU and populates the Name field with the OU members.
Filter	Filters the results with either the Contains or Starts With function and what you type into text field.
Recurse	Sets the Search function to search nested Windows Security Groups when you search a Windows Security Group. The Choose AD Synchronization Mode must be set to Security Group on the Active Directory System Settings dialog box to work, which is launched from Manage>Active Directory>Settings.

3. Click Locations.

The Select AD Location to Search dialog box appears.


**Figure 332 - Select AD Location to Search**



4. Highlight the branch of the Active Directory tree that contains your administrative user account and click OK. Highlighting an Active Directory branch reopens the Search for AD User window with the list of domain users from that branch.

The OU is propagated to the location field of the Search for AD User dialog box.


**Figure 333 - Search Organizational Unit**



5. Click Search.


The list of domain users from that branch are populated to the dialog box.

**Figure 334 - Search for AD User Window**




6. Highlight the desired user and click OK.

The domain user is added to the Username field of the Log In Information page.


**Figure 335 - Domain User Added to Username Field**


The screenshot shows the 'Terminal Configuration Wizard' window. The title bar is blue with a close button (X). Below the title bar is a 'Log In Information' section with a sub-header and instructions: 'Enter the log in information to log in automatically. Leave the log in information blank or fill only some of the fields to force manual log in.' There is a user icon on the right. The main area is titled 'Windows Log In Information' and contains three input fields: 'Username' (with 'hfinn@Education.local' entered), 'Password' (with masked characters '\*\*\*\*\*'), and 'Domain' (empty). To the right of the 'Username' field is a 'Search' button. To the right of the 'Password' field is a 'Password Options' button. To the right of the 'Domain' field is a 'Verify' button, which is highlighted with a red rectangle. At the bottom of the window are five buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

7. Type the correct password into the Password field.
8. Click Verify to check whether the password entered is correct.
  - a. If you receive a message of an invalid account, click OK and try again.

**Figure 336 - Invalid Account Message**

- b. If you receive verification, click OK..

**Figure 337 - Valid Password Message**

9. Click Next to continue in the configuration wizard.


The Video Resolution page appears.

#### *Video Resolution Page*

The Video Resolution page of the Terminal Configuration Wizard lets you choose the Resolution, Color Depth, Refresh Rate, and Rotation for your monitor.

The resolutions in the pull-down menus are dependent on the make and model of hardware used.

Figure 338 - Video Resolution



Setting	Description
Resolution	Choose the desired screen size from the pull-down menu, which lists the sizes available for the hardware chosen on the Terminal Hardware page. <b>Note:</b> WinTMC configurations offer a Full Screen option.
Color Depth	Choose the desired color depth from the pull-down menu, which contains the values available for the hardware chosen on the Terminal Hardware page.
Refresh Rate	Choose the desired refresh rate for the monitor from the pull-down menu, which contains the values available for the hardware chosen on the Terminal Hardware page. Adjustment to this setting can fix issues where the screen pans.
Rotation (for portrait mode)	Choose the desired rotation (0°, 90°, 180°, or 270°) from the pull-down menu to set the clockwise rotation of the attached monitor. <b>Note:</b> Available for terminals that use Firmware 9.1 and later.




Match the Resolution and Color Depth settings to your monitor’s specifications for a clear picture.

1. After making your choices, click Next.

WinTMC Settings

A Terminal configured as a WinTMC Terminal displays a WinTMC Settings page in the configuration wizard for WinTMC clients. These only apply to connections made by the WinTMC application.

Figure 339 - WinTMC Settings Page



1. Complete the WinTMC Settings page per these descriptions.

Setting	Description
<b>Redirect Local Resources</b>	
Redirect Serial Ports	Makes local serial ports available in a session. <sup>(1)</sup>
Redirect Drives	Makes local drives available in a session. <sup>(1)</sup>
Redirect Printers	Makes your local printer available in a session.
Redirect Sound	Allows audio played in your session to play locally. <sup>(1)</sup>
Redirect Smart Cards	Makes your smart card available in a session. <sup>(1)</sup>
<b>Client Control Settings</b>	
Allow client to be closed	Enables your user to close the client (WinTMC program).
Allow client to be sized	Enables your user to resize the client.
Always maintain monitor connection	Keeps the monitoring connection active when WinTMC is closed to allow shadowing. Clear this checkbox to release the WinTMC license when the WinTMC program is closed but denies shadow access.
Show display clients as separate windows	Displays multiple Display Clients as separate windows rather than in one window shell.
<b>Experience Settings</b>	
Show desktop background	Enables your user to select a Windows Desktop Background. If not selected, the background is a solid color.
Show window contents while dragging	Allows the window contents to be shown while the window is being dragged.
Show menu/window animations	Enables menu/window animations on the client.
Show themes	Enables your user to select a Windows Theme.
Disable NLA	Disables the user of Network Level Authentication for the client.

(1) Does not work when you connect to a Remote Desktop Server running Windows 2000 or earlier.



These functions may be denied by user policies or Remote Desktop Server configuration. Check the Microsoft Local Policy, Group Policy, and Remote Desktop Services Configuration.


2. Click Next.



### Mobile Device Settings

A Terminal configured as an Android or Apple iOS Terminal displays a Mobile Device Options page.

**Figure 340 - Mobile Device Options**



The Mobile Device Options page has several settings that control the user experience on mobile devices. It is displayed only when configuring an Android or iPad Terminal. This page allows you to disable features normally displayed in the mobile apps.


1. Complete this page per the these descriptions.

Setting	Description
<b>Toolbar Buttons</b>	
Show Scan Data Button	Clear this checkbox to hide the Scan Data button.
Show Scan Resolver Button	Clear this checkbox to hide the Scan Resolver button.
Show User Login Button	Clear this checkbox to hide the User Login button.
<b>Sound Options</b>	
Play Location Sounds	Plays a sound when a location is entered.
Play User Login Sounds	Plays a sound when the user logs in as a TermSecure or ThinManager user.
<b>User Interface Settings</b>	
Show Zoom Map	Clear this checkbox to hide the screen map while zooming.
Show Toolbar	Clear this checkbox to hide the app toolbar.
Allow Exit to ThinManager Server List	Clear this checkbox to prevent the user from leaving the app to switch ThinManager Servers.
Allow Terminal to sleep	Clear this checkbox to keep a tablet from going into sleep mode.

2. Click Next.

## Module Selection


**Figure 341 - Module Selection Page of the Terminal Configuration Wizard**



Modules are components that provide additional functions to a Terminal but are not required for running the basic configuration. Modules include touchscreen and sound drivers, dual Ethernet port modules, USB drives, screen savers, and so on.

1. Click Add to launch the Attach Module to Terminal dialog box, which allows you to choose a module to add to the Terminal.

**Figure 342 - Attach Module to Terminal**




2. Click OK to add the module and return to the Module Selection page.

Modules are covered in detail in [Modules on page 537](#).

3. Click Next on the Module Selection page to continue the configuration.

The ThinManager Server Monitor List page appears.

**Figure 343 - ThinManager Server Monitor List Page**


The ThinManager Server Monitor List page is a legacy page from earlier versions of ThinManager and is not used for this version. This page was used before Auto-Synchronization was added to ThinManager. This page was needed to list the ThinManager Servers for the Terminals. Auto-Synchronization does this automatically; so, the page does not appear when using Auto-Synchronization.

However, the ThinManager Monitor List page remains as part of the configuration wizard to prevent problems when upgrading from an old ThinManager system to a modern one.

4. Click Next to continue the configuration.

The Monitoring Configuration page appears, which sets the speed with which failover is detected and initiated.

Figure 344 - Monitoring Configuration Page



A thin client creates a socket connection to the Remote Desktop Server. If the socket is disconnected, the Terminal tries to reconnect and fails over based on these settings.

5. Complete the Monitoring Configuration based on these descriptions.

Setting	Description
<b>Pre-set Monitor Interval</b>	
Fast/Medium/Slow	These setting have a set rate for the frequency whith which the Remote Desktop Server status is checked.
Custom	Allows the administrator to change the settings from the defaults.
Monitor Interval	The period of time the Terminal waits after losing the socket connection before it tries to reconnect.
Monitor Timeout	The period of time the Terminal waits between tries.
Monitor Retry	The number of times the Terminal tries to reestablish a connection before failing over.
Primary Up Delay Multiplier	A constant used to generate the Primary Up Delay time.
Primary Up Delay	A delay added (usually set to 30 or 60 seconds) to allow a Remote Desktop Server to get fully booted before the Terminal tries to login. This time period is equal to the Monitoring Interval multiplied by the Primary Up Delay Multiplier. This setting prevents a Terminal using Enforce Primary from switching back to its primary Remote Desktop Server before it is ready.
Connection Timeout	The amount of time in which a Terminal tries to connect to a Remote Desktop Server before giving up to try the next server.



The Fast setting is recommended.

Faster rates cause a quicker failover, but more frequent checks on Remote Desktop Server status cause more network traffic. Slower rates cause less traffic, but they slow the failover speed a little.

6. Click Finish to save the settings.

## Copy Settings from another Terminal

You can copy the settings from one Terminal during the creation process to speed the configuration.

To create a new Terminal, follow these steps.


1. Right-click on the Terminals branch and choose Add Terminal.

The Terminal Name page of the Terminal Configuration Wizard appears.

**Figure 345 - Terminal Name Page**

2. Check Copy Settings from another Terminal.
3. Click Copy From.

The Select Terminal dialog box appears, which shows a tree with all of the created Terminals.


**Figure 346 - Select Terminal**

4. Highlight a Terminal and click OK.

The dialog box closes and the configuration is applied from the highlighted Terminal to the new Terminal.

5. Click Next.

The Terminal Hardware page appears, where the new Terminal gets Terminal hardware applied to it.

**Figure 347 - Terminal Hardware Page**

6. Choose the hardware Make and Model to make Finish available.

You should also verify the Username and Password on the Windows Log In Information page since every Terminal needs a unique Windows account login. See [Figure 601 on page 420](#) for more details.

## Use Groups for Organization


ThinManager allows the consolidation of Terminals into Terminal Groups, which are used like folders to organize the Terminals into functional or geographic groups. The Group Setting checkbox allows settings to be applied to all members of the group to speed configuration and change deployment.

Any group setting is passed down to its members.

The Group Terminal Configuration Wizard is launched from the Terminals branch of the ThinManager tree.

1. Click the Terminal icon at the bottom of the ThinManager tree to open the Terminals tree.


**Figure 348 - Add Group Command**



2. Right-click on the Terminals branch and choose Add Group.


The Terminal Configuration Wizard appears. The wizard for the Group parallels the Terminal Configuration Wizard since the group is a collection of Terminals.

Figure 349 - Add Group Menu



- 3. (Optional) Right-click on a group and choose Add Group to add a subgroup, which adds a group under the highlighted group.


Figure 350 - Change Group Button



- 4. Click Change Group to add a Terminal.

The Select Terminal Group dialog box appears, which lists the groups and subgroups.




**Figure 351 - Select Terminal Group**

5. Expand the tree as needed, highlight the desired group, and click OK.

The Terminal is assigned to the selected group.

6. Click Finish to close the wizard and apply the changes before you continue. If you need to adjust the configuration, close the wizard and then reopen it.

**Figure 352 - Group Membership**

The group appears in the Terminal Group field, and the Terminal appears nested in the group in the Terminals tree.


*Moving Out of a Group*

A Terminal can be removed from a group by moving it to the Terminals branch of the Select Terminal Group dialog box.

1. Double-click on the Terminal you want to change in the Terminals tree.

The Terminal Name page of the Terminal Configuration Wizard appears.


**Figure 353 - Change Group Button on the Terminal Name Page**



2. Click Change Group.

The Select Terminal Group dialog box appears.


**Figure 354 - Select Terminal Group Window**



3. Choose the top-level Terminals in the Terminal Group tree and click OK.
4. In the Terminal Configuration Wizard, click Finish.

The changes are applied. If you need to adjust the configuration, close the wizard, then reopen it.

**Figure 355 - Terminals Tree Showing Ungrouped Terminal**



Once the wizard is closed, the ThinManager Terminals tree shows the Terminal under the Terminals branch and the Terminal Group field of the Terminal Name page is empty.

## Use Groups for Configuration

ThinManager Terminal Groups can be used for faster configuration as settings configured at the group level are applied to all the Terminals in the group. You can use Group Setting with every setting in the Group Configuration Wizard.


Adding display clients is easy when you use Group Settings.

1. In the Terminals tree, double-click on a Terminal.

The Terminal Group Name page of the Terminal Configuration Wizard appears.


2. Click Next until the Display Client Selection page appears.

[Figure 356](#) shows that Line\_1 group has three Terminals with a single display client assigned.

**Figure 356 - Display Client Deployed With Group Settings**

3. Check Group Setting.
4. Change the Selected Display Clients.
5. Click Finish.
6. Restart the Terminals.

[Figure 357](#) shows that the Line\_1 group had its group display clients changed one time, and the change was propagated to all the member Terminals.

**Figure 357 - Display Clients Deployed With Group Settings**

To demonstrate the effects of using Group Setting, the following figures show the Group Configuration Wizard on the left and the Terminal Configuration Wizard of a member Terminal on the right.

**Figure 358 - Terminal Group Name and Terminal Name Pages**

The left screenshot shows the 'Terminal Group Name' page of the Terminal Configuration Wizard. It prompts the user to 'Enter the name for the terminal group'. The 'Group Name' field contains 'Line\_1'. Below it, a note states: 'This must be a unique name using letters, numbers, hyphens (-), and underscores (\_) only.' There is a 'Description' button. The 'Terminal Group' dropdown shows 'Production', with a 'Change Group' button next to it. At the bottom, there are navigation buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

The right screenshot shows the 'Terminal Name' page. It prompts the user to 'Enter the name for this terminal, select the terminal group to which this terminal belongs, or choose to copy the configuration from another terminal.' The 'Terminal Name' field contains '2-1 Terminals'. A note states: 'This must be a unique name using letters, numbers, hyphens (-), and underscores (\_) only.' There is a 'Description' button. The 'Terminal Group' dropdown shows 'Production\Line\_1', with a 'Change Group' button next to it. Below this, there is a 'Copy Settings' section with a checkbox 'Copy Settings from another Terminal' and a 'Copy From' button. At the bottom, there are navigation buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

The left figure shows the opening screen of the Group Configuration Wizard while the right figure shows the Terminal Configuration Wizard of a group member.


The Group Configuration Wizard does not show the Terminal Hardware page since that is an individual selection, not a group selection. The Terminal Configuration Wizard shows the Terminal Hardware page, where you select the hardware for the individual device.

**Figure 359 - Terminal Group Options and Terminal Options Pages**


The left screenshot shows the 'Terminal Group Options' page. It prompts the user to 'Select the options for terminals in this group.' There are four sections: 'Terminal Options' with 'Allow replacement at terminal if off line' checked and 'Put Terminal in Admin Mode at Startup' unchecked; 'Terminal Schedule' with 'Set Schedule' unchecked and a 'Schedule' button; 'Terminal Effects' with 'Enable Terminal Effects' and 'Show terminal status messages' both checked; and 'Shadowing' with 'Allow terminal to be shadowed' set to 'WARN' and 'Allow Interactive Shadow' checked. Each section has a 'Group Setting' label with a checkmark. At the bottom, there are navigation buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

The right screenshot shows the 'Terminal Options' page. It prompts the user to 'Select the options for this terminal.' The settings are identical to the left screenshot, but the 'Group Setting' label is dimmed, indicating that the terminal inherits the group settings. At the bottom, there are navigation buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

On the left, Group Settings is checked in the Group Configuration. On the right, the Terminal Configuration inherits Group Settings; therefore, Group Settings is dimmed.

**Figure 360 - Group Terminal Mode Selection and Terminal Mode Selection Pages**


In the Terminal Configuration Wizard on the right, Enable MultiMonitor is available because that is based on the hardware selected and not the group membership.

**Figure 361 - Group Display Client Selection and Terminal Display Client Selection Pages**

Choose display clients on the Group Configuration Wizard and check Group Setting to assign those display clients to all member Terminals. You cannot add or subtract from the list in the Terminal Configuration Wizard.


The Group Setting is efficient when all members of a group run the same applications. If members need a different application, clear the Group Setting checkbox and assign the display clients.

**Figure 362 - Group Terminal Interface Options and Terminal Interface Options Pages**




On the left, the Group Configuration has Group Settings checked. On the right, the Terminal Configuration has the settings dimmed because it is inheriting the Group Settings.

**Figure 363 - Group Hotkey Configuration and Terminal Hotkey Configuration Pages**



On the left, the Group Configuration has the Group Settings checked. On the right, the Terminal Configuration has the settings dimmed because it is inheriting the Group Settings.

**Figure 364 - Group Log In Information and Terminal Log In Information Pages**




The Group Log In Information page is dimmed and does not allow a group user account to be added. This is because each Terminal needs a unique Windows account to log in to Remote Desktop Servers.



Use a unique Windows account for each Terminal.

**Figure 365 - Group Video Resolution and Terminal Video Resolution Pages**




The video resolution can be applied to all members of a group. However, if the monitor size is changed unexpectedly, you must clear the Group Settings checkbox and apply the resolutions individually.




Since resolution may vary from terminal or station, it is not better to set video resolution at the group level.



**Figure 366 - WinTMC Settings**

The Group Configuration Wizard has a WinTMC Settings page, which allows configuration of WinTMC clients with Group Settings.


The WinTMC Settings page does not appear in the Terminal Configuration Wizard unless GENERIC/WinTMC is chosen as the Make and Model on the Terminal Hardware page.

**Figure 367 - Mobile Device Group Options**

The Group Configuration Wizard has a Mobile Device Group Options page, which allows mobile clients to be configured with Group Settings.

This page does not appear on the Terminal Configuration Wizard unless GENERIC/Android Device or Apple/iOS is chosen as the Make and Model on the Terminal Hardware page.


**Figure 368 - Group Module Selection and Terminal Module Selection**



Modules can be added at the Group and Terminal levels. Modules selected for a group display a Group icon on the Module Selection page of its members.

The left-side image in [Figure 368](#) shows a module added to the group configuration. The image on the right shows that module on the Terminal with the Group icon to show from where it originated. Also in the image at right, the USB touch screen module was added to the Terminal, but does not show a group icon.

**Figure 369 - Terminal Group Name and Terminal Name**




In [Figure 369](#), the Group Configuration on the left has the Group Settings selected. The Terminal Configuration on the right has the settings dimmed because it is inheriting the Group Settings.

## Deleting Old Groups

Follow these steps to delete an unnecessary group.

1. Click the Terminals icon at the bottom-left of ThinManager to open the Terminals tree.


**Figure 370 - Delete Option on Group Right-click Menu**



2. Right-click on the group and choose Delete.

The Delete dialog box appears.

**Figure 371 - Delete Dialog Box**





---

**IMPORTANT** Read the dialog box before taking an action to prevent the loss of needed Terminals.

---

3. Click Yes, No, or Cancel.
  - a. Click Yes to delete the group **and** member Terminals.
  - b. Click No to delete the group but leave the Terminals under the Terminals tree.
  - c. Click Cancel closes the dialog without deletion.

Figure 372 - Terminal Tree Showing Terminals without the Group



The Terminals from Line\_1 are now nested under the Production group in the Terminals tree.

**EXAMPLE** The two active Terminals from the Line\_1 group are showing the Alert icon, indicating that they must be restarted to load the changed configurations.

## IP Configuration

These are the five types of Terminals that can be used in a ThinManager system.

- ThinManager-ready thin clients
- ThinManager-compatible thin clients
- WinTMC client for Windows PCs
- iTMC client for iOS, iPads, and iPhones
- aTMC client for Android mobile devices

Each type has a different method for connecting to ThinManager to receive its configuration.

A ThinManager-ready thin client is shipped from the factory with the ThinManager BIOS onboard. A ThinManager-ready thin client requires these two things to connect to the ThinManager system.

- An IP Address for the client
- The ThinManager Server Address to retrieve the needed boot file and configuration

A ThinManager-ready thin client can use Dynamic Host Configuration Protocol (DHCP) or a static IP address for the client and ThinManager Server IP address. Its BIOS instructs it to download the firmware.

A ThinManager-compatible thin client is a thin client that lacks the ThinManager BIOS. ThinManager-compatible thin clients do not store static IP addresses; so, each of them requires DHCP to assign the client IP address. The ThinManager Server IP address and bootfile name can be provided by a DHCP server or the ThinManager PXE Server.

A ThinManager-compatible thin client requires these three things to connect to the ThinManager system.

- PXE Boot enabled in ThinManager
- An IP Address for the client
- The ThinManager Server Address to retrieve the needed boot file

The WinTMC client is a ThinManager client that runs on a Windows operating system and provides a centrally managed connection to the Remote Desktop Server.

Each client PC requires these two things to connect to the ThinManager system.

- The installation of the WinTMC program
- The IP address of the ThinManager Server

The iTMC client is a ThinManager client that runs on an Apple iOS operating system and provides a centrally managed connection to the Remote Desktop Server.

Each iPad requires these three things to connect to the ThinManager system.

- The installation of the iTMC program from the Apple App Store
- Membership on the ThinManager Server network
- The IP address of the ThinManager Server

The AndroidTMC client is a ThinManager client that runs on the Android operating system and provides a centrally managed connection to the Remote Desktop Server.

Each Android device requires these three things to connect to the ThinManager system.

- The installation of the aTMC program from the Google Play Store
- Membership on the ThinManager Server network
- The IP address of the ThinManager Server


## ThinManager-ready Thin Client IP Configuration

### DHCP

A ThinManager-ready thin client is shipped from the factory set to use DHCP (Dynamic Host Configuration Protocol).


1. After the Terminal is turned on, a prompt to press any key to configure the IP setting appears. Press the space bar.

**Figure 373 - IP Configuration Prompt Page**




The IP Configuration Menu appears.

**Figure 374 - IP Configuration Menu Page**



Out of the box, ThinManager-ready thin clients use DHCP, which assigns an IP address to the thin client. However, the thin client also needs the IP address of the ThinManager Server. ThinManager Server's IP address can be provided by the DHCP server using Option 066, Boot Server Host Name.

**Figure 375 - Microsoft DHCP Server**



2. Check option 066 Boot Server Host Name, and enter the IP address of the ThinManager Server in the String value field to have the DHCP server send the IP address to the ThinManager-ready thin clients.

PCs and laptops that use DHCP ignore this setting.


### *Static IP Addressing*

Most models of ThinManager-ready thin clients allow the usage of static IPs, which are set on the IP Configuration Menu.

1. Press any key at the IP Configuration Prompt page.

The IP Configuration Menu appears.

**Figure 376 - IP Configuration Menu - Static IP**



2. Press A to allow the client IP address to change from DHCP to static.

3. Type the static IP address for the client, including the separating periods, and press Enter.

Once the Terminal has a static IP assigned, the IP Configuration Menu is shown to allow the setting of other values.

Setting	Configuration	Description
(A)	Terminal IP Address	A unique address for the Terminal.
(B)	Primary ThinManager Server IP Address	The unique address for your main ThinManager Server.
(C)	Secondary ThinManager Server IP Address	The Secondary ThinManager field allows the Terminal to use two ThinManager Servers. If the Terminal cannot connect to the Primary ThinManager Server, it connects to the Secondary ThinManager Server to receive its configuration. If you are not using a Secondary ThinManager Server, set the IP address to 0.0.0.0.
(D)	Router IP Address	Fill in the IP address of the router or gateway. If one is not used, set to 0.0.0.0.
(E)	Subnet Mask	Set to 0.0.0.0.
(F)	Password Status	Set this to your subnet mask. 255.255.255.0 is a standard setting. <b>IMPORTANT:</b> Do not forget this password.
(G)	Load Default Values	Resets the ThinManager-ready thin client to the original IP values.
(H)	Help	Launches Help to explain the IP Configuration Menu.
(Q)	Abort Changes and Exit	Cancel any setting changes and let the Terminal continue to boot with the old settings.
(S)	Save Changes and Exit	Apply any changes and allow the Terminal to continue to boot with the new settings.

4. Type the letter of the desired setting and type the IP address, with periods. Press the Enter key on the keyboard to accept each change.


### Hybrid IP Addressing

ThinManager-ready thin clients with Boot Loader 5.01 and later can use DHCP to assign the Terminal IP address. However, they can assign the ThinManager Server IP address as a static IP in the IP Configuration Menu, as well.

1. Boot your thin client and press the spacebar when prompted on the IP Configuration Prompt page.


The IP Configuration Menu appears.

**Figure 377 - Boot Loader Default Values**



2. Press B to add a static IP for the ThinManager Server.
3. Type the address.



**Figure 378 - DHCP with Static ThinManager Server**

4. Once a ThinManager Server is assigned, type C to allow a redundant secondary ThinManager Server to be assigned.
5. Type S to save the changes and allow the connection to the ThinManager Server.


The Terminal nows boot using DHCP.




The Escape key lets you exit the entry field and return to the IP Configuration Menu.

### *Firmware Download*

Once the ThinManager-ready thin client is configured, the Terminal connects to the ThinManager Server and downloads the firmware and configuration.

**Figure 379 - Firmware Download**

If the static IP address for the Terminal is a duplicate of another IP address on the network, an error message is displayed, and the firmware download stops.

**Figure 380 - Duplicate IP Address Error**

A Terminal with an error message needs to be rebooted and the IP address corrected, see [Figure 380](#). This is the error message: “A Device Exists on the Network with this Terminal’s IP Address. You Must Resolve this Conflict to Continue.”


## Add and Configure Thin Clients

### *Connect and Start Wizard*

When a Terminal is turned on for the first time, it initiates the Create New Terminal mode given one of the conditions that follow are true.


- No Terminals are defined in ThinManager.
- All the defined Terminals are currently connected.
- All the defined Terminals that are turned off have the Allow replacement at terminal if off line checkbox cleared on the Terminal Group Options page. See [Figure 359 on page 267](#).

When a Terminal enters the Create New Terminal Mode, the Terminal launches the Terminal Configuration Wizard on the ThinManager Server. The Terminal displays a dialog box that indicates to wait until the configuration is finished before you proceed.

**Figure 381 - Create New Terminal Mode Screen**

### *Preconfigure and Select Configuration*

The Replace or Create New Terminal Mode is initiated when a Terminal is turned on for the first time and Allow replacement at terminal if off line is checked on the Terminal Group Options page. See [Figure 359 on page 267](#).

**Figure 382 - Replace or Create New Terminal Mode**

The dialog box displays all the offline Terminals that the Terminal can replace. Groups are displayed, which requires a pull-down menu to the desired Terminal.

Highlight the desired Terminal name using the keyboard and press Enter.

The Terminal retrieves the selected configuration and assumes its identity.

If a Terminal has previously connected to ThinManager and received its configuration, rebooting it does not present the option to select a different terminal configuration.

## PXE Server and PXE Boot

A ThinManager-ready thin client is shipped from the factory with the ThinManager BIOS onboard. A ThinManager-ready thin client can use DHCP or static for the client and ThinManager Server IP addresses. Its BIOS instructs it to download the firmware.

A ThinManager-compatible thin client is a common off-the-shelf thin client that lacks the ThinManager BIOS. ThinManager-compatible thin clients do not store static IP addresses. Therefore, each of these thin clients is assigned an IP address by a DHCP server.

A ThinManager-compatible thin client requires three things to connect to the ThinManager system.

- An IP Address for the device.
- The ThinManager Server Address to retrieve the needed boot file.
- The Boot File name.

### PXE Server Modes

There are four modes or methods that a ThinManager-compatible thin client can use to receive information.

- Using standard DHCP server
- Using standard DHCP server on this machine
- Using standard DHCP server with Boot Options (PXE Disabled)

- Not using standard DHCP server

Table 2 - ThinManager-compatible Thin Client IP Sources

Mode/Method	Device IP	ThinManager IP	Boot File Name
Using Standard DHCP	DHCP Server	ThinManager	ThinManager
Using Standard DHCP on machine	DHCP Server	ThinManager	ThinManager
DHCP with Boot Options	DHCP Server	DHCP Option 066	DHCP Option 067
Not Using Standard DHCP	ThinManager	ThinManager	ThinManager


*Using Standard DHCP Server*

Use the Using standard DHCP server mode when you have an existing DHCP server in your system to pass out the IP addresses.

1. Choose Manage>PXE Server to open the PXE Server Wizard.

The PXE Server Configuration page appears.

Figure 383 - PXE Server Configuration Wizard




2. Check Enable PXE Server and click Next.

The Network Interface Configuration page appears.

**Figure 384 - Network Interface Configuration Page of PXE Server Configuration**

Setting	Description
Select Interface to Configure	Pull-down menu allows the network interfaces to be configured individually if ThinManager Server has multiple network cards.
<b>PXE Server Mode</b>	
Using standard DHCP server	Uses existing DHCP server to provide client IP addresses while the ThinManager PXE server provides the ThinManager IP and boot file name.
Using standard DHCP server on this machine	Required to provide the PXE information when a standard DHCP server is installed on the same computer as the ThinManager Server. Additionally, Port UDP-4011 must be open on the computer.
Using standard DHCP server with Boot Options (PXE Disabled)	Allows DHCP server to provide all needed information. Use if your DHCP server is configured to use Option 066 (Boot Server Host Name) with the ThinManager Server IP address. You must use Option 067 (Boot file name) set to <i>acpboot.bin</i> .
Not Using standard DHCP server	Allows PXE thin clients to connect to ThinManager, which provides all necessary information, through the selected network interface. Clear this checkbox if you only want known clients to connect.
<b>IP Address Conflict Detection</b>	
ARP	Checks for conflicts in the Address Resolution Protocol.
None	Does not check for conflicts in the Address Resolution Protocol.
Allow New PXE Clients	Allows unknown PXE thin clients to connect to ThinManager through the selected network interface. Clear the checkbox to allow only known clients to connect, which is a security feature that can prevent the provision of PXE information to new PXE boot ThinManager-compatible thin clients.

**Figure 385 - Synchronized Network Interface Configuration Page**

A synchronized ThinManager Server has a pull-down menu for the network interface on both ThinManager Servers.

The easiest method of PXE boot is if you have an existing DHCP server.

3. Choose Using standard DHCP server and click Finish.

The PXE Server Initialization dialog box appears.


**Figure 386 - PXE Server Initialization Dialog**

The PXE server initializes and becomes active.

When the ThinManager-compatible thin client is turned on, it requests the DHCP and PXE information. The DHCP server responds with the client IP address. ThinManager responds with the PXE boot information, and the thin client connects to ThinManager.

#### *Using Standard DHCP Server on this Machine*

Use the Using standard DHCP server on this machine mode when you have an existing DHCP server in your system to assign the IP addresses, and it is installed on the ThinManager Server.

**Figure 387 - Using standard DHCP server on this machine**

This mode optimizes the PXE server when the ThinManager Server is installed on the same machine as the DHCP server.

Port UDP-4011 must be open for this setting, and it is also required for Unified Extensible Firmware Interface (UEFI) boot PXE clients.

#### *Using standard DHCP server with Boot Options*


Use the Using standard DHCP server with Boot Options (PXE Disabled) mode when you have an existing DHCP server that is not on the ThinManager Server and want it to provide all the information.

The DHCP server needs to be configured to provide Option 66, Boot Server Host Name, and Option 67, Bootfile Name.

## On the DHCP Server

1. Choose Start>Administrative Tools>Computer Management on your Microsoft DHCP server to open the Microsoft DHCP Service.

**Figure 388 - Microsoft 2012 Server DHCP Scope Options**



2. Right-click on Scope Options in the Scope tree and choose Configure Options.

The Scope Options dialog box appears.

3. Scroll to and check Option 066 Boot Server Host Name. Type the IP address of the ThinManager Server in the String value field. If you use a redundant pair of ThinManager Servers, enter both IP addresses separated by a space.
4. Scroll to and check Option 067 Bootfile Name. Type `acpboot.bin` in the String value field.

The DHCP server is allowed to provide the boot information to both ThinManager-ready thin clients using the default DHCP and ThinManager-compatible thin clients via PXE boot. DHCP server is able to do this because we configured a DHCP to provide IP addresses, the ThinManager Server IP address as Option 066 and the `acpboot.bin` bootfile as Option 067.

## In ThinManager

1. Choose Manage>PXE Server to open the PXE Server Wizard.
2. On the PXE Server Configuration page, check Enable PXE Server.
3. Click Next.

The Network Interface Configuration page appears.



**Figure 389 - Network Interface Configuration Page**

4. In the PXE Server Mode section, choose Using standard DHCP server with Boot Options (PXE Disabled).
5. Click Finish.

The PXE server is configured.

When the ThinManager-compatible thin client is turned on, it makes a DHCP request. The DHCP server responds with the client IP address, ThinManager IP address, and name of the bootfile to download. The ThinManager-compatible thin client connects to ThinManager.

#### *Not using standard DHCP server*

Use the Not using standard DHCP server mode when you do not have an existing DHCP server. This mode is configured to give ThinManager the ability to pass all the information needed to boot.

ThinManager only passes IP addresses to terminals making a PXE request. It ignores traditional DHCP requests.

1. To open the PXE Server Wizard, choose Manage>PXE Server.

The PXE Server Configuration page appears.

2. Check Enable PXE Server.
3. Click Next.

The Network Interface Configuration page appears.

**Figure 390 - Network Interface Configuration Page**

**PXE Server Wizard**

**Network Interface Configuration**  
Select the settings for each network interface

Select Interface to Configure  
Microsoft Hyper-V Network Adapter

Interface Primary IP Address 10.3.10.153

**PXE Server Mode**

- ☐ Using standard DHCP server
- ☐ Using standard DHCP server on this machine
- ☐ Using standard DHCP server with Boot Options (PXE Disabled)
- ☒ Not using standard DHCP server

**IP Address Conflict Detection**

- ☒ ARP
- ☐ None


☒ Allow New PXE clients

< Back Next > Finish Cancel Help

4. Click Not using standard DHCP server.
5. (Optional) Click ARP to have the IP Address Conflict Detection check for conflicts in the Address Resolution Protocol.
6. (Optional) Check Allow New PXE clients to control whether ThinManager gives PXE information to new PXE boot ThinManager-compatible thin clients.
7. Click Next.

The IP Address Range Configuration page appears.

Figure 391 - IP Address Range Configuration




The ThinManager Server needs to have a range of available IP addresses so that it can give the ThinManager-compatible thin clients their IP addresses.

8. Click Add.

The IP Address Range dialog box appears.

Figure 392 - IP Address Range



9. Complete the IP Range dialog box per these descriptions.

Setting	Description
Starting IP Address	Type the first IP address for the PXE Server to assign.
Ending IP Address	Type the last IP address for the PXE Server to assign.
Subnet Mask	The subnet mask of the network.
Router IP Address	If needed, type the IP address of your router. Leave as 0.0.0.0 if not needed.
<b>Buttons</b>	
Exclusions	Launches the Exclusions dialog box to exclude a specific IP address from the available page.

Setting	Description
Reservations	Launches the Reservations dialog box that allows you to reserve a specific IP address to be assigned to a thin client based on the thin client MAC add address.
Advanced	Launches the Advanced IP Range Settings dialog box, which allows the addition of DHCP options.
Clear IP Addignments	Clears the settings from the IP Address Range dialog box.


*Exclusions*

To add an exclusion to the IP address range, complete these steps.

1. On the Exclusions dialog box, click Add.

The Exclusion Range dialog box appears.

**Figure 393 - Exclusions and Exclusion Range Dialog Boxes**



2. Type the Exclusion Start IP Address.
3. Type the Exclusion End IP Address.



To exclude a single IP address, enter it in the Exclusion Start IP Address field.

4. Click OK to close the Exclusion Range dialog box.
5. Click OK to close the Exclusions dialog box.

The range of IP addresses to exclude from assignment is complete.

*Reservations*

Reservations allow you to assign a specific IP address to a thin client each time it boots. This can be done in the PXE Server or in the Terminal Configuration Wizard.

*Reservations in the PXE Server*

To add a Reservation, complete these steps.


1. On the IP Address Range dialog box, click Reservations.

The Reservations dialog box appears.

2. Click Add.

The Reservation dialog box appears.


**Figure 394 - Reservation Window in the PXE Server**



3. Type the MAC address from the ThinManager-compatible thin client in the Hardware Address (MAC) field.
4. Type a secondary MAC address if the ThinManager-compatible thin client has two NICs. These MAC addresses are often on the serial number label.
5. Type the IP Address you want to assign to it.
6. Click OK on the Reservation dialog box.
7. Click OK on the Reservations dialog box.

The IP address range is displayed on the IP Address Range Configuration page when the IP Address Range dialog box is closed.

**Figure 395 - IP Address Range in PXE Server**



The ThinManager PXE server is not a true DHCP server. It only issues IP addresses to PXE boot devices. It does not assign IP addresses to other computers, laptops, or devices.

## Reservations in the Terminal Configuration Wizard

ThinManager has an easy way to reserve IP addresses for PXE boot thin clients.

Follow these steps.

1. Turn on the device and associate it with a configuration.

**Figure 396 - Original Assigned IP Address**




Figure 396 shows the original IP address.

2. Turn off the device. You cannot change the IP address of a Terminal that is on.

When off, the Terminal icon in the tree turns red.

3. Double-click on a turned off Terminal in the ThinManager tree to open the Terminal Configuration Wizard.
4. Navigate to the Terminal Hardware page and click Edit.

The Edit Terminal Id page appears, which is only be active on Terminals that are off.

**Figure 397 - Edit Terminal ID Window**

**Terminal Configuration Wizard**

**Terminal Hardware**  
Select the manufacturer and model of this terminal.

**Edit Terminal Id**

Terminal Id (MAC) 000C29EF1AC3

Secondary MAC Address (optional)

IP Address (for PXE clients)

☒ Statically assign IP Address

Static IP Address 10 . 7 . 10 . 158

OK Cancel

Clear


Terminal ID 000C29EF1AC3

Edit

< Back Next > Finish Cancel Help

5. Check Statically assign IP Address, which allows you to set a static IP reservation when addresses are assigned with the ThinManager PXE server.
6. Click OK to close the Edit Terminal Id page.
7. Click Finish to close the Terminal Configuration Wizard.
8. Right-click the Terminal, and choose Restart.

It is now assigned the new IP address.

**Figure 398 - Newly Assigned IP Address**

An advantage of using ThinManager to assign IP addresses is, if you do a replacement, the replacement Terminal is assigned the reserved IP address.


## Local WinTMC Configuration

WinTMC is a PC application that allows ThinManager to manage the RDP connections between the PC and Remote Desktop Servers. Also, WinTMC provides enhanced features like failover and Instant Failover, which standard RDP connections lack.

The WinTMC needs to be installed on a PC, then it needs to be configured to point to ThinManager to receive its configuration.

When WinTMC starts, Configure is displayed on the ThinManager splash screen.


**Figure 399 - WinTMC Splash Screen**



1. Click Configure to specify the ThinManager Server(s) to use.

The Add New ThinManager Server dialog box appears.



**Figure 400 - WinTMC ThinManager Server List Configuration**

The ThinManager Server List allows the WinTMC to be pointed to one or more ThinManager Servers to retrieve its configuration.

2. Type the IP address or name of your ThinManager Servers in the Enter new ThinManager Server Name or IP Address field and click OK to add them to the Current ThinManager Server list.
3. Click Move Up and Move Down to change the list order of ThinManager Servers with which WinTMC tries to connect.
4. Click Delete to remove unneeded ThinManager Servers.
5. (Optional) Click Set Password to password protect this configuration menu.


Once a password is configured, it is required to change the configuration when a user clicks Configure when WinTMC is started.

If OK is clicked without entering a ThinManager Server, an error dialog reminds you to enter a ThinManager Server address.

#### *No ThinManager Server Specified*



Once the local configuration is set, WinTMC connects to a ThinManager Server and attempts to retrieve its configuration.

*Terminal Replacement Dialog*

If the WinTMC PC has not been defined, the user is prompted with a dialog box to allow for the creation of a new configuration or to replace an existing Terminal configuration on the ThinManager Server.

This functionality is similar to that of the create/replacement menu on a Thin Client. Select the thin client configuration you want to assume. Once the WinTMC is assigned a configuration, you do not need to make a selection again.

## **WinTMC Configuration in ThinManager**

To create a WinTMC client in ThinManager using the Terminal Configuration Wizard, follow these steps.

1. Choose GENERIC from the Make/OEM pull-down menu and WinTMC from the Model pull-down menu on the Terminal Hardware page.

**Figure 401 - WinTMC Settings in Terminal Hardware**

The Terminal ID populates with the name of the PC once the WinTMC client is tied to a PC.

The Terminal Configuration Wizard for a WinTMC client is the same as for a thin client with a few exceptions—the Video Resolution page and the WinTMC Settings page.

**Figure 402 - Video Resolution for WinTMC**

The Video Resolution for WinTMC includes a setting for FullScreen, which populates with whatever resolution the PC client runs.

Also, you may choose from set resolutions.



-  WinTMC that runs on computers with multiple monitors can run as MultiMonitor WinTMC clients.

Figure 403 - WinTMC Settings



The Terminal Configuration Wizard includes a WinTMC Settings page for WinTMC clients. These settings only apply to connections made by the WinTMC application and include the following.

Setting	Description
<b>Redirect Local Resources</b>	
Redirect Serial Ports	Makes local serial ports available in a session. <sup>(1)</sup>
Redirect Drives	Makes local drives available in a session. <sup>(1)</sup>
Redirect Printers	Makes your local printer available in a session.
Redirect Sound	Allows audio played in your session to play locally. <sup>(1)</sup>
Redirect Smart Cards	Makes your smart card available in a session. <sup>(1)</sup>
<b>Client Control Settings</b>	
Allow client to be closed	Enables your user to close the client (WinTMC program).
Allow client to be sized	Enables your user to resize the client.
Always maintain monitor connection	Keeps the monitoring connection active when WinTMC is closed to allow shadowing. Clear this checkbox to release the WinTMC license when the WinTMC program is closed but denies shadow access.
Show display clients as separate windows	Displays multiple Display Clients as separate windows rather than in one window shell.
<b>Experience Settings</b>	
Show desktop background	Enables your user to select a Windows Desktop Background. If not selected, the background is a solid color.
Show window contents while dragging	Allows the window contents to be shown while the window is being dragged.

Setting	Description
Show menu/window animations	Enables menu/window animations on the client.
Show themes	Enables your user to select a Windows Theme.
Disable NLA	Disables the user of Network Level Authentication for the client.

(I) Does not work when you connect to a Remote Desktop Server running Windows 2000 or earlier.




These functions may be denied by user policies or Remote Desktop Server configuration. Check the Microsoft Local Policy, Group Policy, and Remote Desktop Services Configuration.

### MultiMonitor WinTMC

ThinManager supports MultiMonitor for WinTMC if the PC runs Windows on multiple video cards. If the PC successfully runs multiple monitors on the host OS, then WinTMC can run MultiMonitor on up to five monitors.

**Figure 404 - MultiMonitor - Enable MultiMonitor**



MultiMonitor requires the use of Display Clients.

1. Check Use Display Clients to enable Enable MultiMonitor.
2. To configure a WinTMC client for MultiMonitor use, check Enable MultiMonitor.
3. Click Next.

The Terminal Configuration Wizard displays the MultiMonitor Video Settings page, Monitor Layout page, and Display Client Selection page as it does for thin clients.

### WinTMC Modules

WinTMC clients cannot use the ThinManager modules because they are running Windows locally. Touch drivers, sound drivers, printers, and so on

must be installed through the local Windows operating system instead of relying on ThinManager modules.

## Mobile Devices

ThinManager supports Microsoft tablets with WinTMC, Apple iPads and iPhones with iTMC, and Android devices with aTMC.

Apple iPad 2 is supported, but Bluetooth requires iPad 4.


Currently, ThinManager supports Android 5.0 and higher.

### Configure an iPad in ThinManager

A configuration needs to be created in ThinManager so that the mobile device can join the system as a Terminal.

1. Open ThinManager and click the Terminal icon to show the Terminals branch of the tree.

**Figure 405 - ThinManager Terminal Configuration Wizard**




2. Right-click on the Terminals branch and choose Add Terminal.

The Terminal Configuration wizard appears.

3. Type the name for your mobile device in the Terminal Name field and click Next.

The Terminal Hardware page appears.

**Figure 406 - Terminal Hardware Page**


**Terminal Hardware**  
Select the manufacturer and model of this terminal.

Use this to configure the type of hardware for this terminal.

Make / OEM: Apple  
Model: iOS Device  
OEM Model: iOS  
Video Chipset: UNKNOWN

Terminal Firmware Package: Model Default  
Terminal will run Package 7.

Terminal ID and IP Address


Terminal ID: None

Clear  
Edit

< Back Next > Finish Cancel Help

4. Choose Apple/iOS Device from the pull-down menus for the make and model of hardware.
5. Click Next.

The Terminal Mode Selection page appears.

**Figure 407 - Terminal Mode Selection Page**


**Terminal Mode Selection**  
Select the operating modes for this terminal

Terminal Mode

☐ Enable Relevance User Services  
☐ Enable Relevance Location Services  
☐ Enable MultiMonitor  
☐ Enable MultiStation


< Back Next > Finish Cancel Help

An iPad can run as a traditional client and have an application sent to it without using Relevance.

- 6. Check Enable ThinManager User Services and Enable Location Services to control content by user permission or location.
- 7. Click Next.

The Relevance Options page appears, which allows you to assign a location to the iPad. You may not want to assign the iPad to a location, but have it interact with different locations.

Figure 408 - Relevance Options Page



The Relevance Options page allows you to enable various Resolver types. Check the ones you want to use from the iPad.

Setting	Description
<b>Enabled Resolver Types</b>	
Enable QR Code Location Ids	Allows the scanning of a QR code to determine the location.
Enable Bluetooth Locations	Allows the use of Bluetooth beacons to determine the location.
Enable GPS Locations	Allows the Global Positioning System of the mobile device to determine the location.
Enable Wi-Fi Locations	Allows the signal strength of Wi-Fi access points to determine the location.


Each method selected requires configuration to associate a location with the Resolver data.

- 8. Click Next.

The Mobile Device Options page appears, which has several settings that control the user experience on mobile devices.



**Figure 409 - Mobile Device Options**



This page allows you to disable features normally displayed in the mobile apps.

9. Complete the Mobile Device Options page per these descriptions.

Setting	Description
<b>Toolbar Buttons</b>	
Show Scan Data Button	Clear this checkbox to hide the Scan Data button.
Show Scan Resolver Button	Clear this checkbox to hide the Scan Resolver button.
Show User Login Button	Clear this checkbox to hide the User Login button.
<b>Sound Options</b>	
Play Location Sounds	Plays a sound when a location is entered.
Play User Login Sounds	Plays a sound when the user logs in as a TermSecure or ThinManager user.
<b>User Interface Settings</b>	
Show Zoom Map	Clear this checkbox to hide the screen map while zooming.
Show Toolbar	Clear this checkbox to hide the app toolbar.
Allow Exit to ThinManager Server List	Clear this checkbox to prevent the user from leaving the app to switch ThinManager Servers.
Allow Terminal to sleep	Clear this checkbox to keep a tablet from going into sleep mode.


10. Complete the wizard as you would for any other thin client.

### *Configure an iPad for ThinManager*


The iPad needs to have the iTMC client installed. The iTMC application can be downloaded from the Apple App Store for free.

1. Go to the Apple App Store.
2. Type ThinManager in the search field.
3. Choose the iTMC application and click Open.

It downloads and installs on your iPad.


**Figure 410 - ThinManager iTMC Icon on iPad**

4. Press the iTMC icon to launch the iTMC program.

**Figure 411 - ThinManager iTMC Configuration Page**


5. Press Add New ThinManager Server at the bottom of the configuration page to add a ThinManager Server connection.

The Primary ThinServer Name or IP Address dialog box appears.

**Figure 412 - ThinManager Server Name or IP Address Dialog Box**

6. Type the IP address of your primary ThinManager Server and click OK.

The Add ThinManager Server page appears.


**Figure 413 - Add ThinManager Server Page**

7. Type the name of the primary ThinManager Server in the Description field.
8. Type the IP address of a secondary ThinManager Server in the Secondary ThinManager Server IP field if you have one.
9. Click Save in the upper-right corner of the page.

You are returned to the Main page.

### *Associate the iPad to the Configuration*

Once the ThinManager Server is defined on the iPad, you must associate the hardware to the iTMC configuration you created.


**Figure 414 - Main Screen with Defined ThinManager Server**

The defined ThinManager Server is displayed on the Main screen.


1. Press the ThinManager Server.

You are connected to that ThinManager Server.

A Pick Replacement page appears, which allows you to choose the newly created Terminal configuration or launch the Terminal Configuration Wizard when you click Create New Terminal.


**Figure 415 - Pick Replacement**

2. Press your newly defined Terminal to choose the configuration you created for the iPad.

**Figure 416 - iTMC Client Session**


Once the iTMC client connects, the display client assigned in ThinManager is launched.

3. Press the Keyboard icon in the upper-left corner to launch the keyboard.

**Figure 417 - Display Client Session on iPad**


The iPad displays one session at a time.

4. In MultiSession configurations, when you use more than one display client, use a finger swipe to minimize and switch display clients.
5. Press the Cascade icon in the upper-left corner to show all the available display clients and navigate amongst them.

**Figure 418 - Multiple Display Clients**

6. Press a minimized display client to open it in full screen.


### *iTMC iPad Gestures*

**Figure 419 - Pinch Zoom Gesture**

The iPad program can use multiple figure gestures to control the application.

1. Zoom in by using two fingers to expand the screen.

Figure 420 - Main Menu




The complete list of supported gestures is on the Info page.

2. To open the Info page, press Menu in the upper-right corner to launch the Main Menu, then press Info.

This launches a list of gestures.

Figure 421 - Info Page of the iPad Program



Gestures	Description
Left-click	A tap performs a left-click.
Right-click	A long press performs a right-click.
Left-click and Drag	Pans in the session.
Toggle Keyboard	A two-finger long press hides or reveals the keyboard.
Zoom Session	A two-finger pinch zooms in and zooms out.
Pan Session	A two-finger pan allows you to pan while zoomed in.
Toggle Menu Bar	A three-finger long press hides or reveals the top menu bar.
Next Display Client	A three-finger swipe left moves you to the next display client.
Previous Display Client	A three-finger swipe right moves you to the previous display client.




If your three-finger commands do not work, choose Settings>General>Accessibility and turn off the Zoom feature.

### Close the iTMC App

1. Double-click Home and swipe the app, or return to the Main Menu, to close the iTMC app.

**Figure 422 - Multiple Display Clients**




Main is displayed when the display clients are minimized.

2. Touch Main.

A dialog box prompts for confirmation of connection termination.

**Figure 423 - Close Application Dialog**



3. Click Yes.

The iTMC connection closes and you are returned to the Main Menu.



## Guided Access on the iPad

Guided Access is a feature that allows the iPad to be locked to a single application. Guided Access can help an administrator control the iPad, which limits users to the iTMC program.




This advice is provided as a service to our users. Please see Apple documentation for implementation.

To turn on Guided Access in the General Settings of the iPad, follow these steps.

1. Open Settings on the iPad.


**Figure 424 - Settings**



2. Under Settings, press General.
3. Under General, press Accessibility.

The Accessibility page appears.

Figure 425 - Accessibility Settings



4. Press Guided Access.

The Guided Access page appears.

Figure 426 - Guided Access Settings



5. Turn on Guided Access.

6. Press Set Passcode.

The Set Passcode dialog box appears.

Figure 427 - Set Passcode



7. Type a four-digit number as the passcode.
8. Type the number again to confirm it.

---

**IMPORTANT** DO NOT FORGET THIS NUMBER. It allows you to turn off Guided Access.

---

9. Press the Home button once to close Settings.

### *How to Use Guided Access*

To use Guided Access, follow these steps.

1. Open the application you want to run exclusively, like iTMC.
2. Click the Home button three times to open the Guided Access control.

**Figure 428 - Guided Access for an Application**

3. Press Start in the upper-right corner.

This restricts the iPad to that application. The user cannot close the application and is restricted to that app.

4. Press the Home button three times to return to the Guided Access control.
5. Press End in the top-left corner to stop Guided Access.

Guided Access is dormant until reapplied.


6. Choose Settings>General>Accessibility>Guided Access and turn off Guided Access to completely turn it off.

## Configure an Android Device in ThinManager

A configuration needs to be created in ThinManager so that the mobile device can join the system as a Terminal.


1. Open ThinManager and click the Terminal icon to show the Terminal branch of the tree.
2. Right-click on the Terminals branch and choose Add Terminal.

The Terminal Configuration Wizard launches.

**Figure 429 - ThinManager Terminal Configuration Wizard**

3. Type the Terminal Name for your mobile device and click Next.

The Terminal Hardware page appears.

**Figure 430 - Terminal Hardware Page**

4. Choose Generic/Android Device from the Make/OEM and Model pull-down menus.
5. Click Next.


The Terminal Mode Selection page appears.

6. Complete the wizard as you would for any other thin client.

### Configure an Android for ThinManager


The Android device needs to have the aTMC client installed. The aTMC application is a free download from the Google Play App Store.

**Figure 431 - aTMC at the Google Play Store**



1. In the Google Play App Store, search for ThinManager and install the aTMC application.


**Figure 432 - aTMC Application on an Android Desktop**



2. Once installed, press the aTMC program to launch it from the desktop icon.

The Add New ThinServer dialog box appears, where your first action is to define the ThinManager Server.




**Figure 433 - Add New ThinServer Dialog Box**

3. Type the ThinManager Server name in the Description field.
4. Type the Primary ThinManager Server IP address in the Primary field.
5. (Optional) Type the Secondary ThinManager Server IP address in the Secondary field.



If you have only one ThinManager Server, you need to click Next to cycle to Done.

**Figure 434 - Add ThinManager Server Dialog Box**

6. Click Add.


The aTMC app shows your ThinManager Server listed.

### *Associate the Android Device to the Configuration*

Once the ThinManager Server is defined on the tablet, associate the hardware to the aTMC configuration you created.


The aTMC Start Screen shows the registered ThinManager Server.

**Figure 435 - aTMC Start Screen**




1. Touch the ThinManager Server to connect.
- The aTMC connects to the ThinManager Server.

**Figure 436 - Connecting Status**




Once the aTMC connects to the ThinManager Server, the Select a Terminal to Replace dialog box appears.



**Figure 437 - Select a Terminal to Replace**

2. Choose an existing Terminal configuration or click Create new Terminal.
  - a. If you click Create New Terminal, a Terminal Configuration Wizard launches on the ThinManager Server that lets you configure the aTMC as a new Terminal.

Once connected, the Android device displays the applications assigned in ThinManager. If the Android client uses MultiSession, then the display clients are shown on tabs at the top of the screen.

**Figure 438 - aTMC Client**

**Notes:**

## ThinManager Users

### Introduction

ThinManager User Services grants and denies access to applications based on permissions and membership in Access Groups.

To activate ThinManager User Services, check Enable ThinManager User Services on the Terminal Mode Selection page of the Terminal Configuration Wizard.

See [ThinManager User Services Introduction on page 321](#) for details.

Location Services is Location-based computing. It does not just send an application to a mobile device, but it is a way to enable the location to determine the content sent to the device. The mobile device allows the user to interact with the location.

To activate Location Services, check Enable Location Services on the Terminal Mode Selection page of the Terminal Configuration Wizard.

See [Location Services on page 413](#) for details.

Location Services has two types of locations: Assigned and Unassigned.

Assigned locations are those that have a Terminal and monitor at the given location, much like traditional computing. Location Services adds additional functions to the location. These functions allow mobile devices to interact with the location and Shadow the Terminal, Clone the applications, or Transfer control of the location to the mobile device.

Unassigned locations are those that lack a permanent Terminal and monitor, and all of the content is sent to the mobile device, which becomes the Terminal.

### ThinManager User Services Introduction

ThinManager User Services, formerly TermSecure, is a ThinManager feature that allows users to use a ThinManager-ready thin client to access user-specific or Terminal-specific Display Clients. ThinManager User Services does not replace the Windows login, but adds an additional layer of security and control to it.

ThinManager User Services has two main functions: hiding applications from unauthorized users and deploying applications to a user at any location.

- With Permission Deployed Applications, you can assign a display client to a Terminal and keep it hidden from users until they log in with the correct Permissions. A user with the proper ThinManager User

credentials is able to reveal and access the hidden application.

An example of how to apply this function is to allow a supervisor to initiate a product change in regard to a recipe program. This belongs to the station on the floor, but you want to prevent operators from initiating the change.

- With Roaming User-specific Applications, you can assign Display Clients to a ThinManager user, and they can get access to their applications from any Terminal in the system. This function can be initiated by either manual login or the use of an authentication device.

Roaming User-specific Applications allow a user to leave one Terminal and log in to a different Terminal and reconnect to their session. Essentially, the session follows the user from Terminal to Terminal.

An example use for this function includes a quality control worker's ability to retrieve reports assigned to them anywhere they log in.

Permission Deployed Applications are controlled with Permissions, which is covered in [Permission-deployed Applications in ThinManager](#).

Roaming User-specific Applications are controlled when the Display Client is added to the ThinManager User configuration. This is covered in [Assign Roaming Display Clients to a ThinManager User on page 343](#).

The ThinManager User Services section is organized into several sections to walk through the process.

Permission-deployed Applications – See [Permission-deployed Applications in ThinManager](#).

- [ThinManager Access Group Creation on page 326](#)
- [Create the ThinManager User without a Windows Account on page 335](#)
- [Add Access Group to a Display Client on page 329](#)
- [Configure Terminals for Location Services on page 331](#)
- [Log On to Location Services on page 339](#)

User-specific Applications – See [Assign Roaming Display Clients to a ThinManager User on page 343](#).

- [Create the ThinManager User via Active Directory on page 345](#)
- Create login strategies. See [Assign Roaming Display Clients to a ThinManager User on page 343](#)
- [Add User-specific Display Clients on page 353](#)
- [Configure Terminals for Location Services on page 331](#)
- [Log On with a ThinManager User Account on page 358](#)

Use of Active Directory to Create ThinManager Users – see [Password and Account Management on page 381](#).

- [Batch Create ThinManager Users using Active Directory OU on page 377](#)

## Permission-deployed Applications in ThinManager


ThinManager User Services can use Access Group Permissions to control access to display clients on a Terminal. Since the display clients belong to the Terminal, they are started with the Terminal's Windows account. The ThinManager user does not need a Windows account to start the session.

The scenario described in this section to explain the concept of Access Groups, Permissions, and ThinManager Users does not have a Windows account tied to it. Window accounts are covered in [Create the ThinManager User via Active Directory on page 345](#).

### Permission-deployed Applications Diagrams


This section is a graphical representation of controlled access to display clients via the Permission tied to Access Groups.

**Figure 439 - Create Access Groups**




See [ThinManager Access Group Creation on page 326](#).

**Figure 440 - Apply Access Groups to Display Clients**




See [Add Access Group to a Display Client on page 329](#).

**Figure 441 - Configure Terminals for Location Services**



See [Configure Terminals for Location Services on page 331](#).

**Figure 442 - Create ThinManager Users**



See [Create the ThinManager User without a Windows Account on page 335](#).

**Figure 443 - Apply Access Groups to ThinManager Users**



See [Create the ThinManager User without a Windows Account on page 335](#).

**Figure 444 - Log In with Access Group Permission Unlocks Display Client**


See [Log On to Location Services on page 339](#).

**Figure 445 - Different Permissions Grant Access to Different Display Clients**

See [Log On to Location Services on page 339](#).

## ThinManager Access Group Creation

Figure 446 - Access Groups on ThinManager Menu Bar




To create a ThinManager Access Group, follow these steps.

1. Choose Manage>Access Groups in the ThinManager menu bar.

The Access Groups dialog box appears.


Figure 447 - Access Groups Dialog Box




2. Click Add.

The Access Group dialog box appears, which lets you define an Access Group.



**Figure 448 - Access Group Dialog Box**

3. Type a name for your Access Group in the Enter Group Name field and click OK.


**Figure 449 - Access Groups Dialog Box**

The newly created Access Group appears in the list on the Access Groups dialog box, available for use to grant or deny access to display clients.

Windows Security Groups can be added as Access Groups in a domain.

To add Windows Security Groups as Access Groups, follow these steps.


1. Click Add on the Access Groups dialog box.
2. The Access Group dialog box appears.

**Figure 450 - Access Group Dialog Box**

3. Click Select Windows Security Group.

The Select Security Group to Add dialog box appears, which displays the Active Directory tree.


Figure 451 - Select Security Group to Add Dialog Box



4. Highlight the desired Windows group and click OK.

The Windows security group is populated to the Enter Group Name field of the Access Group dialog box.


Figure 452 - Access Group Dialog Box



5. Click OK.

The Windows Security Group is added to the list on the Access Groups dialog box, and it is now available for use to grant or deny access to display clients.

Figure 453 - Windows Security Group as Access Group



### Add Access Group to a Display Client


You must add the Access Group to the Display Client that you want to hide from unauthorized users. This example uses Form01 and Form02.

ThinManager Access Group	Display Client	ThinManager User
Maintenance	Form01	Mike, Bob
Supply	Form02	Steve, Bob

1. Double-click on the desired display client in the ThinManager tree.

The Display Client Wizard appears.


**Figure 454 - Client Name Page**



2. Click Permissions


The Permissions dialog box appears.

**Figure 455 - Display Client with Permissions Dialog Box**




Display clients are members of the Unrestricted group by default.

- Highlight Unrestricted in the Member Of list and click the left arrow to remove it from the list.
- Highlight the desired Access Group and click the right arrow to add the Access Group to the Member Of list. A display client can have several Relevance Access Groups added to it.

**Figure 456 - New Group Membership**

The Permissions dialog box shows the Relevance Access Group membership.

- Click OK to accept the change.
- On the Client Name page, click Finish to close the Display Client Wizard and accept the changes.

**Figure 457 - Display Client Configuration Properties**

- Highlight the display client in the Display Clients tree and click the Configuration tab to quickly view Access Group membership. Scroll

down to the bottom of the Configuration tab to see Access Group membership.

Figure 457 shows that this process was repeated to assign Maintenance to Form01.


## Configure Terminals for Location Services

Each Terminal can be configured to allow ThinManager logins.

1. Double-click on a Terminal in the ThinManager tree.

The Terminal Configuration Wizard appears.

**Figure 458 - Default Terminal Permissions**




By default, Terminals are members of the Unrestricted Access Group, which allows any user to use the Terminal. Leave it this way unless you want to require a ThinManager login to allow any access at all.



Setting an Access Group in Permissions for a Terminal locks users out of the Terminal until they log in with a ThinManager User account.

Access is configured on the Terminal Mode Selection dialog box.

**Figure 459 - Terminal Mode Selection**


2. Check Enable Location Services to enable Location Services logins on the Terminal.



You must use Display Clients with Location Services.

You may use ThinManager User Services in combination with MultiMonitor and/or Location Services.

3. Click Next until the Display Client Selection page appears.

**Figure 460 - Display Client Selection**

4. Add the display clients to the Terminal.

In [Figure 460](#), HMI\_1 is Unrestricted, Form01 is restricted to Maintenance, and Form02 is restricted to Supply.


5. Click Next until the Terminal Interface Options page appears.

When Enable Location Services is checked on the Terminal Mode Selection page (see [Figure 459 on page 332](#)), a Main Menu Options button is displayed on the Terminal Interface Options page.

6. Click Main Menu Options.

The Main Menu Options dialog box appears, which configures the Location Services Login Menu.


Figure 461 - Terminal Interface Options Page



Setting	Description
Allow reboot/restart	Adds Reboot and Restart to the menu.
Show Main Menu on Selector	Adds the Location Services Main Menu to the Display Client pull-down menu.
Show Virtual Keyboard	Shows a virtual keyboard to the login process. Use to display an on-screen keyboard for touch screens.

7. Click OK to accept the changes.

Figure 462 - Pin Pad Options Dialog Box






The Pin Pad Options dialog box allows you to configure the PIN pad when using a Personal Identification Number instead of a password.

Setting	Description
Reverse Pin Pad Button Order	Changes the PIN pad from 1-2-3 on the top row, like a phone, to 7-8-9 on the top row, like a calculator.
Pin Pad Size	Sets the size of the PIN pad as a percentage of the screen size.

8. Click Next.

The Hotkey & Button Configuration page appears.

**Figure 463 - Hotkey & Button Configuration Page**



When Enable Location Services is checked on the Terminal Mode Selection page (see [Figure 459 on page 332](#)), a Main Menu hotkey action is displayed in the Terminal Hotkeys section of the Hotkey & Mouse Button Configuration page. This allows you to set a keyboard hotkey to launch the Location Services menu.

9. Click Finish to apply the changes.
10. Reboot the Terminal after changes are made.

## Create the ThinManager User without a Windows Account


The ThinManager User Configuration Wizard is launched from the ThinManager Users branch of the ThinManager tree.

1. Click ThinManager Users at the bottom-left of the ThinManager tree.

The ThinManager Users tree appears.

2. Right-click on the ThinManager Users branch and choose Add User.

The ThinManager User Configuration Wizard appears.

**Figure 464 - User Branch of the ThinManager Tree**

The first page of the ThinManager User Configuration Wizard is the ThinManager User Information page that creates the ThinManager User account.

ThinManager Users with display clients assigned to them must be tied to a Windows account.

If a ThinManager User does not have a display client assigned to them, and they only use the Permissions to access a display client that belongs to the Terminal, then the user does not need a Windows account.

In this scenario, a Windows account is not needed because the display client belongs to the Terminal and is getting logged in with the Terminal's account. A Permission is applied to the user.

**Figure 465 - ThinManager User Information Page**

**ThinManager User Configuration Wizard**

**ThinManager User Information**  
Enter username, password and permission information.

☐ Active Directory User

ThinManager User Information

User Name: Mike

Password: \*\*\*\*

Verify Password: \*\*\*\*\*

Customize

Password Options PIN Options

Group: [ ] Change Group

Copy Settings

☐ Copy Settings from another User Copy From

Permissions

Password and Verify Password do not match.

< Back Next > Finish Cancel Help

3. To create a ThinManager User that is not an Active Directory user, first, clear the Active Directory User checkbox.
4. Type a name in the User Name field.
5. Type a password into the Password and Verify Password fields.

A dialog box appears if the passwords do not match.

6. Click Permissions.

The Permissions dialog box appears.

**Figure 466 - Permissions Dialog Box**

**Permissions**


TermSecure Access Groups

Available	Member Of
Foremen	Maintenance
Quality	
Supply	
Technicians	

OK

7. To add your Relevance Access Group to your created user, double-click on the Access Group in the Available list to move it to the Member Of list.

Figure 467 - Multiple Access Groups



A ThinManager User can be a member in multiple Access Groups.

- 8. Click OK button to accept the changes.

These are the only settings needed for a ThinManager User to unlock hidden applications: a ThinManager User name and membership in a Relevance Access Group. The wizard has other settings that are described in [ThinManager Configuration Wizard on page 350](#).


Location Services Results

Use the information in this table to follow the example in [Figure 468](#).

Relevance Access Group	Display Client	ThinManager User
Maintenance	Form01	Mike, Bob
Supervisor	Form02	Steve, Bob

The OperatorWorkstation is using Location Services with the unrestricted HMI\_1 display client and the restricted Form01 and Form02 display clients.

Figure 468 - ThinManager Shadow of Thin Client Example



The example in [Figure 468](#) shows the ThinManager tree and the shadowed display of the thin client.

- The Terminals tree shows four display clients assigned to OperatorWorkstation. The lightning bolt indicator for the hidden display clients are red to show that it does not have a connection. Only HMI\_1 and RDS1 are visible on the Terminal because they are unrestricted.
- [Figure 468](#) shows the group selector in the shadow and displays the unhidden display client in the selector.


## Log On to Location Services

To log in a ThinManager User on a Terminal, follow these steps.

1. Go to a Terminal that has Enable Location Services checked on the Terminal Mode Specification page, see [Figure 459 on page 332](#).
2. Log in one of these ways.
  - Open the display client selector pull-down menu and choose Main Menu.
  - Press the CTRL+m hotkey to launch the Main Menu if the hotkey was activated.

The Main Menu is displayed on the Terminal.

**Figure 469 - Location Services Main Menu**




3. Click Log In.

A virtual keyboard is displayed if Show Virtual Keyboard is checked on the Main Menu Options dialog box when the Terminal for Location Services is configured on the Terminal Interface Options page.

Figure 470 - Location Services Log On Screen with Virtual Keyboard



Figure 471 - Location Services Log On




- 4. Type your ThinManager user name in the Enter User Name field and click OK.

Figure 472 - Password Dialog Box




- 5. Type the password in the Enter Password field.
- 6. Click OK.

**Figure 473 - ThinManager with User Logged On**

[Figure 473](#) shows ThinManager User, Mike, logged in to the Terminal, his name in parentheses.


Notice that the group selector on the shadowed Terminal now has the hidden display client showing in the pull-down menu. The lightning bolt icon now shows a connection.

The ThinManager Users tree lists the users.

**Figure 474 - ThinManager Users Tree**

A user that is logged in to a terminal with Location Services shows a different icon and the name of the terminal into which they are logged. In [Figure 474](#), Mike is logged in to OperatorWorkstation.

Figure 475 - Membership in Multiple ThinManager Access Groups



A ThinManager User can be a member of multiple Location Services Access Groups.

In [Figure 475](#), Bob is a member of both Maintenance and Supply. When he is logged in, the display clients for both Maintenance and Supply are displayed. They are hidden when he logs off.

Log Out of Location Services

The ThinManager User can log out by one of these actions.

- Open the Location Services Main Menu on the Terminal and click Log Off
- Right-click on the ThinManager User in the ThinManager tree and choose Logoff User
- Restart or reboot the Terminal that has a ThinManager User logged in

Figure 476 - Main Menu



Button	Description
Switch User	Logs off the ThinManager User and disconnects any sessions from Display Clients assigned to the user. It opens the Login screen for another ThinManager User.
Log Off	Logs off the ThinManager User, and logs off any sessions from Display Clients assigned to the user, and returns to the Terminal's display.




## Assign Roaming Display Clients to a ThinManager User

Location Services can assign a user-specific display client to a ThinManager User. This display client is accessible from any Terminal or location that has been configured with ThinManager User Services. ThinManager Users require a valid Windows account since they log in to a Windows session of their own.


### Roaming Display Clients in Location Services Diagrams

The following is a graphical representation of the process to assign user-specific display clients to a ThinManager user to allow the application to follow the user anywhere they need to go.


#### Create ThinManager Users and Display Clients




#### Assign the Display Client to the ThinManager User




The Display Client is sent to the Terminal where the ThinManager User Logs In



The Display Client follows the ThinManager User



The Display Client Follows the ThinManager User



## Create the ThinManager User via Active Directory

ThinManager Active Directory integration allows a ThinManager User to have its Windows user account drawn from the Active Directory. You allow ThinManager to store the password to streamline password management.

The ThinManager User Configuration Wizard is launched from the ThinManager User branch of the ThinManager tree.


1. Click ThinManager Users near the bottom-left corner of the ThinManager tree.

The ThinManager Users tree appears.

2. Right-click on the ThinManager Users branch and choose Add User.

The ThinManager User Configuration Wizard appears.

**Figure 477 - User Branch of the ThinManager Tree**




The first page of the ThinManager User Configuration Wizard is the ThinManager User Information page that creates the ThinManager User account.

ThinManager Users that have display clients assigned to them must be tied to a Windows account. If a ThinManager User does not have a display client assigned to it, and it only uses the Permissions to access a display client that belongs to the Terminal, then it does not need a Windows account.

This scenario assigns display clients to the ThinManager User so a valid Windows account is needed.

Figure 478 - ThinManager User Information


The image shows the 'ThinManager User Configuration Wizard' window, specifically the 'ThinManager User Information' step. The window has a blue title bar and a close button. Below the title bar, there's a header area with the title 'ThinManager User Information' and a subtitle 'Enter username, password and permission information.' To the right of the subtitle is a ThinManager logo. The main content area is divided into several sections. The first section is 'Active Directory User', which is checked. Below it is a 'ThinManager User Information' section containing an 'AD User Name' text box and a 'Search' button. Below this are 'Customize', 'Password Options', and 'PIN Options' buttons. The next section is 'Group', with a text box and a 'Change Group' button. Below that is a 'Copy Settings' section with a checkbox 'Copy Settings from another User' and a 'Copy From' button. At the bottom of the main content area is a 'Permissions' button. The footer of the window contains navigation buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

The first page of the ThinManager User Configuration Wizard is the ThinManager User Information page that creates the ThinManager User account.

1. Click Active Directory User, which allows you to draw the user account from the Active Directory.
2. Click Search.

The Search for AD User dialog box appears, which begins the Active Directory process.


Figure 479 - Search for AD User Dialog Box

The image shows the 'Search for AD User' dialog box. It has a blue title bar and a close button. The main area contains a large text box for the search query. To the right of the text box is a 'Locations ...' button, which is highlighted with a red rectangle. Below the text box is a 'Filter' dropdown menu set to 'Contains', followed by another text box. To the right of these is a 'Search' button. Below the search area is a table with two columns: 'Name' and 'User Principal Name'. The table is currently empty. At the bottom right of the dialog box are 'OK' and 'Cancel' buttons. The 'Recurse' checkbox is checked.

3. Click Locations.


The Select AD Location to Search dialog box appears from which you can choose a location.

**Figure 480 - Select AD Location to Search Dialog Box**




4. Highlight the AD location you want to select the user from and click OK, which populates the location into the Locations field in the Search for AD User dialog box.

**Figure 481 - Search for AD User - Location Selected**




5. Once the Location has been selected, click Search to populate the user field with users from the highlighted location.

**Figure 482 - Search for AD User Dialog Box - Users**

- Highlight the desired user account from the Active Directory members and click OK.

The user account is populated to the AD User Name field of the ThinManager User Information page. See [Figure 483](#).

**Figure 483 - ThinManager User Information**

- Click Permissions to apply membership in Access Groups. See [Permission-deployed Applications in ThinManager on page 323](#).

8. Click Finish if you only need a Permission applied.

Button/Setting	Description
Customize	Launches the User Description dialog box. See <a href="#">ThinManager User Settings for Non-domain Users on page 363</a> .
Password Options	Choose Manage>Active Directory>Settings on the ThinManager menu to configure in the Active Directory System Settings.
Pin Options	Launches the Pin Maintenance Options dialog box. See <a href="#">ThinManager User Settings for Non-domain Users on page 363</a> .
Change Group	Launches the Choose User Group dialog box. See <a href="#">ThinManager User Settings for Non-domain Users on page 363</a> .
Copy Settings from another User	Allows the user to inherit the properties of another user.
Copy From	Opens the Select User dialog box that allow you to select the user from which to inherit properties.

9. Click Next if you want to apply user-specific display clients.

**Figure 484 - Active Directory Password Page**


Setting	Description
<b>Active Directory Password</b>	
Allow ThinManager to store password	Allows ThinManager to store the Active Directory password in an encrypted form. Clear the checkbox for ThinManager to require a password each time the session logs on.
Password	Type the password.
Verify	Checks with Active Directory to validate the password.
Re-Sync Account	Sends the typed password to the Active Directory.
<b>Password Maintenance</b>	
Allow ThinManager to rotate password	Check to allow ThinManager to update the Active Directory password per the schedule you set.
Use System Defaults	Uses the system defaults set at Manage>Active Directory>Settings.
Minimum Password Length	Sets the minimum amount of characters the password must contain to be valid.
Maximum Password Length	Sets the maximum amount of characters the password must contain to be valid.
Rotate Password every <i>n</i> days	Sets the number of days between scheduled password changes. This setting is propagated from the Password Maintenance Options dialog box when Force User to change password periodically is checked.

If Allow ThinManager to store password is checked, then you can have the Windows password stored in ThinManager, which allows a fingerprint scan to send the Windows password automatically for authentication.

Check Allow ThinManager to store password to use the system defaults, or clear the Use System Defaults checkbox to customize the password settings.


10. Type the user password in the Password field and click Verify to check your password against the Active Directory.
  - a. If the password is incorrect, a dialog box appears to indicate account information is not valid.

**Figure 485 - Account Verify Dialog - Not Valid**



- b. If the password is correct, the dialog box appears to show a positive result.

**Figure 486 - Account Verify Dialog - Valid**



11. Click OK.
12. Click Next on the Active Directory Password page.

The Card/Badge Information page appears.

## ThinManager Configuration Wizard

The next page in the ThinManager User Configuration Wizard is the Card/Badge Information page.



Figure 487 - Card/Badge Information

ThinManager User Configuration Wizard

**Card / Badge Information**  
Enter card/badge information if user has one.

Login Methods

Card / Badge Login


☐ This user will use a card or badge to log in

Enter Card/Badge ID number

☐ Prompt for Password

☐ Prompt for PIN

Biometric Login



☐ Prompt for Password

☐ Prompt for PIN

Manual Login

☒ Prompt for Password

☐ Prompt for PIN

< Back   Next >   Finish   Cancel   Help

You can tie a ThinManager User to an HID card and validate with a card scan, or you can associate a user fingerprint to the account and have a fingerprint scan validate the user.

These methods are covered in [Card Readers and Fingerprint Scanners on page 393](#).


1. Check Prompt for Password or Prompt for Pin, as a secondary credential, for the Card/Badge Login, Biometric Login, or Manual Login.

Setting	Description
Prompt for Password	If checked, requires the user to enter a password.
Prompt for Pin	If checked, requires the user to enter their PIN.

2. Click Next to continue.

The Resolver Selection page appears.

Figure 488 - Location Resolver




Setting	Description
Prompt for Password	If checked, requires the user to enter a password.
Prompt for Pin	If checked, requires the user to enter their PIN.

ThinManager allows a Resolver to pass the specific user’s credentials for a login.

- 3. Click Add.

The Choose a Location Services Resolver dialog box appears.

Figure 489 - Choose a Resolver Dialog



- 4. Choose the resolver from the Resolver Name pull-down menu.
- 5. Choose User Login from the Choose Action pull-down menu.
- 6. Click OK to apply the resolver.

The user logs in when the resolver is activated.


- 7. Click Next to continue.

The Display Client Selection page appears.

### Add User-specific Display Clients

Roaming applications require that display clients are assigned to individuals.


**Figure 490 - Display Client Selection Page**



The Display Client Selection page has one setting, Add User-specific Display Clients?

Setting	Description
Yes	User can be assigned display client of their own that they can access from any Terminal that has Location Services enabled. You can also assign the user Permissions to let them access hidden applications.
No	User is able to access display clients that belong to the Terminal they log in to only. Use with Permissions to grant access to applications hidden with Access Group Permissions.

8. Click Next to continue.

**Figure 491 - Display Client Specification Page**

The Display Client Specification page allows Display Clients to be assigned to the ThinManager User if Add User-specific Display Clients is set to Yes.

9. Move a Display Client that you want the ThinManager User to use from the Available Display Clients list to the Selected Display Clients list. Use the Right Arrow to move a highlighted Display Client, or double-click a display client to move it.
10. To add a new Display Client, click Edit Display Clients to launch the Display Client Wizard. See [Remote Desktop Services Display Clients on page 123](#) for details.
11. Click Next to continue.

**Figure 492 - Terminal Interface Options**

The screenshot shows the 'Terminal Interface Options' window within the 'ThinManager User Configuration Wizard'. The window has a title bar with the wizard's name and a close button. Below the title bar, the title 'Terminal Interface Options' is followed by the instruction 'Select the group selector and main menu options that will be available on the terminal.' and a ThinManager logo. The main content area is divided into two sections: 'Display Client Selection Options' and 'Main Menu Options'. The first section contains a list of checkboxes: 'Use Terminal Settings' (checked), 'Show Selector on Terminal' (checked), 'Enable Tiling' (unchecked), 'Screen Edge Display Client Selection' (unchecked), and 'Allow Display Clients to move to/from screen' (unchecked). To the right of these checkboxes are two buttons: 'Selector Options' and 'Tiling Options'. The second section, 'Main Menu Options', contains a single button labeled 'Main Menu Options'. At the bottom of the window is a navigation bar with five buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

The Terminal Interface Options page sets the menus and hotkeys for the ThinManager User so a Terminal using MultiSession needs to have a method to switch between sessions. This is similar to the page in the Terminal Configuration Wizard.


Group Selector Options allow on-screen switching of sessions.

Setting	Description
Use Terminal Settings	Check to let the ThinManager User inherit the properties that are configured for use with the Terminal.
Show Group Selector on Terminal	Check to display an on-screen pull-down menu that can be activated by mouse.
Enable Tiling	Check to allow the sessions to be tiled so that the user can make a visual selection of the desired selection.
Screen Edge Group Selection	Check to activate a feature that switches windows if the mouse is moved off screen.
Allow Display Clients to move to/from screen	Check to give the user the ability to move display clients from screen to screen.
Selector Options	Launches the Group Selector Options dialog box.
Tiling Options	Launches the Tile Options dialog box.
Main Menu Options	Launches the Main Menu Options dialog box, which allows configuration of the Relevance Main Menu.

12. Select the Next button to continue.

The Terminal Hotkey Options page appears.

Figure 493 - Terminal Hotkey Options



Terminal Hotkeys on the Terminal Hotkey Options page allows the selection of keyboard combinations that allow switching between sessions. This is similar to the page in the Terminal Configuration Wizard.

Setting	Description
Use Terminal Settings	Check to let the ThinManager User inherit the properties that were configured for use with the Terminal. Clear the checkbox to let the user receive the settings as configured for them.
Mouse Button Mapping	Click to open the Mouse Button Mapping dialog box, which allows functions to be assigned to mouse buttons. See <a href="#">Figure 265 on page 202</a> .

13. Click Next to continue.

The User Options page appears.

Figure 494 - User Options

ThinManager User Configuration Wizard

User Options

Select options for this user.

Log In / Log Out Options

Inactivity Timeout

120

seconds

Reset Sessions at Logout

Activate Display Client at Log In

User Schedule

Set Schedule

Schedule

Terminal Effects

Enable Terminal Effects

Shadowing

Allow terminal to be shadowed

YES

Allow Interactive Shadow

< Back

Next >

Finish

Cancel


Help

The User Options page has a few options for the user experience.

Setting	Description
<b>Log In/Log Out Options</b>	
Inactivity Timeout	Location Services logs a ThinManager User off of the Terminal after this much inactive time has passed.
Reset Sessions at Logout	Check to log off a session when the ThinManager User logs off.
Activate User Group at Log In	Check to display the ThinManager User's first Display Client when the user logs in to the Terminal.
<b>User Schedule</b>	
Set Schedule	Check to enable Schedule.
Schedule	Click to launch the Event Schedule dialog box and allow a schedule to be created for Terminal events.
<b>Terminal Effects</b>	
Enable Terminal Effects	Check to allow the use of Terminal Effects, which currently includes sliding Windows and message rollups.
<b>Shadowing</b>	
Allow Terminal to be shadowed	<div>Allows the configuration of these Shadowing Options.</div> <ul style="list-style-type: none"><li>No - Prevents the ThinManager Users from being shadowed.</li><li>Ask - Displays a message dialog box that prompts for a positive response before the shadow is allowed.</li><li>Warn - Displays a message dialog box, which alerts the Terminal that it is to be shadowed, but does not require a positive response before the shadow is allowed.</li><li>Yes - Allows shadow to occur without warning or recipient input.</li></ul>
Allow Interactive Shadow	Allows members with Interactive Shadow privileges to shadow this ThinManager User. Click the Shadow tab on the Details pane to initiate the shadow. Clear this checkbox to prevent shadowing from within ThinManager.

14. Click Finish to complete the configuration.

The ThinManager User tree shows the display clients assigned to the user.

**Figure 495 - ThinManager User with User-Specific Display Clients**


## Log On with a ThinManager User Account

To log in a ThinManager User on a Terminal, go to a Terminal that has Enable Location Services checked on the Terminal Mode Specification page.

Follow these instructions to log in.

1. Open the display client selector pull-down menu and choose Main Menu.
2. Press CTRL+m to launch the Main Menu if the hotkey was checked.


The Main Menu is displayed on the Terminal.

**Figure 496 - ThinManager Console with a Single Display Client on Terminal**

The Terminal tree shows the Terminals and display clients assigned to the Terminals.



**Figure 497 - Location Services Main Menu**



3. Click Log In on the Main Menu dialog box.

**Figure 498 - Location Services Log On Screen with Virtual Keyboard**



A virtual keyboard is displayed if Show Virtual Keyboard was checked on the Main Menu Options dialog box when you configured the Terminal for Location Services on the Terminal Interface Options page. See [Figure 461 on page 334](#).


**Figure 499 - Location Services Log On Dialog Box**



4. Type your ThinManager User Name and click OK.

The Password Dialog box appears.


Figure 500 - Password Dialog



5. Type the password and click OK.


If the user has valid Windows credentials, the user is logged in.

Figure 501 - ThinManager User Logged On




The Terminal displays the name of the ThinManager User in parentheses. [Figure 501](#) shows Anna logged in to the Terminal.

The group selector on the Terminal shows the ThinManager User's display client in the pull-down menu selector. Now, the lightning bolt icon shows a connection.

**Figure 502 - ThinManager User Logged On**

When a ThinManager User logs off from a Terminal, the sessions disconnect by default and remain in an idle state on the Remote Desktop Servers.

If the ThinManager User logs in from another Terminal, then Location Services connects the user to their session, and the sessions are displayed at the new Terminal.

**Figure 503 - ThinManager User Tree**

The ThinManager Users tree lists the users.

A user that is logged in to a terminal with Location Services shows a different icon as well as the name of the terminal. Adam Brown is logged in to 3\_Terminal in [Figure 503](#).

## Log Out of Location Services

The ThinManager User can be logged out by one of these methods.

- Open the Location Services Main Menu on the Terminal and click Log Off.
- Right-click on the ThinManager User in the ThinManager tree and choose Logoff User.
- Restart or reboot the Terminal that has a ThinManager User logged in.
- The Inactivity Timeout set on the User Options page is reached.

Figure 504 - Main Menu




Setting	Description
Switch User	Click to log off the ThinManager User and disconnect any sessions from Display Clients assigned to the user. The Log On dialog box for another ThinManager User appears.
Log Off	Click to log off the ThinManager User and any sessions from Display Clients assigned to the user and return to the Terminal's display.

Roaming Applications for Non-domain Users

Each ThinManager User who has their own display client assigned must be tied to a Windows User account. When a user is created from the Active Directory, the ThinManager User account is the Windows user account. When you create a ThinManager User who is not from the domain, you have a few options to assign the Windows account.

Figure 505 - Non-Active Directory ThinManager User



Clear the Active Directory User checkbox to create a ThinManager User who is not in the Active Directory.

Button	Description
Customize	Click to launch the User Description dialog box.
Password Options	Click to launch the Password Maintenance Options dialog box.
PIN Options	Click to launch the PIN Maintenance Options dialog box.
Change Group	Click to launch the Choose User Group dialog box.
Permissions	Click to launch the Permissions dialog box.


### ThinManager User Settings for Non-domain Users

In [Figure 505](#), the ThinManager User Information page has several buttons that configure user settings.

1. Click the Customize button.

The User Description dialog box appears, which allows a verbose description to be associated with the user account that is displayed in the Configuration detail pane.

**Figure 506 - User Description Dialog Box**




Setting	Description
User Description	Allows you to type a verbose description to be added to the user account.
Add	Click to open the Custom Variables dialog box.

Custom variables allow for the creation of a single display client with a custom variable as part of the path. Each user, Terminal, or location has specific data in the custom variable to modify the content that the display client delivers, which allows one display client to do the work of many.

2. Click Add.

The Custom Variable dialog box appears, which allows you to add a custom variable. A custom variable can be used to pass information to the AppLink display client or to the TermMon ActiveX that you embed in your application.

Figure 507 - Custom Variable Dialog Box


A dialog box titled "Custom Variable" with a close button (X) in the top right corner. It contains two text input fields: "Name" with the value "Custom Variable" and "Value" with the value "And its value". Below the "Value" field is a checkbox labeled "Hide Value" which is currently unchecked. At the bottom right are "OK" and "Cancel" buttons.

Setting	Description
Name	Type the name of the custom variable.
Value	Type the value or content to be assigned to the custom variable.
Hide Value	Check to obscure the custom variable value. Clear this checkbox to show the value.

3. On the ThinManager User Information page, click Password Options.

The Password Maintenance Options dialog box appears.

Figure 508 - Password Maintenance Options

A dialog box titled "Password Maintenance Options" with a close button (X) in the top right corner. It contains four sections: "Password Complexity Requirements" with a "Minimum Password Length" field set to "0" and three checkboxes for "Must contain numbers", "Must contain upper and lower case letters", and "Must contain symbols"; "Password Maintenance" with three checkboxes for "Allow User to change password", "Force User to change password at next login", and "Force User to change password periodically", followed by a field "User must change password every" set to "10" days; "Account Lockout Policy" with "Failed Login Attempts Threshold" set to "10" and an "Unlock" button, and "Account Lockout Period" set to "10" minutes; and "Authorization Caching" with a text box "Cache authorization for 10 minutes" and a "Change" button. At the bottom are "OK" and "Cancel" buttons.

The Password Maintenance Options dialog box allows user password configuration.


Setting	Description
<b>Password Complexity Requirements</b>	
Minimum Password Length	Type the length requirement.
Must contain numbers	Check to add the number requirement to the password.
Must contain symbols	Check to add the symbol requirement to the password.
Must contain upper and lower case letters	Check to add the mixed-case requirement to the password.
<b>Password Maintenance</b>	
Allow User to change password	Check to allow a user to change the password. Clear the checkbox to prevent a password change by the user.

Setting	Description
Force User to change password at next login	Check to prompt the user to change their password at the next login.
Force User to change password periodically	Check to prompt the user to change their password at the interval set in the User must change password every ___ days field.
User must change password every ___ days	Type the interval for password changes.
<b>Authorization Caching</b>	
Change	Click to open the Authorization Cache dialog box.

4. Click Change.

The Authorization Cache dialog box appears.


**Figure 509 - Authorization Cache Dialog Box**



Setting	Description
Cache Authorization for _ minutes	Type the time interval for which the password to be cached. A user enters their password once, and it is cached and provided for the duration.
Clear	Click to remove cache authorization for the user and require the user to enter a password.

When a user has a cached password, the Password Maintenance Options dialog box appears with the cache interval indicated.

**Figure 510 - Password Maintenance Options**



5. On the ThinManager User Information page, click PIN Options. See [Figure 505 on page 362](#).

The PIN Maintenance Options dialog box appears, which allows the configuration of a Personal Identification Number, or PIN.

### Figure 511 - PIN Maintenance Options

**PIN Maintenance Options**

**PIN Options**

Minimum PIN Length: 4

Maximum PIN Length: 4

Maximum Sequence Length: 0

Maximum Repeat Length: 0

☐ Use a temporary PIN

Cache authorization is disabled Change

**PIN Maintenance**

Require User to change PIN every 0 days

Require User to change PIN at next login ☐

**User PIN**

PIN:

Verify PIN:

OK Cancel

Setting	Description
<b>PIN Options</b>	
Minimum PIN Length	Type the minimum length requirement for the PIN.
Maximum PIN Length	Type the maximum length requirement for the PIN.
Maximum Sequence Length	Type the maximum length allowed for the creation of the PIN.
Maximum Repeat Length	Type the maximum number of times a digit can be repeated in the creation of a PIN.
Use a temporary PIN	Check to allow use of a PIN for the duration set in the Authorization Cache dialog box, which is launched when Change is clicked on the Password Maintenance Options dialog box. See <a href="#">Figure 510</a> .
Change	Click to toggle cache authorization between enabled and disabled.
<b>PIN Maintenance</b>	
Require User to change Pin every ___ days	Type the frequency with which the PIN needs set.
Require User to change pin at next login	Check to require the user to create a new PIN the next time they login.
<b>User PIN</b>	
PIN	Type the PIN.
Verify PIN	Type confirmation of the PIN.

The PIN Maintenance Options dialog displays the amount of time for which the Temporary PIN is valid.



**Figure 512 - PIN Maintenance Options**

**PIN Maintenance Options**

**PIN Options**

Minimum PIN Length: 4

Maximum PIN Length: 4

Maximum Sequence Length: 0

Maximum Repeat Length: 0

☒ Use a temporary PIN

Temporary PIN is valid for 1 hour, 0 minutes Change

**PIN Maintenance**

Require User to change PIN every: 0 days

Require User to change PIN at next login: ☐

**User PIN**

PIN:

Verify PIN:

OK Cancel

6. Click Change.

The Authorization Cache dialog box appears, where you can set the duration the Temporary Pin.

**Figure 513 - Authorization Cache Dialog Box**

**Authorization Cache**

Cache authorization for: 60 minutes

Clear Authorization Cache for this user: Clear


OK Cancel

7. Type the Cache authorization duration or click Clear to clear Authorization Cache.

8. On the ThinManager User Information page, click Change Group. See [Figure 505 on page 362](#).

The Choose User Group dialog box appears, which allows you to select the ThinManager User group in which to nest the user.


Figure 514 - Choose User Group



9. On the User Information page, click Permissions. See [Figure 505 on page 362](#).

The Permissions dialog box appear.

Figure 515 - Permissions Dialog Box



The user can be granted permissions by moving the desired Access Group from the Available list to the Member Of column.

The ThinManager User Configuration Wizard is the same until the Windows Log In information page.

**Figure 516 - Windows Log In Information Page**

If you chose to assign a display client to the user by selection of the User-specific Display Clients on the Display Client Selection page (see [Figure 490 on page 353](#)), then you must provide a Windows account to start the session.

This page is not displayed if the ThinManager User is selected from the Active Directory.


The Windows Log In Information page provides four session log on options.

Setting	Description
Use Terminal Configuration Login Information	Check to use the Terminal's username and password to log on the ThinManager User automatically to the Remote Desktop Server. Since a different account is used at each Terminal, this does not keep a consistent session for the ThinManager User.
Same as ThinManager User username/password	Check to use the ThinManager User's username and password to log on to the Remote Desktop Server automatically. The ThinManager User username and password must match a Windows User username and password to get authenticated by Windows. If the ThinManager User is selected from the Active Directory, then this is the default behavior.
Use the Username, Password, Verify Password, and Domain fields	The ThinManager User can use an alias username and password to log on to the Remote Desktop Server automatically, which allows you to tie the ThinManager User account to a different Windows account. This allows you to hide the actual Windows account from the user.
Blank Username and Password fields	The ThinManager User can be required to log on to the Remote Desktop Servers manually. To do this, clear the checkboxes and leave the Username, Password, and Domain fields empty. When a ThinManager User logs in with their ThinManager account, they are prompted to enter a valid Windows account and password.

## ThinManager User Groups

ThinManager Users can be organized into ThinManager User Groups, just as Terminals can be organized into Terminal Groups. This section shows the configuration of a ThinManager User Group.

Figure 517 - Add User Group Command



1. Click ThinManager Users at the bottom-left of the ThinManager tree, right-click on the ThinManager Users branch of the tree, and choose Add User Group.

The ThinManager User Group Information page of the ThinManager User Configuration Wizard appears.

**Figure 518 - ThinManager User Group Information Page**


Setting	Description
AD Synchronization Group	Check to access the AD Security Group field.
AD Security Group	Type the name of the Organization Unit to which a user belongs.
Search	Click to select a Security Group to Synchronize.
User Name	Type the user name of your user's login. It can be a unique ThinManager user name, a Windows user name, or one listed in Active Directory.
Password	Type the password for the user. If you are using a Windows account for the ThinManager User, you should use the actual Windows password for automatic login, or leave this field blank for a manual login. If the ThinManager User account is an alias for a Windows account, the password is used as the Location Services password and not the Windows password.
Customize	Click to launch the User Description dialog box and allow custom variables to be applied to the ThinManager User.
Password Options	Click to launch the Password Maintenance Options dialog box, where you can specify password length, complexity, and longevity.
PIN Options	Click to launch the PIN Maintenance Options dialog box, where you can specify the Personal Identification Number length, complexity, and longevity.
Group Setting	Check to apply the setting to all members of the group.
Change Group	Click to launch the Choose User Group dialog box, which allows you to assign the user to a group.
Permissions	Click to apply permissions to the group.

Active Directory Integration allows a Location Services Group to be formed and populated straight from the Active Directory. See [Batch Create ThinManager Users using Active Directory OU on page 377](#).

2. Click Permissions.

The Permissions dialog box appears.


Figure 519 - Permissions Dialog Box



- 3. Highlight the desired permission in the Available list and click the right-facing arrow to move it to the Member Of list.
- 4. Highlight the group and check Also apply to users in group, which applies the permission to all group members.
- 5. Click OK to close and apply.
- 6. On the ThinManager User Group Information page, click Customize.

The User Description dialog box appears, which allows a verbose description to be associated with the user account. The description is displayed in the Configuration detail pane.

Figure 520 - User Description Dialog Box




Setting	Description
User Description	Type a description, which is added to the user account. The text field allows a verbose description.
Add	Click to launch the Custom Variable dialog box to add a custom variable.

Custom variables allow a single display client to be created with a custom variable as part of the path. Each user, Terminal, or location has specific data in the custom variable to modify the content that the display client delivers, which allows one display client to do the work of many.

Additionally, a custom variable can pass specific data to an application through the TermMon ActiveX.

Figure 521 - Custom Variable Dialog Box




Setting	Description
Name	Type the name of the custom variable.
Value	Type the value or content to assign to the custom variable.
Hide Value	Check to obscure the custom variable value. Clear the checkbox to show the value.
OK	Click to accept the changes and close the dialog box.

- 7. On the ThinManager User Group Information page, click Next.

The Display Client Specification page appears.

Figure 522 - Display Client Specification Page



- 8. Double-click the display clients in the Available Display Clients list for the group to move them to the Selected Display Clients list.
- 9. Click Next to continue the group configuration.

The Windows Log In Information page appears.

Figure 523 - Windows Log In Information Page

Setting	Description
Group Setting	Check to apply setting to all members of the group.
Use Terminal Configuration Login Information	Check to allow the ThinManager User to use the terminal credentials for the application.
Same as ThinManager User username/password	Check when a Windows account is used for the ThinManager User account.
Username/Password/Verify Password	These are dimmed because every user needs a unique Windows account. Therefore, a group setting is not allowed.
Domain	Type the domain if domain accounts are used.

The rest of the wizard follows the ThinManager User Configuration Wizard.

10.Click Next to continue or Finish to close and save the settings.



Any member of this group receives the Group Settings. Change a Group Setting and that change affects all members.


Add a ThinManager User to a ThinManager User Group

ThinManager Users can be added to the ThinManager User Group.

- 1. Right-click on the ThinManager Users branch in the ThinManager tree and choose Add User.

The ThinManager User Information page of the ThinManager User Configuration Wizard appears.




**Figure 524 - ThinManager User Information Page**


The screenshot shows the 'ThinManager User Configuration Wizard' window. The title bar says 'ThinManager User Configuration Wizard'. The main heading is 'ThinManager User Information' with the instruction 'Enter username, password and permission information.' Below this, there is a checkbox for 'Active Directory User' which is unchecked. Under the heading 'ThinManager User Information', there are three text fields: 'User Name' (containing 'Ed'), 'Password' (masked with '\*\*'), and 'Verify Password' (masked with '\*\*'). There are three buttons: 'Customize', 'Password Options', and 'PIN Options'. Below these is a 'Group' field (empty) and a 'Change Group' button, which is highlighted with a red rectangle. Under the heading 'Copy Settings', there is a checkbox for 'Copy Settings from another User' (unchecked) and a 'Copy From' button. At the bottom of the main area is a 'Permissions' button. The bottom of the window has navigation buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

2. Type a name for the ThinManager User in the User Name field.
3. Click Change Group.

The Choose User Group dialog box appears.

**Figure 525 - Choose User Group Dialog Box**


The screenshot shows the 'Choose User Group' dialog box. It has a title bar with the text 'Choose User Group' and a close button. On the left, there is a tree view under the heading 'Users' with three items: 'Foremen' (highlighted with a blue selection bar), 'Maintenance', and 'Support'. On the right side of the dialog, there are three buttons: 'OK', 'Cancel', and 'Search'.

4. Highlight your ThinManager User Group and click OK to close the window and accept the changes.

The ThinManager User Group is displayed in the Group field.

Figure 526 - ThinManager User Group Displayed

The image shows the 'ThinManager User Configuration Wizard' dialog box. The title bar says 'ThinManager User Configuration Wizard'. The main heading is 'ThinManager User Information' with the subtitle 'Enter username, password and permission information.' Below this, there is a checkbox for 'Active Directory User' which is unchecked. Underneath is a section titled 'ThinManager User Information' containing three text boxes: 'User Name' with 'Ed' entered, 'Password' with two asterisks, and 'Verify Password' with two asterisks. There are buttons for 'Customize', 'Password Options', and 'PIN Options'. Below this is a 'Group' section with a dropdown menu showing 'Foremen' (highlighted with a red box) and a 'Change Group' button. Underneath is a 'Copy Settings' section with a checkbox 'Copy Settings from another User' (unchecked) and a 'Copy From' button. At the bottom is a 'Permissions' button. The bottom of the dialog has navigation buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

5. Click Finish to accept the configuration.

Once a ThinManager User has joined a group, the user is displayed in the tree under the group.

Figure 527 - Group Membership


The image shows the 'ThinManager v13.0 - RDS1' interface. The top menu bar includes 'Edit', 'Manage', 'Install', 'Tools', 'View', 'Remote View', and 'Help'. Below the menu is a toolbar with buttons for 'Add', 'Delete', 'Lock', 'Find (Ctrl-F)', 'Find Next (F3)', 'Modify', 'Add Group', 'Rename', 'Unlock', and 'Copy'. The main area is divided into two panes. The left pane, titled 'ThinManager Users', shows a tree view with 'ThinManager Users' expanded, revealing a sub-tree with 'Foremen' (highlighted with a red box), 'Ed', 'Maintenance', and 'Support'. The right pane, titled 'Config', shows a table of user attributes. The table has two columns: 'Attribute' and 'Value'. The first section is 'Identification' with rows for 'Name' (Foremen) and 'User Description' (None). The second section is 'PIN Options' with a row for 'PIN Change Interval' (None).

Attribute	Value
<strong>Identification</strong>	
Name	Foremen
User Description	None
<strong>PIN Options</strong>	
PIN Change Interval	None

## Batch Create ThinManager Users using Active Directory OU

You can create ThinManager Users in a batch by either selecting one Windows Security Group or multiple Active Directory organizational units (OU). A user can only reside in one OU, but they can be members in multiple Security Groups. Limit users to a single Security Group to prevent duplicate accounts.


**Figure 528 - Active Directory System Settings**



1. Choose Manage>Active Directory>Settings.

The Active Directory System Settings dialog box appears.

**Figure 529 - Active Directory System Settings Dialog Box**



2. From the Choose AD Synchronization Mode pull-down menu, choose either Organizational Unit or Security Group.

This manual shows the batch creation of ThinManager Users using Active Directory Organizational Units.




Since a user can be in several Windows Security Groups, but only one Organizational Unit, you can only select one Windows Security Group as a ThinManager User Group, but you can add many Organizational Units.

3. Click OK to close.

ThinManager User Groups are defined using the ThinManager User Configuration Wizard.

**Figure 530 - Add User Group Command**



1. Click ThinManager Users at the bottom-left of the ThinManager tree.
2. Right-click on the ThinManager Users branch and click Add User Group.

The ThinManager User Configuration Wizard for the ThinManager User Group appears.

**Figure 531 - ThinManager User Group Information Page**

The figure shows two side-by-side screenshots of the 'ThinManager User Configuration Wizard' window. Both windows have the title 'ThinManager User Configuration Wizard' and a subtitle 'ThinManager User Group Information'. The subtitle also says 'Enter the ThinManager User Group name.'.

The left window shows the 'AD Synchronization Group' checkbox unchecked. Below it, there is a 'Group Name' field with 'User Name' entered. There are also fields for 'Password' and 'Verify Password', and buttons for 'Customize', 'Password Options', 'PIN Options', and 'Group Setting'. At the bottom, there is a 'Group' field with a 'Change Group' button and a 'Permissions' button. The footer says 'Please enter a name' and has navigation buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

The right window shows the 'AD Synchronization Group' checkbox checked. The 'Group Name' field now contains 'AD Security Group'. A red box highlights the 'User Name' field. A 'Search' button is visible next to the 'Group Name' field. The rest of the interface is the same as the left window.

### 3. Check AD Synchronization Group.

The User Name field becomes an Organizational Unit field.


**Figure 532 - ThinManager User Group Information Page**

The figure shows a single screenshot of the 'ThinManager User Configuration Wizard' window. The title is 'ThinManager User Configuration Wizard' and the subtitle is 'ThinManager User Group Information'. The subtitle also says 'Enter the ThinManager User Group name.'.

The 'AD Synchronization Group' checkbox is checked. Below it, there is a 'Group Name' field with 'AD Security Group' entered. A red box highlights the 'Search' button next to the 'Group Name' field. There are also buttons for 'Customize', 'Password Options', 'PIN Options', and 'Group Setting'. At the bottom, there is a 'Group' field with a 'Change Group' button and a 'Permissions' button. The footer says 'Please enter a name' and has navigation buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.


### 4. Click Search.

The Select AD Location to Search dialog box appears, which lists the Organizational Units for the domain that the ThinManager Server is a member.

**Figure 533 - Select AD Location to Search**

5. Highlight the desired Organizational Unit and click OK.


The ThinManager User Group appears in the Organizational Unit field.

**Figure 534 - ThinManager User Group**

6. Select Next.
7. Click Finish

The ThinManager Users Group is created. Depending on the Active Directory size, it may take some time to populate the ThinManager Users group.

Figure 535 - ThinManager Users Group



Once populated, all members of the Organizational Unit appear as members of the ThinManager Users group.

## Password and Account Management


ThinManager has tools to manage domain accounts and passwords.

### Active Directory

#### Manage Accounts Management

The first tool is the Manage Accounts tool.


Figure 536 - Manage Active Directory Accounts



- 1. Choose Manage>Manage Accounts.

The Manage Active Directory Accounts dialog box appears, which lists all the Active Directory accounts that are referenced in ThinManager.

Figure 537 - Password Maintenance Options Dialog Box



- 2. Double-click on an account.

The Password Maintenance Options dialog box appears, where you can have ThinManager manage the account's password.



**Figure 538 - Password Maintenance Options**

3. Check Allow ThinManager to manage password to add the account to the list of managed accounts with which you can use the system defaults.

Clear the Use System Default Password Settings checkbox to customize the password settings.

Setting	Description
Minimum Password Length	The minimum number of characters a password can have.
Maximum Password Length	The maximum number of characters a password can have.
Rotate Password every ___ days	The number of days in which the password must be changed.

4. Click OK to accept the changes, or click Cancel to close and not save.

On the Manage Active Directory Accounts dialog box, the account is displayed as a managed account.

**Figure 539 - Manage Active Directory Accounts**

Username	Managed by ThinManager	Password Synchronized	Last Password
thin01@tmlab.loc	NO	N/A	Fri Mar 30 10
ed@tmlab.loc	YES	NO	Fri Mar 30 10
thin02@tmlab.loc	NO	N/A	Mon Apr 2 0
labuser@tmlab.loc	NO	N/A	Tue Mar 27 1
ThinManager Users	NO	N/A	Must be char
Enterprise Admins	NO	N/A	Must be char
Engineer	NO	N/A	Must be char

### Convert Accounts

Domain accounts that were used in previous versions of ThinManager can be converted to a managed account with the Convert function.

Figure 540 - Legacy Domain Log In





Figure 540 shows a domain account that was entered in an earlier version of ThinManager that did not have Active Directory integration.

Figure 541 - Manage Active Directory Accounts




1. Choose Manage>Manage Accounts.


The Manage Active Directory Accounts dialog box appears.

2. Highlight the legacy account and click Convert.

The Convert Accounts to Managed Accounts dialog box appears.

**Figure 542 - Convert Accounts to Managed Accounts**

3. Highlight the legacy account and click Convert.
4. The Manage Active Directory Accounts dialog box shows that the account is now managed by ThinManager. See [Figure 543](#).

**Figure 543 - Manage Active Directory Accounts**

5. Double-click on a legacy domain account.

The Password Maintenance Options dialog box appears for that account.

Figure 544 - Password Maintenance Options

Password Maintenance Options

☒ Allow ThinManager to manage password

☒ Use System Default Password Settings

Password Complexity Requirements

Minimum Password Length: 20

Maximum Password Length: 60

Password Maintenance

Rotate Password every: 1 days

OK Cancel

6. Check Allow ThinManager to manage password to add the account to the list of managed accounts with which you can use the system defaults.

Clear the Use System Default Password Settings checkbox to customize the password settings.

Setting	Description
Minimum Password Length	The minimum number of characters a password can have.
Maximum Password Length	The maximum number of characters a password can have.
Rotate Password every ___ days	The number of days in which the password must be changed.

7. Click OK to accept the changes or click Cancel to not save and close the dialog box.

A Domain Administrator password is required to synchronize the Active Directory account.

Figure 545 - Synchronize Active Directory Account

Synchronize Active Directory Account

Active Directory Admin Account

Username: [ ]

Password: [ ]

☒ Auto-Generate Password

New Password: [ ]

OK Cancel

8. Enter domain admin credentials.
9. Check Auto-Generate Password to have ThinManager automatically create a password.

Clear the Auto-Generate Password checkbox to enter your own password in the New Password field.

10. Click OK to synchronize the password, or click Cancel to not save it and close the dialog box.

An acknowledgment dialog box appears, which indicates a successful synchronization.

Figure 546 - Password Reset Dialog




*Synchronize Password*

- 1. Choose Manage>Synchronize Passwords.

The Synchronize Active Directory Passwords dialog box appears, which allows the synchronization of passwords for many accounts at once.


Figure 547 - Synchronize Active Directory Passwords



- 2. Click Set Passwords.


The Active Directory Domain Administrator dialog box appears.

Figure 548 - Active Directory Domain Administrator Log In



This action requires a Domain Administrator account.


Figure 549 - Active Directory Domain Administrator Log In



- 3. Type the credentials in the appropriate fields and click OK.

The Synchronizing Passwords progress dialog appears.

Figure 550 - Synchronizing Passwords



- 4. Click OK to close the dialog box.


The selected accounts have their passwords synchronized between ThinManager and the Active Directory.

Settings

Choose Manage>Settings (Active Directory).

The Active Directory System Settings dialog box appears, which contains the settings for the passwords.

**Figure 551 - Active Directory System Settings**



Setting	Description
Password Change Interval	The number of days before the password must be changed.
Minimum Password Length	The minimum number of characters a password can have.
Maximum Password Length	The maximum number of characters a password can have.
Choose AD Synchronization Mode	Use with batch creation of ThinManager Users. You can generate users from one Windows Security Group or multiple Organizational Units.
Synchronize every ___ minutes	Type how frequently ThinManager synchronizes with the Active Directory. Password communication is encrypted for security.
Start Sync Now	Manually start the synchronization between the ThinManager Server and the Active Directory.


## Shortcut Method to Add Access Groups

Quickly add members to Access Groups through the Access Groups Wizard.

1. Choose Manage>Access Groups from the ThinManager menu.

The Access Groups dialog box appears.

Figure 552 - Access Groups Dialog Box




Access groups can be added, deleted, or edited.

- 2. Highlight the desired Access Group and click Edit.

The Access Group dialog box appears.


Figure 553 - Access Group Dialog Box



- 3. Click Edit Members.

The Access Group Members dialog box appears.


Figure 554 - Access Group Members



- 4. Click Terminals, Display Clients, or Users to configure that category and click Add.


The Select ThinManager User dialog box appears with a tree of the configured Users and User groups.



**Figure 555 - Select ThinManager User**

5. Highlight the desired ThinManager User and click OK for each addition.

The Access Group Members dialog box shows the members of the Location Services Access Group.

**Figure 556 - Access Group Members**

6. Highlight the members of the Access Group and click Remove to remove members.

Display Clients and Users can be added by the same process.

## ThinManager User Schedule

ThinManager Users and ThinManager User Groups have a schedule on the User Options page of the ThinManager User Configuration Wizard.

Figure 557 - User Options Page

ThinManager User Configuration Wizard

**User Options**  
Select options for this user.

Log In / Log Out Options

Inactivity Timeout: 120 seconds

Reset Sessions at Logout: ☐

Activate Display Client at Log In: ☐

User Schedule

☒ Set Schedule **Schedule**

Terminal Effects

☒ Enable Terminal Effects

Shadowing

Allow terminal to be shadowed: YES

☒ Allow Interactive Shadow

< Back   Next >   Finish   Cancel   Help

- 1. Check Set Schedule and click Schedule.

The Event Schedule dialog box appears, which lists events for the ThinManager User or ThinManager User Group.


 The Schedule for ThinManager User Groups feature is the same as for individual ThinManager Users. The advantage of the Schedule for ThinManager User Groups feature is that it allows you to apply scheduled events to a whole group of users rather than the requirements to configure each event for each user.

Figure 558 - Event Schedule

Event Schedule

Event Type	Time
Disable User	every Friday at 09:00 PM
Enable User	every Monday at 06:00 AM

Add   Edit   Delete   OK


Setting	Description
Add	Launches a Schedule dialog box, which allows an event to be configured.

Setting	Description
Edit	Allows a highlighted event to be changed.
Delete	Removes a highlighted event.
OK	Accepts changes and closes the Event Schedule dialog box.

2. Click Add.

The Schedule dialog box appears, which has several configuration settings.

Figure 559 - Schedule Dialog Box



Setting	Description
Event Type	Choose an event from the pull-down menu.
Disable User	Prevents a user login through Location Services, or disconnects a session.
Enable User	Allows a user to become active again.
<b>Repeat Interval</b>	
Once Only	Shows a Select Date field for the event.
Weekly/Daily	Shows a Weekly Schedule list for the event to run. The Every Day button selects all the days in the list.
Monthly	Shows a Select Day of Month field for the event.
Yearly	Shows a Select Date field for the event.
Time	Allows the selection of the time that the event should occur.

3. Click OK to close the Schedule dialog box.
4. On the Event Schedule dialog box, click Add to add another event to the Event Schedule or click OK to close the Event Schedule window and return to the Terminal configuration.

Card Readers and Fingerprint Scanners

Card and Badge Configuration for a ThinManager User

ThinManager has the ability to use Prox (proximity) cards for Location Services logins, which requires these actions.

- Add a card reader to the ThinManager-ready thin client

- Add the card reader module to the Terminal configuration
- Associate the card number to the ThinManager User configuration

ThinManager has support for the RF Ideas Inc. serial RDR-6081AK2 pcProx card reader and the USB RDR-6081AKU and RDR-80582AKO pcProx card readers ([www.rfideas.com](http://www.rfideas.com)).


### Configure a Terminal with the Card Reader Module

1. Double-click on the Terminal in the tree.

The Terminal Configuration Wizard appears.


2. Click Next until the Module Selection page appears.

**Figure 560 - Module Selection Page**



3. Click Add.
4. The Attach Module to Terminal dialog box appears.


**Figure 561 - Attach Module to Terminal**



5. Choose Relevance from the Module Type pull-down menu.
  6. Highlight an RF Ideas pcProx Module and click OK.
- Use the RF Ideas pcProx Module for serial devices
  - Use the RF Ideas pcProx USB Module for USB devices
7. Click OK to attach the module to the Terminal.

The module can be configured once it is attached to a Terminal.


**Figure 562 - Module Selection**



8. Highlight RF Ideas pcProx Module and click Configure.

The Module Properties dialog box appears.

**Figure 563 - Serial pcProx Card Module Properties**



The RF Ideas Serial pcProx Module has parameters that can be configured.

Setting	Description
Port	Choose the port on which the serial RF Ideas pcProx card reader is installed.
Number of Data Bits	Different cards use different numbers of data bits in their format. Sets the number of data bits to match that used by the card as an identifier. The choices are 26, 37, or Raw.
Use Facility Code	Set to Yes to add the card's Facility Code to the Card/Badge ID number.
Allow Manual Logon	Set to Yes to allow a ThinManager User to log in to a Terminal without a ThinManager ID device. Set to No so ThinManager users must use a ThinManager ID device to log in.
Prompt for Password	Set to Yes to require a ThinManager User to enter their password for access even if the password is configured in ThinManager.
Zero Pad Facility Code and ID	Adds a leading 0 to the Facility Code if needed.



The USB RDR-6081AKU does not have the Facility Code option. Do not use the Facility code on serial pcProx card readers if you are using a mix of both USB RDR-6081AKU and RDR-6081AK2 serial devices.

Figure 564 - USB pcProx Card Module Properties

The RF Ideas USB pcProx Module has parameters that can be configured.

Setting	Description
Model	Choose from these different USB pcProx card readers. RDR-6081AKU RDR-6011AKU RDR-80582AKO RDR-80082AKO
Mode	Choose from ThinManager, Wedge, and TermMon modes.
ThinManager Mode	Allows the card to be used with ThinManager as a login device.
Wedge Mode	Allows the data to be sent to the session as a character string.
TermMon Mode	Allows the data to be sent to the TermMon ActiveX.
Bits in ID Number (AKO Only)	Different cards use different numbers of data bits in their format. Sets the number of data bits to match that used by the card as an identifier.
Bits in Facility Code (AKO Only)	Different cards use different numbers of data bits in their format. Sets the number of data bits of the Facility Code.
Zero Pad Facility Code and ID (AKO Only)	Adds a leading zero to the Facility Code if needed.

Setting	Description
Allow Manual ThinManager Logon	Set to Yes to allow a ThinManager User to log in to a Terminal without a ThinManager ID device. Set to No so ThinManager users must use a ThinManager ID device to log in.
Prompt for ThinManager Password	Set to Yes to require a ThinManager User to enter their password for access even if the password is configured in ThinManager.
Expose Card ID to TermMon ActiveX Control	Allows the card data to be sent to the TermMon ActiveX without incorporating ThinManager.

To configure a parameter, follow these steps.

1. Highlight the parameter.
2. Change the value.
3. Click Done to accept the changes.

Once the Terminal has the module added, restart it to apply the changes.

4. On the Module Selection page, click Finish.

The Terminal Configuration Wizard closes.

5. Right-click on the Terminal in the ThinManager tree and choose Restart.


### *Configure ThinManager for Automatic User Configuration*

A card reader can be used to associate cards with ThinManager Users using wizards.

1. Choose View>Options from the ThinManager menu.

The Options dialog box appears.

**Figure 565 - Options Dialog Box**



2. Check Display “Create New User” dialog for unknown users.
3. Click OK to accept the change.

Now, when an unknown ID device (USB key or ID card) is read by a Terminal, the ThinManager User Configuration Wizard appears. Also,

when a new ID is scanned or an undefined USB key is inserted, the Enter Card/Badge ID number is automatically populated in the ThinManager User Configuration Wizard.


### *Automatically Apply the Card to a Configuration*

Once ThinManager has Display “Create New User” dialog for unknown users checked, a card scanned on a Terminal can be used to associate cards with Location Services.

1. Pass an HID card over the card reader on the Terminal.

The ThinManager User Configuration Wizard appears.

**Figure 566 - Card/Badge Information**



Once the card reader has scanned an unknown Prox card, a ThinManager User Configuration Wizard is launched, associated with the new card number.

2. Click Assign Card Number to Existing User.


The ThinManager User Replacement page appears.

3. Click Next if you want to create a new ThinManager User for this card instead of associating it with a previously created ThinManager User.



The User Replacement Page allows you to select an existing ThinManager User with whom to associate the card.


**Figure 567 - User Replacement Dialog Box**



4. Select a ThinManager User from the tree and click OK.

The ThinManager User Information page for the selected user appears.

**Figure 568 - ThinManager User Configuration Wizard**




The Password and Permissions can be modified at this time if it is not an Active Directory user.

5. Click Next.

The Card/Badge Information page appears with This user will use a card or badge to log in checked.

The serial number of the HID card is populated to the Enter Card/Badge ID number field.

Figure 569 - Card/Badge Information Page



Check Prompt for Password or Prompt for Pin for the Card/Badge Login, the Biometric Login, or a Manual Login to require a secondary credential.

Setting	Description
Prompt for Password	Check to require the user to enter their password
Prompt for Pin	Check to require the user to enter their PIN

6. Click Finish to accept the changes.

The card can now be used to log in at terminals configured with card readers.

*Manually Apply the Card to a Configuration*

Although the easiest method to assign a card or badge is automatic as described in the previous section, ThinManager can be configured for manual entry.

To configure a terminal to allow a device, follow these instructions.

1. In the Options dialog box, see [Figure 565 on page 397](#), clear the Display “Create New User” dialog for unknown users checkbox to manually complete the Enter Card/Badge ID number field. You can find the Card/Badge ID number in the event log.

2. Turn the ThinManager User Event Log on in the ThinManager Server Configuration Wizard. See [Event Log on page 401](#) for more information.
3. Have the appropriate hardware on the terminal, either a USB or Serial ProxCard reader.
4. Add the appropriate module.
5. Use the device once to have the device's identifier entered to the event log.
6. Open the ThinManager User Configuration Wizard and enter the ID number to tie the ThinManager User to the device.
7. Log in with the ID device.

### Event Log

The Event Log is configured in the ThinManager Server Configuration Wizard.

1. Click the ThinManager Server icon to access the ThinManager Server branch of the ThinManager tree.
2. Double-click on the ThinManager Server icon or choose Edit>Modify from the menu to open the ThinManager Server Configuration Wizard.
3. Click Next until the Historical Logging page appears.

**Figure 570 - Historical Logging Page**

All events can be selected to be logged, but the ThinManager User Configuration changes checkbox is critical to the ThinManager Device detection.

4. Check ThinManager User Configuration changes and click Finish.


### Device Identifier Number

Next, the HID card needs to be scanned to help find the ID number.

1. Pass the HID card over the pcProx Card scanner attached to a terminal.

A ThinManager dialog box is displayed.

**Figure 571 - ThinManager Dialog Box**



The ID device does not work; so, the Terminal sends a message with the ID device's identifier number.


2. Record the number displayed.

This number is also entered in the event log if the Terminal Events are checked in the ThinManager Server Configuration Wizard.

3. Open ThinManager.
4. Highlight the Terminal in the tree and click the Event Log tab.

The ID for the device is entered in the log.


**Figure 572 - ThinManager Event Log**



Next, the ID number needs to be associated with the ThinManager User.

5. Open the ThinManager User Configuration Wizard for the user you want to associate with that ID card.
6. Click Next until the Card/Badge Information page appears.

Figure 573 - Card/Badge Information Page



7. In the Card/Badge Login section, check This user will use a card or badge to log in.
8. Type the ID Identifier from the earlier steps into the Enter Card/Badge ID number field.




Check Prompt for Password or Prompt for Pin for the Card/Badge Login, the Biometric Login, or a Manual Login to require a secondary credential.

Setting	Description
Prompt for Password	Check to require the user to enter their password.
Prompt for Pin	Check to require the user to enter their PIN.

Now, the Terminal is configured, the ID device is identified, and the ThinManager User is configured to use the device.

9. Click Finish to complete the configuration.

Figure 574 - Event Log



10. Rescan the card that now is associated with a ThinManager User account.

The Event Log shows the results of the successful login. The terminal has the ThinManager User added to its icon in the tree, while the ThinManager User icon shows the name of the terminal into which it is logged.

## Fingerprint Reader

ThinManager supports the DigitalPersona UareU models 4500 and 5160 fingerprint readers as biometric readers. These can be used as identifiers for ThinManager.


These are the requirements for the DigitalPersona UareU model 4500 fingerprint scanner.

- Activation in the ThinManager Server Configuration Wizard
- The unit is plugged into a terminal and the DigitalPersona UareU Fingerprint Reader module added to the terminal
- The user fingerprint scanned in ThinManager to associate a user with the fingerprint

### *Fingerprint Reader in ThinManager*

The DigitalPersona UareU fingerprint reader must be activated in the ThinManager Server Configuration Wizard.

**Figure 575 - ThinManager Server Configuration Wizard**




1. Double-click on the ThinManager Server icon in the ThinManager branch of the ThinManager Server tree.

The ThinManager Server Configuration Wizard appears.

2. Click Next until the Biometric Device Configuration page appears.

Figure 576 - Biometric Device Configuration Page




Setting	Description
Support Finger Print Readers	Check to enable the use of readers
Fingerprint storage format	Choose the data format you plan to use from the pull-down menu <ul style="list-style-type: none"> <li>• ISO IEC 19794_2_2005</li> <li>• ANSI INSITS 378_2004</li> </ul>
False Match Probability	Sets the sensitivity of the read. 1/100 is less sensitive than 1/1,000,000

3. Click Finish to accept the changes.

### Fingerprint Reader on the Terminal


You must add the DigitalPersona UareU Fingerprint Module to a Terminal if you plan to plug a DigitalPersona UareU fingerprint reader into the terminal.

1. Double-click on the terminal icon in the terminal branch of the ThinManager Server tree to open the Terminal Configuration Wizard.

**Figure 577 - Terminal Mode Selection Page**

2. Click Next until the Terminal Mode Selection page of the Terminal Configuration Wizard appears.
3. Check Enable ThinManager User Services to make the fingerprint reader work with ThinManager.
4. Click Next until the Module Selection page appears.
5. Click Add on the Module Selection page.

The Attach Module to Terminal dialog box appears.


**Figure 578 - Attach Module to Terminal**



6. Choose Location Services from the Module Type pull-down menu, highlight the DigitalPersona UareU Fingerprint Reader module, and click OK to add the module to the Terminal.
7. On the Module Selection page, highlight the DigitalPersona UareU Fingerprint Reader module and click Configure.

The Module Properties dialog box appears.

**Figure 579 - DigitalPersona UareU Fingerprint Reader Module Properties**




The DigitalPersona UareU Fingerprint Reader module has several configurable settings.

Setting	Description
Mode	Allows you to choose the Mode
ThinManager	Used to identify a ThinManager User
TermMon	Sends the fingerprint data to the TermMon ActiveX
TermMon Lookup	Allows the TermMon ActiveX to identify the user without the need for them to log in
Data Format	Sets the data format for the fingerprint reader. It should match the configuration in the ThinManager Server Configuration Wizard. These are the data formats. <ul style="list-style-type: none"> <li>• ISO_19794_2_2005</li> <li>• ANSI_378_2004</li> <li>• DigitalPersona</li> </ul>
Show Status Messages	Set to YES to show a brief message in the upper-right corner of the Terminal for each fingerprint reader event
Allow Manual Logon	Set to NO so that a user must use the fingerprint reader to log on. Set to YES to use the fingerprint scanner or log on manually.
Prompt for ThinManager Password	Set to YES for the user to be required to enter a password in addition to the fingerprint scan. Set to NO so the fingerprint scan is enough to allow a log on.

### *Fingerprint Reader for the ThinManager User*

Fingerprint data is associated with a user in the ThinManager User Configuration Wizard.


Figure 580 - ThinManager User Configuration Wizard



1. Open the ThinManager Users branch of the ThinManager tree and double-click on the ThinManager User whose fingerprints you want to register.

The ThinManager User Configuration Wizard appears.

Figure 581 - Card/Badge Information Page



Setting	Description
Prompt for Password	Check to require the user to enter a password
Prompt for Pin	Check to require the user to enter a PIN




Check Prompt for Password or Prompt for Pin for the Card/Badge Login, the Biometric Login, or a Manual Login to require a secondary credential.

The Card/Badge Information page has an Enroll Fingerprint button that begins the registration process.

1. Click Enroll Fingerprint.

The Enroll Fingerprint dialog box appears.


**Figure 582 - Enroll Fingerprint**



2. Click Change.


The Select Terminal Group dialog box appears, where you can select the Terminal that has the fingerprint scanner to use for registration.

**Figure 583 - Select Terminal Group Dialog Box**



3. Highlight the terminal that has the fingerprint scanner to use for registration and click OK.

Now, this terminal is registered as the Enrollment Terminal in the Enroll Fingerprint dialog box.

**Figure 584 - Enroll Fingerprint**

4. Choose the finger you want to enroll in the Select Finger to Enroll pull-down menu.


A crosshair appears on the finger chosen.

5. Click Start Enrollment.


The enrollment requires four scans of the fingerprint.

6. Place the finger on the scanner.

The blue light should turn red, and then back to blue. Leave the finger on the scanner until the red light turns off.


**Figure 585 - Enrollment Started**

A status message indicates progress.

**Figure 586 - Scan Status**


The enrollment requires four scans of the fingerprint.

7. Repeat until complete.

**Figure 587 - Enroll New Finger**


Once the finger has been scanned and enrolled, the scanned finger appears green in the Enroll Fingerprint dialog box.

8. Choose a new finger from the Select Finger to Enroll pull-down menu.

**Figure 588 - Shadow of a Terminal Scan**

If Prompt for Password was checked on the Card/Badge Information page, then a dialog box appears with a request for the Windows password for the Windows account. See [Figure 581 on page 408](#).

[Figure 589 on page 412](#) shows a ThinManager User logged in to a terminal that uses a DigitalPersona UareU Fingerprint Reader.

**Figure 589 - Shadow of a Terminal Scan**

The Terminals icon shows a user logged in, it names the user, and the Desktop2012 application shows a user login to show that display client was assigned through the ThinManager User.

## Location Services

Location Services is mobile computing based on location. It does not just send an application to a mobile device, but it is a way to enable the location to determine the content sent to the device. The mobile device allows the user to interact with the location.

Location Services is the *how* to provide *what* you need, *where* and *when* you need it.


There are two types of locations in Location Services: Assigned and Unassigned.

Assigned locations are those that have a terminal and monitor at the given location, much like traditional computing. Location Services adds functions to the location that allow mobile devices to interact with it. These interactions include Shadow the terminal, Clone the applications, or Transfer the control of the location to the mobile device.

Unassigned locations are those that lack a permanent terminal and monitor, and all of the content is sent to the mobile device.

In ThinManager, to deploy applications, define a terminal and configure it with applications and a user account, which allows the operator to access needed applications. See [Figure 590 on page 413](#).

**Figure 590 - ThinManager Deployment**



The Location Services method starts with location creation. The application, user account, and terminal are added to the location. See [Figure 591](#).

**Figure 591 - Assigned Location**




Location Services can deploy applications to locations without terminals. Your mobile device becomes the terminal. See [Figure 592 on page 414](#).

**Figure 592 - Unassigned Location**

## Create a Location with the Location Configuration Wizard

The first task is to create a location and apply the application and user account to the location, which is then be assigned to the terminal.

**Figure 593 - Location Configuration Wizard**

1. Click the Locations (globe) icon in the Tree Selector at the bottom of the tree to open the Locations branch.
2. Right-click on the Locations branch and choose Add Location.

The Location Configuration Wizard appears.

3. Type the Location Name in the field.
4. Click Next to continue.

The Location Options page has several configurable options that control the remote access.



**Figure 594 - Location Options Page**

**Location Configuration Wizard**

**Location Options**  
Select Options for the location


Options

Inactivity Timeout	300	secs
Resolver Signal Loss Timeout	15	secs
Activate Display Client at Log In	<input checked="" type="checkbox"/>	
Enforce Location Fencing	<input type="checkbox"/>	
Inherit from parent Locations	<input checked="" type="checkbox"/>	
Allow Local Access	<input checked="" type="checkbox"/>	
Allow Remote Access	<input checked="" type="checkbox"/>	
Reset Cloned Sessions on Logout	<input type="checkbox"/>	
Allow Location to be selected manually	<input type="checkbox"/>	

< Back   Next >   Finish   Cancel   Help

Setting	Description
Inactivity Timeout	Time interval in which a ThinManager user is logged off for inactivity.
Resolver Signal Loss Timeout	Time interval before a ThinManager user is logged off due to lack of a signal.
Activate Display Client at Log In	Check to bring the display client to the forefront when the ThinManager user logs in.
Enforce Location Fencing	Check to control access in an area with nested locations. If local fencing is enforced, the user must be within the fence to access the sub-locations.
Inherit from parent Locations	Check to allow nested sub-locations to inherit the parent display clients.
Allow Local Access	Check to allow a ThinManager user to access the location from that location. Clear this checkbox to allow remote access only.
Allow Remote Access	Check to allow a ThinManager user to access the location from a remote site. Clear this checkbox to allow access at the location only.
Reset Cloned Sessions on Logout	Check to close any cloned sessions once they are disconnected.
Allow Location to be selected manually	Check to allow a location to be selected manually and dynamically reveal settings under Allowed Manually Selected Location Actions. Clear this checkbox to require the ThinManager user to use a Resolver like QR Codes, Wi-Fi, or Bluetooth to initiate the location access.


Figure 595 - Location Options Page



These are the actions you can select manually. You can allow all or none. The defaults are fine, but you have the option to customize the settings as needed.

Setting	Description
Allow Shadowing	Check to allow a duplicate of the display to be shown on mobile device.
Allow Cloning	Check to allow the user to launch the same applications as the location but using their Windows account.
Allow Transfer	Check to allow the display to be moved from the location to the mobile device.

5. Choose the manual connections of your choice. Cleared checkboxes are not available in the manual selection menu.

**Figure 596 - Remote Desktop Server Selection**

6. Select the display clients you want displayed on the Location.
7. Click Override.

The Override Settings dialog box appears, which allows you to add a different user name to a highlighted display client.

8. Apply the desired display clients to the location and click Next to continue.



A location with a display client requires a Windows username.

Figure 597 - Windows Log In Information


Setting	Description
Username	Type a valid Windows username.
Password	Type the password.
Verify Password	Type the password.
Domain	Click Search and the Search for AD User dialog box appears.

The Search for AD User window allows you to reference users from the Active Directory.

Figure 598 - Search for AD User

9. Click Locations.


The Select AD Location to Search dialog box appears, where you can choose users.

**Figure 599 - Select AD Location to Search**

10. Highlight the domain branch you want to use and click OK.


The Location for the search is added.

#### Search for AD User



11. Click Search to fetch the user accounts and populate the Search for AD User dialog box.


Figure 600 - Populated Search for AD User



12. Highlight the domain user you want and click OK.

This references the user for the terminal log in account. The Location is now configured to use an Active Directory user account.


Figure 601 - Windows Log In Information Page



13. Select Next to continue.

The Location Services Resolver Selection page appears, which allows the association of Resolvers to the location.

Figure 602 - Location Services Resolver Selection Page




These are the Resolvers.

- QR Codes
- Bluetooth Beacons
- Wi-Fi Access Points
- GPS

14. Click Finish to create the Location.

Figure 603 - Location with Assigned Display Clients




The Location tree shows the created Locations and the display clients assigned to it.

## Add a Location to a Terminal

Now, the newly created location must be attached to a Terminal.

These instructions show how to add a Location to an already configured Terminal. You can create the Terminal from scratch and add the location as you configure the Terminal.

**Figure 604 - Terminal Configuration Wizard**



1. Click the Terminal icon on the Tree Selector at the bottom of the tree.


The Terminals branch appears.

2. Double-click a Terminal or right-click and choose Modify.

The Terminal Configuration Wizard appears.



Figure 605 - Terminal Mode Selection Page




3. Click Next until the Terminal Mode Selection page appears. There are ThinManager User and Location Services checkboxes.

Setting	Description
Enable ThinManager User Services	Check to use the ThinManager User Access to control access to applications.
Enable Location Services	Check to allow the Terminal to use Locations in its configuration.

4. Check Enable Location Services to use Locations.
5. Click Next to navigate to the Display Client Selection page.

Figure 606 - Remove Display Clients on the Display Client Selection Page



6. Highlight the display clients that already exist in the Selected Display Clients list and click the left arrow to remove them from a Terminal that already exists.

Leave the Selected Display Clients list blank if you want to configure a new terminal.

The user accesses the display clients through the location, not the Terminal.

7. Click Next and continue to the Location Services Options page.

Figure 607 - Location Services Options Page




Choose Options prior to a Location. Once the Location is assigned, Options are locked. Click Clear to clear the Location if you need to change an option, and then reassign the Location.

Options	Description
Use Force Transfer to restore Assigned Location	Check to allow the operator to take a transferred session back without the need to wait for the other device to approve of the transfer.
Allow selection of Location manually	Check to let the user manually select the location from a menu on the mobile device. Clear the checkbox so the user must use a Resolver.
Enforce fencing on manual Location selection	Check to enforce the fencing on a location during manual selection.
Confirm before entering a location	Check so you are notified as you enter a fence and asks for an acknowledgment.
Enable Resolver Types	Location Services has several methods to resolve the location to allow specific applications to get sent to specific locations.
Enable QR Code Location Ids	Check to allow the scanning of a QR code to determine the location.
Enable Bluetooth Locations	Check to allow the use of Bluetooth beacons to determine the location.
Enable GPS Locations	Check to allow the Global Positioning System of the mobile device to determine the location.
Enable Wi-Fi Locations	Check to allow the signal strength of Wi-Fi access points to determine the location.

Each method selected requires configuration to associate a location with the Resolver data.


8. Click Change.

The Select Location dialog box appears with the created Locations displayed in the Selection Location tree.

**Figure 608 - Select Location Dialog Box**

9. Highlight the desired Location and click OK.

The Location is displayed in the Assigned Location field once it is assigned to the Terminal.


**Figure 609 - Location Assigned**

Once the Location is assigned, the Options are locked.



If you need to change an option, click Clear, change the option, and then reassign the Location.

10. Once the location is assigned, click Next until the Log In Information page appears.

**Figure 610 - Log In Information Page**

The screenshot shows a window titled "Terminal Configuration Wizard" with a close button (X) in the top right corner. Inside the window, there is a section titled "Log In Information" with a sub-header "Enter the log in information to log in automatically. Leave the log in information blank or fill only some of the fields to force manual log in." To the right of this text is a small icon of a person. Below this, there is a group box labeled "Windows Log In Information" containing four text input fields: "Username", "Password", "Verify Password", and "Domain". To the right of the "Username" field is a "Search" button. At the bottom of the window, there are five buttons: "< Back", "Next >", "Finish", "Cancel", and "Help".


Typically, a preconfigured Terminal is assigned a user account to allow it to log in to the servers. However, this is not needed now because it uses the user account assigned to the location.

11. Leave the Username and Password fields blank.
12. Once the Username is cleared, click Finish to complete the wizard.

Once the wizard is closed, you must restart the Terminal to load the changes.

13. Right-click on the Terminal in the tree and choose Restart Terminal to load the new configuration.

The application now runs on the location that is assigned to the Terminal.

**Figure 611 - Locations on Terminals in Terminal Tree**

The tree shows location icons to show which display clients are from the location.

In [Figure 611](#), the terminal 2\_Terminal is using location Loc\_1.



The user should see no difference in the application deployment between a Terminal with display clients deployed with Locations and a Terminal without Locations.

The big difference Location Services makes is when a mobile device interacts with the location.

## Mobile Device Interactions with Location Services

When you add a location to a Terminal, it does not seem like it makes any difference. The application runs the same on the Terminal versus a location on a Terminal. The difference is the mobile-device interaction a user can have with that location.

Configuration of mobile devices is covered in [Mobile Devices on page 300](#).

ThinManager uses Resolvers to define the location.

- Manual Selection – allows user to select the location manually from a menu on the mobile device
- QR Code – can be created to define a location
- Bluetooth – allows the use of Bluetooth beacons to determine the location
- GPS – allows the Global Positioning System of the mobile device to determine the location
- Wi-Fi – allows the signal strength of Wi-Fi access points to determine the location
- iBeacon – the Apple® Inc. version of Bluetooth

Resolvers are identified and marked using the mobile device; so, it is important to configure a mobile device to identify the resolvers in Location Services.



- The iTMC application can be installed for free from the App Store® on iTunes®
- The aTMC application can be downloaded for free from the Google Play™ store
- The WinTMC client for Windows® can be downloaded at the ThinManager website at <http://downloads.thinmanager.com/>

Two pages of the Terminal Configuration Wizard enable mobile devices.

The first page that covers interaction with a Location is the Location Services Options page, which lets you select which Resolver methods you want to use. These are listed in the Enable Resolver Types section.

**Figure 612 - Location Services Options**

1. Check the Resolvers you want to use and Allow selection of Location manually.

Each method selected requires configuration to associate a location with the Resolver data.


These are the Options.

Options	Description
Use Force Transfer to restore Assigned Location	Check to allow the operator to take a transferred session back without the need to wait for the other device to approve of the transfer.
Allow selection of Location manually	Check to let the user manually select the location from a menu on the mobile device. Clear the checkbox so the user must use a Resolver.
Enforce fencing on manual Location selection	Check to enforce the fencing on a location during manual selection.
Confirm before entering a location	Check so you are notified as you enter a fence and asks for an acknowledgment.
Enable Resolver Types	Location Services has several methods to resolve the location to allow specific applications to get sent to specific locations.

Options	Description
Enable QR Code Location Ids	Check to allow the scanning of a QR code to determine the location.
Enable Bluetooth Locations	Check to allow the use of Bluetooth beacons to determine the location.
Enable GPS Locations	Check to allow the Global Positioning System of the mobile device to determine the location.
Enable Wi-Fi Locations	Check to allow the signal strength of Wi-Fi access points to determine the location.

- Click Next to navigate to the Mobile Device Options page, which has several settings that control the user experience on mobile devices. This page allows you to disable features normally displayed in the mobile applications.

**Figure 613 - Mobile Device Options**



Options	Description
<b>Toolbar Buttons</b>	
Show Scan Data Button	Clear this checkbox to hide the Scan Data button.
Show Scan Resolver Button	Clear this checkbox to hide the Scan Resolver button.
Show User Login Button	Clear this checkbox to hide the User Login button.
<b>Sound Options</b>	
Play Location Sounds	Check to play a sound when a location is entered.
Play User Login Sounds	Check to play a sound when the user logs in as a TermSecure or ThinManager user.
<b>User Interface Settings</b>	
Show Zoom Map	Clear to hide the screen map while zoomed in.
Show Toolbar	Clear to hide the app toolbar.
Allow Exit to ThinManager Server List	Clear to prevent the user from leaving the app to switch ThinManager Servers.

- Click Finish to complete the configuration of the mobile Terminal.

**Notes:**



## Locations

### Unassigned Locations

Relevance allows you to deploy applications to mobile devices and not tethered to a location. You can create a location, deploy applications to it, and access these applications with a mobile device when you are at that location.

Unassigned Locations support Transfer, which acts like Forced Transfer, and Cloning. It does not support Shadow as there is no Terminal to shadow.

### Create an Unassigned Location

[Figure 614 on page 432](#) uses GPS so that when the mobile user enters the area, the appropriate applications are delivered to the user.

1. Click the Locations icon in the Tree Selector.

The Locations branch of the tree appears.


2. Right-click on the Locations branch and choose Add Location.

The Location Configuration Wizard appears, opened at the Location Name page.

3. Type a Location Name and click Next.

The Location Options page appears.

Figure 614 - Location Options Page



The Location Options page has several configurable options that control the remote access.

Option	Description
Inactivity Timeout	Type a time interval (in seconds) after which an inactive ThinManager user logged off.
Resolver Signal Loss Timeout	Type a time interval (in seconds) before a ThinManager user is logged off due to lack of a signal.
Activate Display Client at Log In	Check to bring the display client to the forefront when the ThinManager user logs in.
Enforce Location Fencing	Check to control access in an area with nested locations. If local fencing is enforced, the user must be within the fence to access the sub-locations.
Inherit from parent Locations	Check to allow nested sub-locations to inherit the parent display clients.
Allow Local Access	Check to allow a ThinManager user to access the location from that location. Clear this checkbox to allow remote access only.
Allow Remote Access	Check to allow a ThinManager user to access the location from a remote site. Clear this checkbox to allow access at the location only.
Reset Cloned Sessions on Logout	Check to close any cloned sessions once they are disconnected.
Allow Location to be selected manually <sup>(1)</sup>	Check to allow a location to be selected manually. Clear this checkbox to require the ThinManager user to use a Resolver like QR Codes, Wi-Fi, or Bluetooth to initiate the location access. When checked, the following options dynamically appear.
Allow Manually Selected Location Actions	Check the actions you can manually select. You can allow all, or none.
Allow Shadowing	This option is not supported in Unassigned Locations as there is no Terminal to shadow.
Allow Cloning	Check to allow the user to launch the same applications as the location, but use the Windows account of the mobile device.
Allow Transfer	Check to allow the display to be shown on the mobile device with the Windows account of the Unassigned Location.

(1) This option lets you manually choose the location from the mobile device. Clear the checkbox to rely on another resolver, like QR code or Bluetooth, to choose the location.


Unassigned Locations do not support Shadow. Therefore, the Allow Shadowing checkbox is clear in [Figure 614 on page 432](#). Allow Cloning and

Allow Transfer are checked in [Figure 614 on page 432](#). The defaults are fine, but you have the option to customize the settings as needed.

4. Click Next to continue.

The Display Client Selection page appears.

**Figure 615 - Display Client Selection Page**



5. Add the display clients you want on the Remote Desktop Server Selection page.
6. Click Next to continue.

The Windows Log In Information page appears.

**Figure 616 - Windows Log In Information Page**

7. Type a Windows user account into the Username field.
8. Click Search to use an Active Directory user as described in [Search for Active Directory User on page 243](#).
9. Click Next to continue.

The Resolver Selection page appears.

**Figure 617 - Resolver Selection Page**

Name	Type	Action
QR-03	QR Code	Force Transfer

10. Click Add to add the resolver on the Resolver Selection page and add an action.

**Figure 618 - Choose a Resolver Page**

11. Choose a resolver from the Resolver Name pull-down menu.
12. Choose the action from the Choose Action pull-down menu.
13. Click OK to accept the configuration.

There is a Settings button for the resolvers.

**Figure 619 - Bluetooth Resolver Settings**

Option	Description
RSSI to Log In	A relative value that determines when a device automatically logs on.
RSSI to Log Out	A relative value that determines when a device automatically logs out.

The Bluetooth Resolver Settings dialog box shows the signal strength that was measured when the Bluetooth beacon was registered as the RSSI to Log In. The log out strength is automatically added as the RSSI to Log Out value is generated through the subtraction of 10 from the RSSI to Log In value.

Figure 620 - GPS Settings

GPS Resolver Settings

Latitude: 34.103725

Longitude: -84.240595

Altitude: 0.00

Location Radius: 37.19

Location Altitude Range: 0.00

OK Cancel

Option	Description
Latitude	The Fractional Latitudinal Coordinate in Degrees.
Longitude	The Fractional Longitudinal Coordinate in Degrees.
Altitude	The altitude trigger of the GPS Point.
Location Radius	The trigger Radius of the GPS Point in meters.
Location Altitude Range	The range along the Z-axis, in meters, that the mobile device is supposed to enter to be considered active at the location.

The GPS Resolver Settings dialog box shows the Latitude, Longitude, and Altitude that was measured when the GPS was registered. The Location Radius and Location Altitude Range are added automatically.

Figure 621 - Selected Resolver

Location Configuration Wizard

Relevance Resolver Selection  
Assign Relevance Resolvers to this location


Relevance Resolvers

Name	Type	Action
ACP WHQ	GPS	Transfer

Add Delete Edit

< Back Next > Finish Cancel Help

14. Once a resolver is added, click Finish to close the wizard and accept the configuration.

**Figure 622 - Display Clients Launched by GPS**

15. Launch the iTMC client.

The display clients appear on the mobile device once the resolver is triggered, either by a QR code or bar code scan, or entry within the range of the Bluetooth beacons, Wi-Fi area, or GPS zone.

This allows you to deploy applications without deploying permanent Terminal hardware.


## Fencing and Sub-Locations

Fencing is a hierarchy that allows you to nest locations within locations, which can be useful for organization and allow control of access.

Fencing allows you to create a location that has to be entered or authenticated before you can access the sub-locations. It is a way to ensure the user is in the right location before they can access a display client or action.

Fencing is useful to make sure the worker is in the area they are supposed to be. For example, a worker cannot take a photo of a QR code and log in at their desk with this method. Fencing can force them to enter an area controlled by Bluetooth beacons, Wi-Fi access points, or GPS before they can scan the QR code or bar code. If they run the application and leave the Fence, then the application is no longer transmitted.

Fencing is best initiated by Bluetooth beacons, Wi-Fi Access Points, or GPS.

**Figure 623 - Location Using Fencing**


In [Figure 623](#), the Warehouse location was created as the parent group with Fencing Enforced. You have to enter the Warehouse location before you are allowed to access the Loc\_1 or Shipping01 locations and applications.

### *Parent Locations*

A Fence needs a parent location that authenticates a high-level location, which must be resolved before the child sub-locations can become active.


The parent location can be configured without display clients and actions, which merely provides proof of location. The applications and actions are delivered by the child sub-locations.



**Figure 624 - Location Options for Parent Location**

The Warehouse parent location has Enforce Location Fencing enabled.

A user must authenticate to the Warehouse location before the child sub-locations can be accessed.

**Figure 625 - Display Client Selection**

The Warehouse parent location is not assigned display clients. It is used only for authentication so display clients are left off the location.

Figure 626 - Windows Log In Information Page

The screenshot shows a window titled "Location Configuration Wizard" with a close button (X) in the top right corner. The main heading is "Windows Log In information" with the instruction "Enter Windows username and password information." Below this is a section titled "Windows Log In Information" containing four text input fields: "Username", "Password", "Verify Password", and "Domain". To the right of the "Username" field is a "Search" button. At the bottom of the window are five buttons: "< Back", "Next >", "Finish", "Cancel", and "Help".

The Warehouse parent location is not assigned a Windows user account because it has no display clients of its own.

Figure 627 - Relevance Resolver Selection Page

The screenshot shows a window titled "Location Configuration Wizard" with a close button (X) in the top right corner. The main heading is "Relevance Resolver Selection" with the instruction "Assign Relevance Resolvers to this location". Below this is a section titled "Relevance Resolvers" containing a table with three columns: "Name", "Type", and "Action". The table has one row with the values "ABF9", "Bluetooth", and "No Action". Below the table is a scroll bar. At the bottom of the section are three buttons: "Add", "Delete", and "Edit". At the bottom of the window are five buttons: "< Back", "Next >", "Finish", "Cancel", and "Help".

Name	Type	Action
ABF9	Bluetooth	No Action

The Warehouse parent location is assigned the ABF9 Bluetooth resolver, which has no action listed because the intent is not to launch a program or initiate an action other than to identify the user in the parent location.

A user must be on the range of the ABF9 Bluetooth beacon to access the sub-locations.

A GPS location or Wi-Fi Access Point could be used instead.


## Child Sub-locations

Sub-locations that are nested under a parent location must resolve the parent location before it can initiate the action of the sub-location.

These two methods can create a sub-location.

This is the first method to create a sub-location.

**Figure 628 - Location Right-click Menu**



1. Right-click on the parent location and choose Add Location.


The Location Configuration Wizard appears with the created location nested under the parent location.

The second method to create a sub-location is to add an existing location to the location.

1. Double-click on a location in the Location branch of the ThinManager tree.

The Location Configuration Wizard appears.


**Figure 629 - Location Name Page**



2. Click Change Group.

The Choose Parent Location dialog box appears.

**Figure 630 - Choose Parent Location**



3. Highlight the desired parent location and select OK. In this example, the Warehouse location is used.

The Location Name page appears, with the highlighted parent location displayed as the Location Group.

**Figure 631 - Location Name Page**

4. Click Finish to accept the change.

The open location becomes a child sub-location.


**Figure 632 - Location Options for Sub-location**

This sub-location is configured to Inherit from parent Locations.

If they had sub-locations of their own, they could have the Enforce Location Fencing applied.


- 5. Check Inherit from parent Locations to inherit the applications applied to the parent location.
- 6. Clear the Allow Location to be selected manually checkbox to make the user use the resolvers at the location to initiate the application or action.

Figure 633 - Display Client Selection Page




- 7. Add the desired display clients to the sub-location that the user accesses when connected.

Figure 634 - Windows Log In Information Page



The sub-location needs a user account if it has a display client added. You can use domain accounts or non-domain accounts.

**Figure 635 - Relevance Resolvers Selection for Sub-locations**



The sub-locations can use any resolver—QR codes, additional Bluetooth beacons, another Wi-Fi access point, or GPS—to allow access to the sub-location. The QR code provides the best way to provide pin point accuracy.

See [Add Actions to Resolver Codes on page 46](#) for details on how to add the Relevance Resolvers to a Location.

## ThinManager User Access

Relevance has Access Groups that can be used to control access to a location or action. This is based on the Relevance permissions in ThinManager.

Relevance has the ability to control access to actions and applications in ThinManager like Relevance does. Follow these steps to control user access.

1. Create Access Groups. See [ThinManager Access Group Creation on page 326](#).
2. Apply to Applications or actions. See [Add Access Group to a Display Client on page 329](#).
3. Apply to location. See [Add Actions to Resolver Codes on page 46](#).
4. Create ThinManager Users. See [Create the ThinManager User via Active Directory on page 345](#).
5. Apply Permissions. See [Add Actions to Resolver Codes on page 46](#).
6. Log in to the location to access applications. See [Interact with the Location on page 507](#).

**Figure 636 - Access Groups Applied to Display Clients and Users**

A Location can have a single resolver, like a QR code, assigned to it. The Location has different Display Clients assigned, each with a different access group.

**Figure 637 - User Access to Display Clients via Permissions**

As each person scans the Resolver, they get the application that matches their access group.

**Figure 638 - User Access to Display Clients via Permissions**

The same Resolver delivers different content, based on Permissions.

## Create a Location with Restricted Applications

Access Group permissions grant or deny access to display clients so that a user must log on with an account that has permission to access the application.

### Use Permissions to Restrict an Application

1. Double-click on the display client with the application you want to restrict in the Display Client tree.

The Client Name page of the Display Client Wizard appears, where permissions are applied to the display client.



**Figure 639 - Client Name Page**

2. Click Permissions.
3. The Permissions dialog box appears.

**Figure 640 - Permissions Dialog Box**


4. Move Unrestricted from the Member Of list to the Available list.

---

**IMPORTANT** If Unrestricted is not removed, then anyone can still access the application.

---

Figure 641 - Permissions



- 5. Move the desired Access Group to the Member Of list.
- 6. Click OK to close the window.
- 7. On the Client Name page, click Finish.

**Add a Restricted Application to a Location**


You can apply ThinManager User Services to Location Services and have applications on Locations that are restricted by membership in Access Groups.

To create a Location with the restricted display client, follow these steps.

- 1. Click the Locations icon on the Tree Selector to open the Locations tree and create a Location.
- 2. Right-click on the Locations branch and choose Add Location.


The Location Configuration Wizard appears.

Figure 642 - Location Configuration Wizard




- 3. Type a Location Name and click Next.

The Location Options page appears.

**Figure 643 - Location Options**

4. Choose your options.
5. Clear the Leave the Allow Location to be selected manually checkbox to force the user to use a resolver to access the applications.
6. Click Next to continue.

The Display Client Selection page appears.

**Figure 644 - Display Client Selection Page**

7. Add the desired display clients to the Selected Display Client list on the Display Client Selection page.

8. In this example, the HMI\_1 display client is unrestricted but the Form01 is restricted to members of the Maintenance Access Group as shown in [Use Permissions to Restrict an Application on page 446](#).
9. Click Next to continue.


The Windows Log In Information page appears.

A location with display clients requires a valid Windows user account, which can be a domain or non-domain account.

**Figure 645 - Windows Log In Information Page**

The screenshot shows a window titled "Location Configuration Wizard" with a close button (X) in the top right corner. The main content area is titled "Windows Log In information" with the instruction "Enter Windows username and password information." Below this, there is a section titled "Windows Log In Information" containing four input fields: "Username" (with the text "Location4"), "Password" (with masked characters "\*\*\*\*\*"), "Verify Password" (with masked characters "\*\*\*\*\*"), and "Domain" (empty). To the right of the Username field is a "Search" button. At the bottom of the window, there are five buttons: "< Back", "Next >", "Finish", "Cancel", and "Help".

10. Click Search for a domain account or type one into the Username field and type the Password.
11. Click Next to continue.

**Figure 646 - Relevance Resolver Selection**

12. Click Add.

The Choose a Relevance Resolver dialog box appears.

13. Choose your action, Forced Transfer in this case.

14. Click Finish.

The location is created and the wizard closes.

## Put It Together

[Figure 647](#) shows 1\_Terminal at the Shipping02 location. It has two display client applications:

- HMI\_1 is unrestricted and is visible to anyone accessing the location
- Form01 is restricted to members of the Maintenance access group



**Figure 647 - Shadowed Location**


Figure 647 shows the location with the HMI\_1 application operational. Form01 is not operational because no Maintenance user is logged in.

**Figure 648 - Mobile Transfer of the Location**


When the mobile user transfers the location, they have access to the unrestricted HMI\_New application only.

1. Click ScanID to scan a QR code resolver.
2. Click Login.

The Login prompt appears, which allows the ThinManager user to login.


**Figure 649 - ThinManager User/ThinManager User Login Prompt**

3. Login with the ThinManager User account that is a member of the proper access group.

**Figure 650 - ThinManager User Account Accesses Application**

Once the ThinManager User logs in, the user has access to the hidden restricted application. [Figure 650](#) shows both locations on the mobile device.

Figure 651 - ThinManager Tree



Once the ThinManager user is logged on with the correct Permissions from the access group membership, the hidden application is revealed.

## One QR Code, Multiple Actions

The previous section covered the use of a Relevance Access Group to hide a display client application from the public with the use of Access Groups. This section covers the use of access groups to provide different actions.


Instead of using a different resolver for every action, you can use a single resolver and Access Groups to provide different actions. The example that follows uses a QR code as the resolver.

1. Click the Locations globe icon on the Tree Selector at the bottom of the tree to open the Locations branch.
2. Double-click the Terminal or right-click on the Terminal and choose Modify.

The Location Configuration Wizard appears.

3. Click Next until the Relevance Resolver Selection page appears.




**Figure 652 - Relevance Resolver Selection Page**

4. Click Add.

The Choose a Relevance Resolver dialog box appears.


Add the same resolver to the location as many times as you have actions and access groups you want to involve.

**Figure 653 - Choose a Relevance Resolver**

5. Choose a different action from the Choose Action pull-down each time you add it.
6. Click Permissions to add the Access Group to the action.

The Permissions dialog box appears.


Figure 654 - Permissions Dialog Box



7. Remove the Unrestricted group from the Member Of list and add the desired access group from the Available list group; Quality in this example.
8. Click OK to finish.

You can also edit the permissions

Figure 655 - Edit Button on the Relevance Resolver Selection Page



1. Highlight a resolver and click Edit.

The Choose a Relevance Resolver dialog box appears, within which the Permissions button resides.

This example used the following settings.

Location	Application	Resolver	QR Action	Access Group
Loc_1	HML_1 Form03	QR-01	Shadow	Quality
		QR-01	Transfer	Maintenance
		QR-01	Force Transfer	Foremen
		QR-01	Clone	Supervisor

If a Quality member scans the QR-01 code, they are able to shadow the location and leave control with the operator.

If a Maintenance member scans QR-01, they transfer the application to their mobile device once the operator allows it.

If a Foreman scans the QR-01 code, they immediately transfer the display from the location to their mobile device so that they can take their application with them when they roam through their section.

If a Supervisor scans QR-01, they clone the application and run it with their own Windows account.


## Calculate Permissions

It is easy to lose track of the permissions as your system expands and more functions and features are added. Relevance has a Permission Calculator to help.

1. Choose Manage>Access Groups.


The Access Groups dialog box appears.

**Figure 656 - Access Groups Dialog Box**



2. Click Calc Permissions.

The Effective Permission dialog box appears.

**Figure 657 - Effective Permission Dialog Box**


3. Highlight members of selection lists to show the display clients that are visible in the Visible Display Clients column.
4. Click Clear User and Clear Location to clear the fields and test another combination.
5. Click OK to close the dialog box.

## Manual Interaction with Locations

A mobile device can connect to a Location and manually interact with the applications.


1. Connect the mobile device to the ThinServer and connect as shown in [Mobile Devices on page 300](#).

**Figure 658 - Main Menu on a Mobile Device**



2. Launch the Main Menu from the mobile device menu bar.
3. Press Login Location, which manually connects to a Location.

The Select Location dialog box appears, which lists all Locations that are allowed to have a manual configuration. In [Figure 659 on page 460](#), only one Location is created.


**Figure 659 - Select Location**

4. Press the Location.

The Select Action dialog box appears.


If a No Actions dialog box appears, it indicates one of two possibilities.

- There were no Actions checked on the Location Options page of the Location Configuration Wizard
- A Relevance Permission was applied, and the user is not a member of a permitted access group

**Figure 660 - No Actions Error**

- a. If the No Actions dialog box appears, click Ok to close it and select another location.

Figure 661 - Actions for Manual Interaction




There are three manual interactions between a mobile device and a location.

Interaction	Description
Shadow	Duplicates the graphic output of the Location screen and sends it to the mobile device.
Transfer	Sends the graphic output of the location to the mobile device instead of the location. Requires the operator to manually allow the transfer.
Clone	Creates a duplicate session for the mobile device using the configuration of the location and the user credentials of the mobile device.

Shadow


Shadow duplicates the graphic output of the location and sends it to the mobile device.

Figure 662 - Shadow



The Shadow feature allows the mobile user to see and interact with the exact display as the location.


Figure 663 - Main Menu



1. Open the mobile program, select your ThinManager Server, and press Menu in the upper-right corner to launch the Main Menu dialog box.
2. Press Login Location on the menu.

The Select Location dialog box appears.


Figure 664 - Select Location Menu



3. Press a Location.


The Select Action dialog box appears, which list the actions allowed at the location.



**Figure 665 - Select Action Dialog Box**

4. Press Shadow to connect and shadow the Location.

[Figure 666](#) shows the shadow of the location.

**Figure 666 - iTMC Shadowing Location**

The shadow only shows one display client window when you shadow the location and receive the current graphic output from the location.

5. Press Leave to end the shadow.

## Transfer


Transfer is similar to Shadow except that the user must allow the transfer at the location, which prevents someone from taking the session while the operator is busy with a process. Also, it allows a mobile user to take sole control of the location.

**Figure 667 - Transfer**




1. Open the mobile program, select your ThinManager Server, and press Menu in the upper-right corner to launch the Main Menu dialog box.

**Figure 668 - Main Menu on a Mobile Device**




2. In the Main Menu, press Login Location.

The Select Location dialog box appears, where you can manually connect to a Location. It lists all Locations that are allowed to have a manual configuration. [Figure 669 on page 465](#) shows only one Location was created.


**Figure 669 - Select Location**

3. Press Location to open the Select Action dialog box.

**Figure 670 - Actions for Manual Interaction**

4. Press Transfer from the Select Action dialog box.

**Figure 671 - Wait for Transfer Permission Message**




The user of the location must allow the transfer. This communication prevents the mobile user from taking the session while the local user is performing a task.

**Transfer at the Location**

A dialog box is displayed at the location to allow the transfer.

**Figure 672 - Location Logoff Dialog Box**




1. The local user must press YES to allow the transfer.

The mobile client is allowed to display the location display.

**Figure 673 - Transferred Location Display**

The Transfer shows all the display clients on the location instead of just the display output of the location.

2. The location display can be restored from the client or the location.
  - Press Leave on the client menu to restore the display to the location.
  - Also, you can press Restore Location at the location to restore the display.


**Figure 674 - Main Menu at the Location**

The Location displays the Main Menu during the transfer.

3. Press Restore Location to return the session.

A dialog box appears on the mobile client to warn the mobile user that the transfer ends soon.

Figure 675 - Location Logoff Dialog




4. Press YES to allow the transfer back to the original location, NO to refuse the restoration, or MORE TIME to delay the restoration.

The amount of time that an operator has to acknowledge and allow the transfer can be set on the Relevance Setting dialog box. See [Bluetooth Beacons on page 478](#) for details.


## Clone

Clone duplicates the display clients of the location on the mobile device, but the sessions are created with the mobile device Windows user account.

Figure 676 - Clone




Session creation with the mobile device Windows user account allows a mobile user to get the HMI or other software and have independence from the user at the location.

**Figure 677 - Main Menu on a Mobile Device**

1. Press Login Location.

The Select Location dialog box appears, which lists all Locations that are allowed to have a manual configuration.


**Figure 678 - Select Location**

In [Figure 678](#), only one Location was created.

2. Press the Location.

The Select Action dialog box for the Location appears.

Figure 679 - Actions for Manual Interaction



3. Press Clone.

The mobile device launches copies of the location's display clients, but uses the mobile device login.

Figure 680 - Cloned Session




Figure 680 shows a session running the same application, but with a different set of credentials.

4. Press Leave near the top-right corner to close the mobile client.



## Addition of Resolver Codes with Mobile Device

Resolvers can help a mobile device know what location it is in. These can be configured to tell the mobile device what action to take.

These are Resolvers.

- QR Codes
- Bluetooth Beacons
- Wi-Fi Access Points
- GPS

### Assignment of Resolvers

Because Resolvers can only be assigned to one location, they identify the Location for Relevance. Each location can have more than one Resolver and action assigned. You can use Permissions to assign a resolver several times with a different action tied to each set of permissions.

Fencing uses combinations of resolvers to limit actions to specific locations. An action can require presence in an area covered by a Bluetooth beacon or GPS site before a QR code can be scanned, which can prevent a user's departure from an area with a critical process. The Fence prevents the use of the application outside of the assigned areas.

#### *QR Codes*

Quick Response (QR) Codes can store text, numeral data, and URLs. QR Codes can be read quickly and easily. There are many programs which generate them, which include free sites on the web.

QR Codes provide pinpoint location as you need to be at the QR Code to read it, which allows a high degree of granularity in your configuration. You can put QR Codes anywhere and not worry about overlap of signals or interference.

One issue with QR Codes is that they are easy to duplicate. If you want to use Relevance to limit an operator to a particular location, then QR Codes should be coupled with other devices like Wi-Fi, GPS, or Bluetooth to provide Fencing. See [Fencing and Sub-Locations on page 437](#) for details.

The iTMC and aTMC programs use the built-in camera as a scanner to read the QR Codes.


#### *Register QR Codes with an iPad*

QR codes must be registered with a mobile device.

1. Open the iTMC program on the iPad.
2. Press Settings at the bottom-center to launch the Settings dialog box.

A selection menu appears.


Figure 681 - iPad Settings Menu



- 3. Press Manage a Server.


The Select Server to Manage screen appears.

Figure 682 - Select Server to Manage Screen




- 4. Press the ThinManager Server to which you want to apply the QR Codes.

The iTMC Settings page appears, which has the links to register the various resolvers.

**Figure 683 - iTMC Settings Page**


5. Press Register QR Code, which opens the camera to scan and register the QR Code.

**Figure 684 - Scan New QR Code**

6. Point the camera at the QR Code. Once the QR Code is framed in the window, it reads the code and registers it.

Once the iTMC program reads the QR code, it asks you to name it.


**Figure 685 - Enter Description for QR Code**




- 7. Type a description in the Enter Description dialog box.
- 8. Click OK.

The iTMC program confirms a successful registration.

**Figure 686 - Successful Registration Confirmation**



The Resolvers are listed in the Resolver Management dialog box.


**Figure 687 - QR Code in Resolver Management Dialog Box**

9. Choose Manage>Manage Resolvers from the ThinManager menu bar to open the Resolver Management dialog box.

## Register QR Codes with an Android Device

QR codes need to be registered with a mobile device.


1. Open the aTMC program on the Android device.

**Figure 688 - aTMC Home Screen**

2. Press Settings on the bottom.

The Settings dialog box appears.

**Figure 689 - Settings Menu**




3. The Setting menu provides these choices.

Setting	Description
Manage ThinServer	Press to open the Settings Menu and register resolvers.
Add ThinServer	Press to open the Add New ThinServer page, which lets you define a new ThinManager Server.
Remove ThinServer	Press to allow you to delete a defined ThinManager Server.

If you have multiple ThinManager Servers defined, you must select the ThinManager Server to which you want to apply the QR codes.


The Settings page contains the links to register the various resolvers.

**Figure 690 - aTMC Settings Page**




4. Press Register QR Code.

The camera opens to scan and register the QR Code.

**Figure 691 - Scan New QR Code**

5. Point the camera at the QR Code. Once it is framed in the window, it reads the code and registers it.


Once the aTMC program reads the QR code, it asks you to name it.

**Figure 692 - Enter Description for QR Code**

6. Type the name for the Resolver in Enter Identifier Name dialog box.
7. Click Ok.

The aTMC program confirms a successful registration.


Figure 693 - Successful Registration Confirmation



8. Click OK.

The Resolvers are listed in the Resolver Management dialog box.

Figure 694 - QR Code in Resolver Management



9. Choose Manage>Manage Resolvers from the ThinManager menu bar to open the Resolver Management dialog box.

Bluetooth Beacons

ThinManager supports Bluetooth Beacons that use the Bluetooth Low Energy (LE) standard, which is part of the Bluetooth Core Specification Version 4.0. In order to work with these beacons, your mobile device also must support Bluetooth Version 4.0 or later. In the case of an iPad, this is any iPad (regular, Mini, or Air) that uses the Lightning connector.



Relevance can use Bluetooth beacons as location resolvers. These must be Low Energy Bluetooth beacons that provide a unique name in the Advertising Packet.

See [Fencing and Sub-Locations on page 437](#) for details.

To add new beacons to the system, you can use the mobile device to find and add them in a manner similar to the other resolvers. In the case of these devices, you stand at the entry point and allow the device to get a few readings so that it can get an average measure of the signal strength at that point. It automatically adds 10 to this number for the exit point. You can adjust these in ThinManager in the Manage Resolvers section.

Here is how to define a Bluetooth beacon with a mobile device.

1. Place the Bluetooth beacons in the locations you want.
2. Launch the iTMC or aTMC program and press Settings.
3. Press Register Bluetooth Beacon command under the Relevance Resolvers section. If you have more than one ThinManager Server defined, you must pick the ThinManager Server on which you want the Bluetooth beacons registered.
4. Choose the desired Bluetooth beacon from the generated list.
5. Type a name and press Register.
6. Choose Manage>Manage IDs.

The Resolver Management dialog box appears, in which the Bluetooth beacon is registered and entered.


## Relevance Settings

The Relevance Settings dialog box has some settings that can affect Bluetooth beacons.

1. Choose Manage>Relevance Settings on the ThinManager menu bar.

The Relevance Settings dialog box appears.

**Figure 695 - Relevance Settings**



These are the settings available in the Relevance Settings dialog box.


Setting	Description
Location Transfer Timeout	Sets the time that an operator has to acknowledge and allow a Transfer. See <a href="#">Transfer on page 464</a> .
Location Transfer Extension Time	Sets the interval of extra wait time that a refused transfer allows.
Bluetooth Device Name Filter Prefix	Enter a name in this field to limit the display of Bluetooth devices that have that prefix, which is helpful because ThinManager Bluetooth devices have an ACP prefix.
iBeacon GUIDs	Shows the registered iBeacons.
Add	Click to open the Enter iBeacon GUID dialog box, which allows definition of a new iBeacon.
Delete	Click to delete a highlighted iBeacon from the list.
Edit	Click to edit a highlighted iBeacon in the Enter iBeacon GUID dialog box.
Allow New Resolvers to be registered	Allows new resolvers. Clear this checkbox to prevent the addition of Bluetooth beacons by unauthorized users.

## Bluetooth Beacons Defined on an iPad

Define a Bluetooth beacon similarly to how you define a QR code.

1. Open the iTMC program on the iPad.

**Figure 696 - ThinManager iTMC Program**




2. Press Settings on the bottom of the screen.

The Settings menu dialog box appears.


3. Press Manage a Server.

The Select Server to Manage screen appears.

**Figure 697 - Select Configuration**

4. Press the ThinManager Server on which you want to register the Bluetooth beacon.


The Settings page appears.

**Figure 698 - Register Bluetooth Beacon Command on the Settings Page**

5. Press Register Bluetooth Beacon on the Settings page.

The Register Bluetooth page appears, which lists the Bluetooth beacons the mobile device finds.

Figure 699 - Available Bluetooth Beacons



6. Press the desired Bluetooth beacon.


ACP-9059AF08ADB5 was chosen in [Figure 699](#).



This ThinManager Server is using ACP as a filter in the Relevance Settings dialog box to limit the number of Bluetooth beacons shown. See [Bluetooth Beacons on page 478](#) for details.

The mobile device prompts you to go to the location that you want as the entrance point for the zone.


Figure 700 - Stand At Zone Entrance Dialog



7. Press Continue.

It can take a few seconds to allow the device to read the signal strength to create the resolver data.


**Figure 701 - Stand Still Message**



8. Do not move around while the device registers.

Once the data is collected and the Bluetooth beacon is registered, you are prompted to name the location.


**Figure 702 - Enter Location Description**



9. Type a Description and click OK.

The program confirms successful Bluetooth registrations.


Figure 703 - Success Dialog Box



10.Choose Manage>Manage IDs.

The Resolver Management dialog box appears, where the QR Code is registered and entered.


Figure 704 - Resolver Management



**Bluetooth Beacons Defined on an Android**


This is the procedure defines a Bluetooth beacon with an Android tablet.

- 1. Open the aTMC program on the Android tablet.

**Figure 705 - ThinManager aTMC Program**


2. Press Settings on the bottom.

The Settings dialog box appears.

**Figure 706 - Settings Menu**


3. Press Manage ThinServer.

The Choose ThinServer to Manage page appears.

**Figure 707 - Select Configuration**

4. Press the ThinManager Server on which you want to register the Bluetooth beacon.


The Settings page appears.

**Figure 708 - Register Bluetooth Beacon Command**

5. Press Register Bluetooth Beacon.

The Bluetooth beacons that the mobile device finds are listed on the Register Bluetooth page.



**Figure 709 - Available Bluetooth Beacons**


6. Press the desired Bluetooth beacon.

In [Figure 709](#), ACP-9059AF08ABF9 was selected.




This ThinManager Server is using ACP as a filter in the Relevance Settings dialog box. See [Bluetooth Beacons on page 478](#) for details.

The mobile device prompts you to go to the location that you want as the entrance point for the zone.


**Figure 710 - Stand At Zone Entrance Dialog Box**

7. Press Ready.

**Figure 711 - Please Wait Message**


It can take a few seconds to allow the device to read the signal strength to create the resolver data.

Once the data is collected and the Bluetooth beacon is registered, you are prompted to name the location.

**Figure 712 - Enter Location Description**

8. Type a Name for the location and click Ok.
9. Choose Manage>Manage IDs.

The Resolver Management dialog box appears with the Bluetooth beacon displayed.

**Figure 713 - Resolver Management Dialog Box**

## Wi-Fi Access Points

This resolver is based on the BSSID (a MAC type address) of the Wireless Access Point (WAP) that the mobile device is connected to at the time.

Relevance can use Wi-Fi access points as location resolvers. Wi-Fi Resolvers work well in situations where there are multiple access points. Membership of a network gives you access to functions in that area.


See [Fencing and Sub-Locations on page 437](#) for details.

## iPad-defined Wi-Fi Access Points

The Wi-Fi resolver is defined like a Bluetooth beacon.

1. Open the iTMC program on the iPad.

**Figure 714 - ThinManager iTMC Program**




- 2. Press Settings on the bottom.

The Settings menu dialog box appears.


- 3. Press Manage a Server.

The Select Server to Manage page appears.

**Figure 715 - Select Configuration**




- 4. Press the ThinManager Server on which you want to register the Wi-Fi resolver.

**Figure 716 - Settings Page of iTMC**

5. Press Register WiFi Access Point.

The Register Access Point page appears.


**Figure 717 - Available Wi-Fi Access Points**

The mobile device allows you to register the Wi-Fi Access Point you are connected to and list it on the Register Access Points page.

6. Press the access point.

Once the data is collected and the Wi-Fi access point is registered, you are prompted to name the location.


Figure 718 - Enter Location Description



7. Type a description and click OK.


The program confirms successful Wi-Fi registrations with a Success dialog box.

Figure 719 - Success Dialog



8. Choose Manage>Manage IDs.

The Resolver Management dialog box appears with the Wi-Fi resolver is registered and entered.




## Android-defined Wi-Fi Access Points

Wi-Fi access points are defined and registered like the Bluetooth beacon.

1. Open the aTMC program on the Android tablet.


**Figure 720 - ThinManager aTMC Program**



2. Press Settings on the bottom.

The Settings page appears.


**Figure 721 - Settings Menu**



3. Press Manage ThinServer.

The Choose ThinServer to Manage page appears.


**Figure 722 - Select Configuration**



4. Press the ThinManager Server with which you want to register the Wi-Fi network.


The Settings page appears.



**Figure 723 - Register Bluetooth Beacon Command**

5. Press Register Wi-Fi Access Point on the Settings page.

The Register WiFi BSSID dialog box appears.


**Figure 724 - Register Configuration**

The ThinManager Server lets you register the wireless network to which you are connected.

6. Press Register.


Once the Wi-Fi access point is identified, you are prompted to name the location.

Figure 725 - Enter Location Description



- 7. Type a Name for the Wi-Fi access point and press Ok to finish the registration process.

Figure 726 - Resolver Management Dialog Box



- 8. Choose Manage>Manage IDs.

The Resolver Management dialog box appears, where the Wi-Fi access point is registered and entered.

GPS

Relevance can use the Global Positioning System, or GPS, as a location resolver. The mobile program uses the built-in GPS system to identify the location.

The Global Positioning System resolver type works well for outdoor areas. It can be used to create a large Parent Location. Set it up so that you must be within the GPS area for other actions to take place.

When you assign the GPS resolver to a Location, you can set the range for altitude and radius from your initial point. This gives you the ability to create a rather large area for something like an oil field, a large processing facility, or

an entire building complex. You can also use it for finer resolution of individual buildings, tanks, pump jacks, or other smaller outdoor areas.


As you assign these types of resolvers, it is best to avoid overlap of GPS areas.

## iPad-Registered GPS

Define a GPS location similarly to how you define a Bluetooth beacon.

1. Open the iTMC program on the iPad.

**Figure 727 - ThinManager iTMC Program**




2. Press Settings on the bottom.

The Settings menu dialog box appears.

3. Press Manage a Server.

The Select Server to Manage page appears.


Figure 728 - Select Configuration



- 4. Press the ThinManager Server on which you want to register the GPS location.

The Settings page appears.

Figure 729 - Register GPS Location



- 5. Press Register GPS Location.

The Register Location page appears with the GPS listed on it after the mobile device finds it.

**Figure 730 - Available GPS Location**

The screenshot shows a mobile application interface titled "Register Location". At the top left is a blue back arrow and the word "Settings". The interface is divided into sections. The "COORDINATES" section contains three rows of data: "Latitude: 34.104179 (deg)", "Longitude: -84.240714 (deg)", and "Altitude: 326.762817 (m)". Below this is the "INFO" section with three rows: "Updated 0 seconds ago.", "Horz Accuracy: 65 meter radius.", and "Vert Accuracy: 10 meters". At the bottom of the screen is a large green button with the text "Tap Here To Register Location".

6. Press Tap Here To Register Location.

Once the data is collected and the GPS location registered, you are prompted to name the location.


**Figure 731 - Enter Location Description**

The screenshot shows the same "Register Location" screen as Figure 730, but with a modal dialog box open in the center. The dialog box is titled "Enter Description" and contains a text input field with the text "ACP-WHQ". Below the input field are two buttons: "Cancel" and "OK". The background of the screen is dimmed. At the bottom of the screen, a virtual keyboard is visible, showing letters, numbers, and symbols.

7. Type the Location Description.

The program confirms a successful GPS location registration.


**Figure 732 - Success Dialog**



8. Choose Manage>Manage IDs.

The Resolver Management dialog box appears with the registered GPS location displayed.


**Figure 733 - Resolver Management**



**Android-registered GPS**


GPS locations are defined and registered like the Bluetooth beacon.

- 1. Open the aTMC program on the tablet.

**Figure 734 - ThinManager aTMC Program**

2. Press Settings on the bottom of the page.


The Settings dialog box appears.

**Figure 735 - Settings Menu**

3. Press Manage ThinServer.

The Choose ThinServer to Manage page appears.


**Figure 736 - Select Configuration**



- 4. Press the ThinManager Server with which you want to register the GPS locations.

The Settings page appears.


**Figure 737 - Register GPS Location**



- 5. Press Register GPS Location.


The Register GPS Location page appears.



**Figure 738 - Register GPS Location**

6. Press Register.


Once the GPS location is identified, you are prompted to name the location.

**Figure 739 - Enter Location Description**

7. Type the Name of the GPS location and press OK to finish the registration process.
8. Choose Manage>Manage IDs.

The GPS location is registered and entered in the Resolver Management dialog box.


Figure 740 - Resolver Management




**Add Actions to  
Resolver Codes**

Resolvers can be applied to a location and have an action associated with them so that when a resolver is used, a particular action is launched.

Figure 741 - Location Configuration Wizard




1. Click the Locations icon at the bottom of the ThinManager tree.
2. Double-click a location to open the Location Configuration Wizard.

**Figure 742 - Relevance Resolver Selection Page**

3. Click Next until the Relevance Resolver Selection page appears.
4. Click Add.


The Choose a Relevance Resolver dialog box appears, which has a pull-down menu that lets you select which resolver to configure.

**Figure 743 - Choose a Relevance ID**

5. Check Only Show Unassigned Resolvers to limit the list to unassigned resolvers, which prevents duplication.
6. Choose a resolver from the Resolver Name pull-down menu.

The Resolver Type indicates whether it is a QR code, Bluetooth beacon, GPS, or Wi-Fi resolver.

**Figure 744 - Choose Action Selection**




There are six actions that can be applied to the Relevance ID.

Action	Description
Clone	Creates a new duplicate session using the mobile device Windows account.
Force Transfer	Automatically diverts the location graphic to the mobile device.
No Action	Initiates no new action.
Shadow	Provides an interactive shadow on the mobile device.
Transfer	Diverts the location graphic to the mobile device after operator input.
View Only Shadow	Provides a shadow without allowance of any input from the mobile device.

Each location can have several Relevance IDs with different actions.

**Figure 745 - Relevance ID Selection Page**



[Figure 745](#) shows a location with three QR codes, each with their own action. Scan a code to initiate the associated action.

Table 3 - QR Code Resolver Actions

QR Code Resolver	Action
QR-01	Shadow
QR-02	Force Transfer
QR-03	Clone




Normally, you use a single QR code and use Permissions to deploy the different functions. [Table 3](#) is just a simplified example to show the concept of different actions. See [One QR Code, Multiple Actions on page 454](#).

## Interact with the Location

The iTMC client can be used to interact with the location by a scan of the four resolvers configured with different actions in the previous example.

The iTMC screen has a menu bar at the top with several command buttons.

Figure 746 - iTMC Menu Bar




These are the button descriptions from right to left.

Button	Description
Switch (cascaded square)	Press to switch between two or more Display Clients.
Full Screen (four-arrow icon)	Press to make the display client full screen. Touch the screen with three fingers to restore the view.
Keyboard	Press to launch an on-screen keyboard.
Name	The center space displays the name of the Terminal, ThinManager user, or display client per the state of the Terminal.
Leave	Press to end the action that was initiated by the original scan.
Scan	Press to allow the scan window to act as a keyboard wedge to pull data into the session.
Scan ID	Press to open the Scan Identified window to scan QR codes to resolve a location or action.
Login	Press to open the Relevance login dialog box to allow you to log in with a ThinManager user name.
Menu	Press to launch the Main Menu screen.

1. Press Main Menu.

The Main Menu appears.

Figure 747 - Main Menu




The Main Menu has a variety of functions. The state of the application determines what is displayed.

Function	Description
ACTIONS	
Login User	Press to launch a dialog box to log in as a ThinManager user.
Login Location	Press to manually select a location.
Scan ID	Press to open the Scan Identified window to scan QR codes to resolve a location or action.
Scan	Press to allow the scan window to act as a keyboard wedge to pull data into the session.
INFORMATION	
Info	Provides version numbers and lists gestures to navigate the program.
About	Launches a dialog box with user, location, and network information.
View Bluetooth Beacons	Lists the Bluetooth beacons within range and their signal strength.
View WiFi Access Point	Lists the BSSID of the Wi-Fi network to which you are connected.
Hide Map When Zoomed	Normally, when the screen is zoomed, a map is provided so you can determine the part of the screen that is viewed. This feature hides the map during a zoom.


Shadow

A Shadow duplicates the graphic output of the location and sends it to the mobile device. The mobile user sees the exact display as the location. See [Figure 748 on page 509](#).

**Figure 748 - Shadow**


1. Launch the iTMC application.
2. Select your ThinManager Server on the configuration screen to run your iPad as a Terminal.

The Main Screen has a menu bar at the top with Main, ScanID, Login, and Menu.

**Figure 749 - ThinManager iTMC Main Screen**

3. Press ScanID in the upper-right of the menu bar.

The Scan Identifier screen, which is the onboard camera, appears.

**Figure 750 - Scan Identifier**

4. Position the camera over the resolver code.


The device reads the code and acts on it.



The image of the QR code is blurry because it registers and closes as soon as it is in focus.

The iTMC client now shadows the location because the resolver had the shadow action applied to it.

**Figure 751 - Shadowed Session on iTMC Client**



5. Press Leave to end the Shadow action.

## Forced Transfer

Transfer sends the graphic output of the location to the mobile device instead of the location. Transfer can be done automatically with Forced Transfer or set to require the operator to manually allow the transfer.

Forced Transfer takes control without operator input, which prevents someone from taking the session while the operator is busy with a process. It also allows a mobile user to take sole control of the location.

**Figure 752 - Forced Transfer**




1. Launch the iTMC application.
2. Select your ThinManager Server on the configuration screen to run your iPad as a Terminal.



The Main Screen has a menu bar at the top with Main, ScanID, Login, and Menu.


**Figure 753 - ThinManager iTMC Main Screen**



3. Press ScanID near the upper-right corner.

The Scan Identifier screen, which is the onboard camera, appears.

**Figure 754 - Scan Identifier**




4. Scan the resolver associated with Forced Transfer. The display is ported to the mobile device.



The image of the QR code is blurry because it registers and closes as soon as it is in focus.

The display from the location is moved to the mobile device.

**Figure 755 - Transfer on the Mobile Device**



When the action of the resolver is Forced Transfer, the display at the location is automatically transferred to the scanning iTMC client.

**Figure 756 - Forced Transfer at Location**



5. Press Leave in the top menu bar or Leave Location on the Main Menu to end the transfer.

A message box is displayed on the client to explain that the display is transferred.


Figure 757 - Main Menu at the Location



- 6. If you want to recall the display, go to the location and press Restore Location.

The iTMC client displays a Location Logoff dialog box when a restoration request is initiated.

Figure 758 - Location Logoff Dialog Box



Setting	Description
Yes	Press to allow the restoration of the display.
No	Press to refuse the restoration of the display.
More Time	Press to send a request to the location for more time. The location gets a message with Yes and No, which provides the power to allow more time or end the transfer.

Transfer

Transfer sends the graphic output of the location to the mobile device instead of the location. Transfer can be done automatically with Forced Transfer or set to require the operator to manually allow the transfer.

Transfer requires operator input to allow the transfer, which prevents someone from taking the session while the operator is busy with a process. Also, it allows a mobile user to take sole control of the location.

**Figure 759 - Transfer**


1. Launch the iTMC application.
2. Select your ThinManager Server on the configuration screen to run your iPad as a Terminal.

The Main Screen has a menu bar at the top with Main, ScanID, Login, and Menu.

**Figure 760 - ThinManager iTMC Main Screen**

3. Press ScanID in the right part of the menu bar.

The Scan Identifier screen, which is the onboard camera, appears.

**Figure 761 - Scan Identifier**


4. Scan the resolver associated with Transfer.

A request for transfer is sent to the location.



The image of the QR code is blurry because it registers and closes as soon as it is in focus.


A message is sent to the mobile device, which tells it that the location must respond.

**Figure 762 - Transfer Notification**

The scan initiates the transfer—this is not a forced transfer, but a manual transfer—which requires confirmation at the location.

The operator at the location is shown a dialog box that requires approval to transfer.

**Figure 763 - Location Logoff Dialog Box**




5. The operator at the location clicks Yes to allow the transfer.

The iTMC client is allowed to show the location display, which is moved from the location to the mobile device.


The location display can be restored from the iTMC client or the location.

**Figure 764 - Transfer on the Mobile Device**




6. Press Leave on the iTMC client menu to restore the display to the location.

**Figure 765 - Main Menu at the Location**



- a. Alternatively, the operator at the Location, can click Restore Location on the Main Menu to restore the display.


On the iTMC client, the Location Logoff dialog box appears, which asks whether to transfer location display to another device.

**Figure 766 - Location Logoff on the Mobile Device**

7. On to the iTMC client, press Yes to allow the transfer to the location.

## Clone

Clone duplicates the display clients of the location on the mobile device, but the sessions are created with the mobile device Windows user account.


**Figure 767 - Clone**

Clone allows a mobile user to get the HMI or other software and have independence from the user at the location.

1. Launch the iTMC application.
2. Select your ThinManager Server on the configuration screen to run your iPad as a Terminal.

The Main Screen has a menu bar at the top with Main, ScanID, Login, and Menu.


**Figure 768 - ThinManager iTMC Main Screen**



3. Press ScanID on the right side of the menu bar.

The Scan Identifier screen, which is the onboard camera, appears.


**Figure 769 - Scan Identifier**




4. Scan the resolver associated with Clone.

Relevance launches the display clients used at the location on the mobile device, but uses the mobile device account. Clone gives a mobile user the same applications as the location, but with an independent session instead of a shared as in Shadow. Clone does not take the session as in Transfer and Forced Transfer.



**Figure 770 - Cloned Session**

[Figure 770](#) is a shadow from ThinManager that shows the Terminal logged in as Admin2.

**Figure 771 - Cloned Session**

Clone duplicates the sessions on the location, but creates the sessions with the Windows user account of the mobile device.

[Figure 771](#) shows the iPad clone of the 2\_Terminal, which runs the same applications, but logs in with the Windows account of the iPad, which is Admin5.

**Notes:**

## Events

ThinManager Events ensure relevant visual content is presented, or ThinManager administrative tasks are completed, subsequent to an occurrence of an external source. The Event source can be any software that uses ActiveX and is defined in the ThinManager Event Property Wizard with simple logic. ThinManager Events provide the ability to Add, Remove, Switch, or Tile a Display Client on a Terminal based on an Event or multiple Events. It also allows the ability to add or remove permissions of a specific Access Group on a Terminal based on an Event or multiple Events. Also, expressions of various Events can be grouped if needed.

ThinManager Events can be accessed from the ThinManager Events \_\_\_\_ from the tree [insert navigation tree here].

### Create a ThinManager Event

Follow these steps to create a ThinManager Event. These steps are not



These steps are not inclusive and may require additional VBA or other configuration in the external software (source of Event).

1. Right-click on ThinManager Event > Add Event.

The ThinManager Event Property Wizard appears, opened to the Event Name page.

Figure 772 - Event Name Page

Fields	Description
ThinManager Event Name	This is an organizational name only. It does not impact the operation of the event.
Buttons	
Add	Opens the Define Match Condition page to create a new Match Expression
Delete	After the undesired Expression is selected, this action permanently removes it
Edit	After an Expression is selected, the Define Match Condition page appears, where modifications can be made
Move Up	Changes the presentation order of an Expression
Move Down	Changes the presentation order of an Expression
Start Group	Denotes the start of a Group of Expressions
End Group	Denotes the end of a Group of Expressions

2. Enter a ThinManager Event Name.
3. Click Add.

The Define Match Condition Wizard appears.

Figure 773 - Define Match Condition

Define Match Condition

Property Name

Compare Operation

=

Compare Value Type

Int

Compare Value

Logical Operation

AND

OK

Cancel

Fields	Description
Property Name	This value should match the value of a User Defined Variable that originated from whichever host has the Termon ActiveX embedded and enabled
Compare Operation	Shows the comparison functions used against the Property Name value in text field of the page. Operations include: <ul style="list-style-type: none"> <li>= (equal)</li> <li>!= (not equal)</li> <li>&gt; (greater than)</li> <li>&lt; (less than)</li> <li>begins with</li> <li>contains</li> <li>matches pattern</li> </ul>
Compare Value Type	Select the type of value to use in the Compare Value field: Int, Real, or String
Compare Value	This value is used to compare against the Property Name value
Logical Operation	Use to combine or create a larger Expression

Define Match Condition is the Expression created for the Event.

- Enter the Property Name.



The Property Name must match the user-defined variable of the external software that uses ActiveX (source of Event).

- Set the Compare Operation, Compare Value Type, Compare Value, and Logical Operation based on desired outcome.



The Logical Operation field is only relevant when multiple expressions are combined.

- Click OK.

The Define Match Condition Wizard closes, and you are returned to the ThinManager Event Property Wizard.

- Click Next.
- From the pull-down menu, select the ThinManager Event Action to occur when the set logical expression is executed.
- Click Edit for the available parameters based on the Event Action.
- Click Finish.

When the Event expression is true, the set ThinManager Event Action occurs. No additional terminal or user configuration is necessary.

**Notes:**

## Packages

### Firmware, Packages, and Modules

Firmware is the basic operating system that thin clients run. It is downloaded and expanded into memory, where it serves as an operation system.

Modules bring additional functionality to the thin client such as touch screen integration, keyboard, and sound.

Packages contain a version of firmware and the modules that belong with it.

In the past, ThinManager made all of the firmware changes backward compatible so that a 12-year-old x86 thin client could run the same firmware as the latest model of thin client. This limited what ThinManager could do to take advantage of new hardware.

ThinManager 6.0 introduced a new approach to firmware and modules called Packages. ThinManager has the ability to run different versions of the firmware on different thin clients. Legacy thin clients can run Package 5 that is equal to the ThinManager 5 firmware while newer thin clients can run Package 6 and later. As new hardware is released, you are able to run even newer packages to take advantage of new features.

A package, the firmware version and the modules that go with it, can get assigned by default to a thin client, or you can override the setting and run a different package.

This is particularly helpful in validated systems. If new hardware is purchased that requires new firmware, you can assign a new package to the new hardware while the existing thin clients can continue to run the original validated package.

Packages, firmware, and modules are included with ThinManager and are registered automatically during ThinManager installation and service package updates. Packages may be updated occasionally and can be downloaded from the ThinManager web site at <http://downloads.thinmanager.com/> and applied to ThinManager.

## Update Packages and Files

ThinManager allows updates of Packages. Also, you can update just the firmware or specific modules if needed.



Firmware and modules get updated automatically during Service Pack upgrades. This section shows how to update firmware and modules without an update to a Service Pack.

1. Download new components from the ThinManager web site at <http://downloads.thinmanager.com/>.
2. Choose Install>Firmware Package from the ThinManager menu bar.

A file browser appears, which allows you to install a \* .pkg file.

3. Choose Install>Firmware.

A file browser appears, which allows you to install a \* .fw file. Also, you can use this command to load a new version of the legacy `firmware.acp` firmware file

4. Choose Install>Module.

A file browser appears, which allows you to install a \* .mod file.

ThinManager uses a Boot Loader and a Chain Loader during PXE boot.

5. Choose Install>Boot Loader.

A file browser appears, which allows you to install a \* .bin file.

6. Choose Install>Chain Loader.


A file browser appears, which allows you to install a \* .bin file.

ThinManager uses a Terminal Capabilities Database, or TermCap, to aid in configuring the thin clients.

7. Choose Install>TermCap Database.

A file browser appears, which allows you to install a \* .db file.




**Figure 774 - Package Installation**

8. Choose Install>Firmware Package.

A file browser appears, which allows you to install a \*.pkg file.

[Figure 774](#) shows a folder with three firmware package versions.

9. Highlight the desired firmware package and click Open.

**Figure 775 - Firmware Installation**

10. Choose Install>Firmware.


A file browser appears, which allows you to install a \*.fw file.

a. Also, use this command to load a new version of the legacy firmware.acp firmware file.

[Figure 775 on page 527](#) shows a folder with several versions of firmware.

11. Highlight the desired firmware and click Open.

**Figure 776 - Module Installation**



12. Choose Install>Module.

A file browser appears, which allows you to install a \*.mod file.

[Figure 776](#) shows a folder with two sound modules.

13. Highlight the desired module and click Open.


## Customizing Packages

ThinManager allows you to run different packages on different models or individual Terminals. You can modify a package by copying it and making changes to it.

Modules and packages are normally updated with service packs and releases. You can download updated modules at <http://downloads.thinmanager.com/> when needed.


1. Choose Manage>Packages.

The Package Manager appears.

**Figure 777 - Package Manager**


2. Click Edit Packages.

The Edit Firmware Packages dialog box appears.

**Figure 778 - Edit Firmware Packages Dialog Box**

3. Choose the package version you want from the Select Package pull-down menu to modify in the Select Package dialog box and click Copy.


The Package Name dialog box appears.

**Figure 779 - Package Name Dialog Box**

4. Type a name for the new package in the Enter name of new package field.


Success is confirmed in the Copy Firmware Package dialog box.

Figure 780 - Success Dialog



- 5. Click OK.
- 6. Click Done on the Edit Firmware Packages and OK on the Package Manager dialog boxes.

Figure 781 - Modules Dialog Box




- 7. Choose Install>Modules.

The Modules dialog box for that server appears.


- 8. Click Install Module.

A file browser appears, which you can use to navigate to your downloaded modules.

**Figure 782 - File Browser**

9. Highlight the needed module and click Open.

A dialog box appears, which allows the selection of a package you want to add the module.

**Figure 783 - Select Firmware Package Dialog Box**


10. Highlight your copied module and click Install.

The new module is added to that package.

11. Click Done on the Modules dialog box to finish.

You can lock a package on the Edit Firmware Packages window.

Figure 784 - Edit Firmware Packages Dialog Box



12. Choose Manage>Packages on the ThinManager menu bar.

The Package Manager dialog box appears.

13. Click Edit Packages.

The Edit Firmware Packages dialog box appears.

14. Choose the package from the Select Package pull-down menu and check Lock.

The package is locked.


Configure Packages for a Model of Thin Client

ThinManager allows you to change the package for all units of a make and model.

1. Choose Manage>Packages.

The Package Manager dialog box appears.

Figure 785 - Package Manager



2. Choose your Manufacturer and Model from the pull-down menus.
3. Choose the Package you want from the pull-down.


This becomes the Model Default.

4. Click OK.

The Package Manager dialog box closes.


Older makes and models have fewer options than newer, more powerful makes and models.

**Figure 786 - ACP DC-30-100 Firmware**




[Figure 786](#) provides an example of limited package availability for the DC-30-100, an older model, as it can only run package 5. This is set in the TermCap as the default package.

**Figure 787 - ACP TC3500 Firmware**



[Figure 787](#) shows package options for the more recent ACP TC3000, which can run several versions of firmware and custom firmware.

**Figure 788 - New Default Firmware**


The firmware package chosen from the Package pull-down menu sets that firmware as the default to run on any Terminal of that make and model.

## Configure Packages for an Individual Thin Client

Packages can be changed for an entire series of thin clients or for an individual thin client. This change is done in the Package Manager dialog box.

1. Choose Manage>Packages.

The Package Manager dialog box appears.

**Figure 789 - Package Manager**

2. Check Allow the setting of the Package in Terminal Configuration, which allows you to override an individual thin client's package setting.
3. Click OK.

The Package Manager dialog box closes.

4. Double-click on the Terminal in the Terminal branch of the ThinManager tree.

The Terminal Configuration Wizard appears.

5. Click Next until the Terminal Hardware page appears.



**Figure 790 - Terminal Firmware Package Setting**

**Terminal Configuration Wizard**

**Terminal Hardware**  
Select the manufacturer and model of this terminal.

Use this to configure the type of hardware for this terminal.

Make / OEM: ACP  
Model: TC3000  
OEM Model: TC3000  
Video Chipset: S3 Savage4

Terminal Firmware Package: Model Default  
Terminal will run Package 6\_B

Terminal ID and IP Address  
Terminal ID: None  
Clear  
Edit

< Back   Next >   Finish   Cancel   Help

The Terminal Firmware Package pull-down menu allows you to pick a different package to run once you allow individual firmware on the Package Manager dialog box.

[Figure 790 on page 535](#) shows that Package 6\_b that was used in the previous example.

Once the firmware setting is allowed on the Package Manager dialog box, it appears in the Terminal Firmware Package pull-down menu on the Terminal Hardware page, which allows you to choose it for that individual Terminal.

**Figure 791 - New Terminal Firmware Package Setting**

**Terminal Configuration Wizard**

**Terminal Hardware**  
Select the manufacturer and model of this terminal.

Use this to configure the type of hardware for this terminal.

Make / OEM: ACP  
Model: TC3000  
OEM Model: TC3000  
Video Chipset: S3 Savage4

Terminal Firmware Package: Model Default

Terminal ID and IP Address

Terminal ID: None

5  
6  
6\_B  
7  
7\_B  
Model Default

Edit

< Back Next > Finish Cancel Help

6. Choose the Terminal Firmware Package from the pull-down menu.
7. Click Finish.

The Terminal Configuration Wizard closes.

8. Highlight the Terminal in the ThinManager Servers tree and choose Tools>Reboot from the ThinManager menu.

The Terminal reboots, and the ThinManager splash screen for that firmware is displayed.

## Modules

Modules are components and drivers for the Terminals that are not needed for the basic boot but can be added to enhance the features and functions of the Terminals.

Modules are added to Terminals individually or through Terminal Groups.

ThinManager divides the modules into a number of categories, or types, to make navigation of the module list easier. Although details on the specific modules follow, the types and modules include the following.



Certain modules are used in limited, specific cases and are considered advanced modules. These are marked with a (\*). See Advanced Modules for details.

This manual covers the details of a dozen modules. The first covers the general steps with the Key Block Module. The other modules cover the individual configuration.

## Module List

ICA\* - see [ICA Modules on page 542](#).

- Citrix ICA UseAlternateAddress Module
- Citrix ICA wfclient.ini Extension Module

Keyboard – See [Keyboard Modules on page 543](#).

- Key Block Module
- Key Block Single Key Module
- Keyboard Configuration Module
- On-Screen Keyboard Configuration Module
- RF Ideas pcProx USB Module
- Share Keyboard and Mouse Controller Module
- Share Keyboard and Mouse Follower Module

Language - See [Language Modules on page 546](#).

- Language Selection Module

Local Storage - See [Local Storage Modules on page 546](#).

- USB Flash Drive Module
- USB Memory Card Reader Module (Package 5 only)

Miscellaneous - See [Miscellaneous Modules on page 548](#).

- Add Serial Port
- Bluetooth Module

- Firmware Update Module
- Local Printer Module
- MultiStation Configuration Module
- Redundant Ethernet Module
- Serial to TCP Module
- TermMon ActiveX Configuration
- Time Zone Redirection Module
- TMTerm DLL Configuration Module
- USB to Serial Module
- User Override Module

Mouse - See [Mouse Modules on page 553](#).

- Locate Pointer Module
- Mouse Configuration
- Serial Mouse Driver
- Share Keyboard and Mouse Controller Module
- Share Keyboard and Mouse Follower Module

Network - See [Network Modules on page 554](#).

- Domain Name System Module
- Second Network Module
- Third Network Module

RDP - See [RDP Modules on page 556](#).

- RDP Experience Module
- RDP Port Module
- RDP Serial Port Redirection Module
- RDP Session IP Module
- Smart Cart Module

Relevance - See [Relevance Modules on page 557](#).

- Bluetooth Module
- DigitalPersona UareU Fingerprint Reader
- RF Ideas pcProx Module
- RF Ideas pcProx USB Module
- RF Ideas pcProx Sonar Module
- TermMon ActiveX Configuration Module
- USB Flash Drive Module
- USB ID Reader Module

Screen Saver - See [Screen Saver Modules on page 564](#).

- MultiSession Screen Saver Module
- Screen Saver Module

Sound - See [Sound Modules on page 566](#).

- Universal Sound Module

TermSecure - See TermSecure Modules

- Bluetooth Module
- DigitalPersona UareU Fingerprint Reader
- RF Ideas pcProx Module
- RF Ideas pcProx USB Module
- RF Ideas pcProx Sonar Module
- TermMon ActiveX Configuration Module
- USB Flash Drive Module
- USB ID Reader Module

Touch Screen - See [Touch Screen on page 568](#).

- Arista ARP-16XXXAP-ACP Touch Screen Driver
- CarrollTouch Touch Screen Driver
- Contec Touch Screen Driver (Package 5 only)
- DMC Touch Screen Driver (Package 5 only)
- DMC TSC Series Touch Screen Driver
- Dynapro Touch Screen Driver
- eGalax Touch Screen Driver
- Elographics Touch Screen Driver
- Gunze AHL Touch Screen Driver
- Hampshire TSHARC Touch Screen Driver
- Intra-T Touch Screen Driver
- MicroTouch Touch Screen Driver
- Panjit TouchSet Touch Screen Driver
- PenMount Touch Screen Driver
- Ronics Touch Screen Driver (Package 5 only)
- Touch Control Touch Screen Driver
- Touch International IR Touch Screen Driver (Package 5 only)
- USB Touch Screen Driver
- Xycom 33XX Touch Screen Driver (Package 5 only)
- Zytronic Touch Screen Driver

Video Driver - See [Video Driver Modules on page 571](#).


- Custom Video Mode Module
- Monitor Configuration Module

## Add a Module

1. Double-click on your Terminal.


The Terminal Configuration Wizard appears.

2. Click Next until the Module Selection page appears.

**Figure 792 - Module Selection Page**


3. Click Add.

The Attach Module to Terminal dialog box appears.

**Figure 793 - Attach Module to Terminal Window**

Modules can be viewed by category or as a whole.

4. Choose a module category from the Module Type pull-down menu.
5. Highlight a module and click OK.


**Figure 794 - Key Block Module**

[Figure 794](#) shows the Key Block Module in the Installed Modules pane.

The Key Block Module has configurable settings.

6. Highlight the Key Block Module and click Configure.

The Module Properties dialog box appears, in which settings can be configured.


**Figure 795 - Module Properties**

7. Use the pull-down menu to change a parameter or type a new setting.

By default CTRL+ALT+DEL, CTRL+ALT+ESC, and CTRL+ESC are blocked.

- a. To change other key combinations, change the respective pull-down value to Yes.
- 8. Click Done to close the Module Properties dialog box.

Figure 796 - Modules Tab for a Terminal



The module and settings are displayed on the Modules tab when the Terminal is highlighted.



The 3\_Terminal shows the red Configuration Indicator icon to indicate that the configuration changed when the module was added, but it has yet to be restarted to load the new configuration.

Individual Module Details

ThinManager divides the modules into a number of categories or types to make navigation of the module list easier. The types and modules include ICA, Local Storage, Miscellaneous, Mouse, RDP, Screen Saver, Sound, TermSecure, Touch Screen, and Video.

ICA Modules

ICA Modules are advanced modules for advanced users of the ICA client communication protocol.

Citrix ICA UseAlternateAddress Module

The Citrix ICA UseAlternateAddress Module is used by advanced Citrix users to specify connections to Citrix Servers.

Configuration includes Use Alternate Address, Browser Protocol, and HttpBrowser Addresses.



### *Citrix ICA wfclient.ini Extension Module*

The Citrix ICA wfclient.ini Extension Module is used by advanced Citrix users. This module allows up to 8 strings of text to be added to the wfclient.exe for passing Citrix parameters.

## Keyboard Modules

Keyboard Modules are modules used to control or alter keyboard behavior.

### Key Block Module

The Key Block module traps certain keystrokes and prevents them from being sent to the Remote Desktop Server for processing.

Key combinations to be blocked can be configured by in the Module Properties. To launch Module Properties, follow these steps.

1. Highlight the module on the Module Selection page and click Configure.

A Module Properties dialog box appears.


2. Choose the parameter to change in the Module Properties dialog box and choose the Value in the pull-down menu.

The key combinations that have a value of YES are blocked from reaching the Remote Desktop Server.

### Key Block Single Key Module

The Key Block Single Key Module lets you block a single key combination from being sent from the Terminal to the session.

**Figure 797 - Key Block Single Key Module Properties**



Add and configure the Key Block Single Key Module to block a single set of key combinations.


You can set ALL, CTRL, ALT, or CTRL+ALT as the modifier key(s) and set A-Z, F1-F12, and ESC, Tab, Backspace, and so on as the key to block.

If you have multiple keys to block, add the Key Block Single Key Module once for each combination and configure them accordingly.

Keyboard Configuration Module

The Keyboard Configuration Module allows you to set the keyboard language and control the behavior of the Caps Lock and Number Lock on the Terminal.

Figure 798 - Keyboard Configuration Module Properties



The Keyboard Configuration parameters include the following.

Parameters	Description
Num Lock State	Allows the Number Lock to be set to On at startup, Off at startup, always On, or always Off.
Cap Lock State	Allows the Caps Lock to be set to On at startup, Off at startup, always On, or always Off.
Scroll Lock State	Allows the Scroll Lock to be set to On at startup, Off at startup, always On, or always Off.
Repeat Delay (ms)	Sets the amount of time that a key needs to be held down before it starts repeating the keystroke. If this parameter is set to Disable, a key sends only one keystroke even if the key is held down.
Repeat Rate (char/sec)	Sets the number of characters per second that a held down key sends.
Disable Repeat for Enter Key	When set to Yes, it prevents the Enter key from repeating if it is held down.
Keyboard Layout	Allows the thin client to use keyboards other than the default English (United States) keyboard map.

On-Screen Keyboard Module

The On-Screen Keyboard Module allows you to configure an on-screen keyboard for touch screens. The configuration of the launch of the keyboard through a long touch or hold is done within the Touch Screen Module. The

settings in the on-screen keyboard are configured in the On-Screen Keyboard Module.

Parameters	Description
Show Keypad	Adds the keypad to the display.
Show Function Keys	Adds the function keys to the display.
Show Control Key	Adds the Control key to the display.
Show Alt Key	Adds the ALT key to the display.
Num Lock State	Turns the numbers lock on or off on launch.
Inactivity Timeout (seconds)	Sets the duration of the idle time that closes the keyboard.
Keyboard Scale Percentage	Sets the width of the keyboard as a percentage of the screen.
Font Size	Sets the font size of the keys.

## RF Ideas pcProx USB Module

The RF Ideas pcProx USB Module uses a USB device that allows a Terminal to use RF Ideas pcProx cards as TermSecure ID cards.

ThinManager supports the RDR-xx81AKx family of card readers from RFIdeas. These include the serial RDR-6081AK2 reader and RDR-6081AKU (Package 5, 6, or 7), RDR-80582AKo (Package 6 or 7), and RDR-80081AKU (Package 7.1.4 and later) USB readers.

These are the parameters.

Parameters	Description
<b>Mode</b>	Allows the device to be used in TermSecure Mode, Wedge, or TermMon mode.
TermSecure	Sends data to ThinManager for use with TermSecure.
Wedge	Sends data straight to the session as a keyboard wedge.
TermMon	Sends data to the TermMon ActiveX that you embed in your application.
Allow Manual TermSecure Login	When set to Yes, allows a ThinManager user to log in to a Terminal without a TermSecure ID device. If set to No, TermSecure users must use a TermSecure ID device to log in.
Prompt for TermSecure Password	When set to Yes, requires a TermSecure user to enter their password for access even if the password is configured in ThinManager.

See [Card and Badge Configuration for a ThinManager User on page 393](#) for details.

## Share Keyboard and Mouse Module

The Share Keyboard and Mouse Module allows several thin clients to be controlled with a single keyboard and mouse without the need of a KVM switch (Keyboard/Video/Mouse).

Share Keyboard and Mouse has a Controller module that is added to the controlling Terminal and a Follower module that is added to the dependent Terminals.

Share Keyboard and Mouse allows you to place several monitors connected to thin clients, side-by-side or top-to-bottom. The Share Keyboard and Mouse Controller module is loaded on the center thin client.

1. Add the IP addresses of the secondary follower thin clients to configure it.

The other Terminals receive the Share Keyboard and Mouse Follower module.

2. Once the Share Keyboard and Mouse Controller Module is added to a Terminal, highlight it in the Installed Module dialog box and click Configure.

These are the configuration settings.

Setting	Description
Left Terminal IP Address	Enter the correct IP address for the Follower Terminal on the left of the Controller Terminal, if used, and click Set.
Right Terminal IP Address	Enter the correct IP address for the Follower Terminal on the right of the Controller Terminal, if used, and click Set.
Top Terminal IP Address	Enter the correct IP address for the Follower Terminal on the top of the Controller Terminal, if used, and click Set.
Bottom Terminal IP Address	Enter the correct IP address for the Follower Terminal on the bottom of the Controller Terminal, if used, and click Set.
Allow Interactive Shadow of Controller	Normally, a Terminal with the controller module loaded is blocked from interactive shadow. If you want to allow interactive shadowing on the Controller, highlight the Allow Interactive Shadow of Controller parameter, choose Yes from the Value pull-down menu, and click Set.
Controller IP Address	Enter the IP address of the Controller Terminal and click Set to allow the follower module to be configured to connect to a specified Controller.

The Share Keyboard and Mouse Follower module is loaded on the secondary thin clients using the same methods in which other modules are loaded.

3. Click Done when finished.

Once the ThinManager Enabled thin clients are booted, the mouse on the controller thin client can be moved seamlessly into the other desktops. The keyboard is active on whatever screen the mouse pointer is present.

This feature allows an operator to have control of several displays with only one keyboard and mouse. The mouse movement is seamless, which allows access to displays without switching.



A Controller Share Keyboard and Mouse session cannot be interactively shadowed in ThinManager unless it is configured to allow it.

The keyboards and mice for the follower thin clients can be left attached but stowed away until a multi-user configuration is needed.

## Language Modules

The Language modules allow different languages to be used by the terminal.

### Language Selection Module

The Language Selection Module sets the language on the terminal. You can use the Keyboard Configuration module to set the keyboard language and set the language in the session.

## Local Storage Modules


The Local Storage modules allow the use of USB ports on thin clients. By default, the USB ports are not active for security reasons.

## USB Flash Drive Module

By default, USB ports are disabled in the ThinManager system. You can use the USB ports for keyboards and mice, but not USB flash drives. For USB flash drives, you need to allow the port to be used with the USB Flash Drive Module.

Also, the USB port works with a device that functions as a keyboard wedge.

**Figure 799 - USB Flash Drive Module Properties**



The USB Flash Drive Module has several parameters.

Parameter	Description
Drive Access Rights in Session	<ul style="list-style-type: none"> <li>ReadWrite allows the user to read and write to the flash drive</li> <li>ReadOnly allows the user to read data, but not write data</li> <li>None sets the flash drive to access only the unique serial number to make it usable as a TermSecure ID device</li> </ul>
Use with TermSecure	<ul style="list-style-type: none"> <li>YES allows the device to be a TermSecure identifier</li> <li>NO in conjunction with a ReadWrite Access Rights allows the device to be used as a remote storage drive</li> </ul>
Allow Manual Login	<ul style="list-style-type: none"> <li>Yes allows a ThinManager user to log in to a Terminal without a TermSecureID device</li> <li>No requires TermSecure users to use a TermSecure ID device to log in</li> </ul>
Prompt for Password	Yes requires a ThinManager User to enter their password for access even if the password is configured in ThinManager.



USB does not map to the session like serial does. If you want to add a USB device that requires a driver to be installed, such as a printer, you can use an IP-to-USB converter that allows you to address the device and mount the drives from the session.

## USB Memory Card Reader Module

The USB Memory Card Reader Module allows USB card readers to connect to a Terminal.

These are the USB Memory Card Reader Module parameters.

Parameter	Description
Number of Slots in Reader	Sets the number of slots that the card reader uses.
Read Only Access	<ul style="list-style-type: none"> <li>• Yes limits the user to reading the card.</li> <li>• No allows the user to read and write to the card.</li> </ul>

## Miscellaneous Modules

These are modules that do not fit into other categories.

### Add Serial Port

The Add Serial Port Module is used only to configure the serial ports of daughter boards that add additional serial ports to Terminals.

1. Add a module for each additional serial port.

Each module lets the user configure one additional port.

These are the Add Serial Port Module parameters.

Parameter	Description
Port Number	Set to the port number of the new port.
Port Address	Set to the port address of the new port.
IRQ	Set to the IRQ of the new port.
UART	Set to the chipset type for the new port.

### Barcode Configuration Module

This module sets the protocols that a tablet uses to scan barcodes.

### Bluetooth Module

See the [Relevance Modules on page 557](#) for more information.

### Firmware Update Module

The Firmware Update module allows a ThinManager-ready thin client with an embedded firmware to be updated.

ThinManager enables some models of Terminals to store the firmware with Disk On Chip or Compact Flash storage so that the unit does not have to download the entire firmware at boot. Instead, the unit can boot locally and download just the configuration to save bandwidth. This is most commonly used with units that connect over low-bandwidth networks, like wireless networks or WANs. These units can use the Firmware Update module to download and flash new firmware when the firmware is updated in ThinManager.

The ability to update stored firmware Terminals eliminates the need to send the Terminal back to the manufacturer to update the firmware.



The firmware download can vary depending on the bandwidth of the connection and the size of the update. It is recommended that updates be done over a wired LAN versus a wireless connection.

The Firmware Update module has three configurable parameters.

Parameter	Description
Confirm at Terminal	<ul style="list-style-type: none"> <li>• Yes prompts the operator to choose between an immediate firmware update or an update at the next Terminal boot.</li> <li>• No causes the firmware download to take place immediately.</li> </ul>
Force Update	Yes forces the Terminal to always download the firmware for an update. Ordinarily, a stored firmware Terminal with the Firmware Update module checks firmware version numbers at boot and only downloads a new firmware if the versions are different.
Disable Update	Prevents the download and flash of a new firmware if it is installed. This allows the administrator to select the time of update instead of an automatic update.



The module downloads firmware when it detects a different firmware. Since this only happens at the first reboot after updating the ThinManager firmware, it is safe to leave this module added to Terminals permanently when Force Update is set to No. It does not need to be added and removed each time the firmware is updated. However, since it updates when the firmware is different, it tries to update the firmware if you boot it from a ThinManager server with older firmware.

### *Firmware Update Program*

Once the new firmware is downloaded, an update program runs on the Terminal to rewrite the new firmware to the storage. The program displays a warning, which state that the Terminal must not be reset or powered off during the process, which usually takes around 30 seconds. If you ignore the warning, the stored firmware can be corrupted; so, it is important to leave the Terminal alone for that time period.

---

**IMPORTANT** The Terminal must not be reset or powered off during the brief period that the update program writes the firmware to the firmware storage device. It is recommended that you update firmware over a wired LAN versus a wireless connection.

---

### *Stored Firmware Terminal Configuration*

A stored firmware Terminal loads the firmware locally before it connects to the ThinManager server. The stored firmware Terminals have a setup program that allows configuration of the connection.

1. Press any key to enter the program when prompted during the boot process.

A setup screen is displayed.

2. Save or discard changes before the boot process resumes.

## **Instant Failover Module**

The Instant Failover Module is to be used only with Terminal configurations that use the legacy “Individual Remote Desktop Servers” method instead of the preferred Display Clients method.

Since the use of Display Clients is a preferred method of getting Remote Desktop Services sessions versus using the legacy “Individual Remote Desktop Servers,” the module is hidden from view unless Show Advanced Modules is checked.

Instant Failover allows a Terminal to connect to a session on two Remote Desktop Servers. Both sessions are active, but only one is displayed. If the first Remote Desktop Server fails, the second session is displayed immediately, which eliminates any downtime due to Remote Desktop Server failure. See [Instant Failover on page 154](#) for details.



The Instant Failover Module is used only with Terminals that use Individual Remote Desktop Servers. Terminals using Display Clients have Instant Failover checked in order to use it. (See [Figure 156 on page 126](#)).

**Do not use the Instant Failover module while using Display Clients.**

The Instant Failover function requires an Instant Failover license for each Terminal that uses it.

#### *Instant Failover Configuration with Use of Individual Remote Desktop Servers*

The thin client cascades both sessions, with the primary in front. You cannot see the secondary session as it is hidden behind the primary session. There is an option that allows one to switch between sessions with a hot key.

Parameter	Description
Hot Key Session Switching	Set to Enabled for the hotkey combination to toggling between sessions.
Hotkey Combination is CTRL+	The value of the hotkey is defaulted to CTRL+F9, but it can be assigned to any function key.

## Local Print Module

The Local Print Module simplifies printing through the parallel port on thin clients.

There are three steps.

1. Install the print driver on the Remote Desktop Servers to which the client connects.
2. Add the Local Print Module to the thin client as described in [Add a Module on page 539](#).
3. Configure the Print Driver Name parameter in the module to contain the print driver's name. The Local Print module works when the name of the print driver is entered in the Value field for the Printer Driver Name. The Print Driver name is provided by the properties page for the printer.
  - a. Choose Start>Settings>Printers to launch the Printer Property page for a printer and choose the appropriate printer.

The Printer Queue dialog box appears.

- b. Choose Printer>Properties to launch the Printer Properties page.

The Advanced tab on the Printer Properties page contains the Print Driver name.



- c. Type the Print Driver name into the appropriate field on the Local Print Module.



When printing from the client, the printer is displayed as Printer/username/session number.

## MultiStation Configuration Module

The MultiStation Configuration Module allows you to specify how many keyboards and mice are at each station.

The settings include these.

Setting	Description
Station Number	Specifies the station number to configure.
Number of Keyboards	Sets the number of keyboards at the selected station.
Number of Mice	Sets the number of mice at the selected station.

## Redundant Ethernet Module

Adding the Redundant Ethernet Module to a Terminal with dual network ports allows the Terminal to use the second port as a backup. The Terminal has one IP address, but it can have the ports plugged into two switches to have redundant paths to the Remote Desktop Servers.

The Redundant Ethernet Module has no configurable settings. Plug each network port into different switches on the same network.

The Terminal boots from the first available network port and downloads the configuration. If the first network path fails, it seamlessly switches to the backup port to prevent interruption of service.

## Terminal Shadow Module

This module needs to be installed in ThinManager, but it is not applied to a Terminal. A Terminal automatically downloads this module if it is needed.

## TermMon ActiveX Configuration Module

This configures the TermMon ActiveX control that collects Terminal information and can perform Terminal functions. It is listed as both a Miscellaneous Module and a TermSecure Module, but is described in the [TermSecure Modules](#) section.

See [TermMon ActiveX Configuration on page 563](#) for details.

## Time Zone Redirection Module

The Time Zone Redirection Module allows a Terminal to display local time when it is connected to a Remote Desktop Server in another time zone.

1. Highlight the Time Zone parameter to activate the Value pull-down menu that contains time zones.
2. Click Set to accept the changes.
3. Allow time zone redirection in the Group Policy Console of the Windows Remote Desktop Servers.

The Allow Time Zone Redirection policy is found under Local Computer Policy\Computer Configuration\Administrative Templates\Windows Components\Terminal Services\Client\Server data redirection folder for Server 2003 or Local Computer Policy\Computer Configuration\Administrative Templates\Windows Components\Terminal Services\Remote Desktop Server\Device and Resource Redirection for Server 2008 of the Group Policy.

See Microsoft documentation for information on Group Policy.

## TMTerm DLL Configuration Module

The TMTerm DLL Configuration module is used to communicate with the Terminal sessions from another Terminal or computer.

Setting	Description
Allow Connections from	<ul style="list-style-type: none"> <li>• ANY_IP allows you to configure the communication from any computer</li> <li>• List allows you to limit communication to specified computers.</li> </ul>
IP Address list (comma separated)	Allows you to list the IP addresses of computers authorized to retrieve the TermMon data. Separate multiple computer IP addresses with a comma.

## USB to Serial Module

The USB to Serial module allows you to map the USB ports to serial ports if you are using a USB-to-Serial device plugged into the Terminal.

## User Override Module

The User Override Module is a temporary module that allowed users of ThinManager 3.1 to use the User Override function in Display Clients. It is no longer needed in ThinManager 3.2 and later.

See Display Client Override for the current method of User Override.


## Mouse Modules

Mouse Modules can configure mouse functions in the ThinManager system.

### Locate Pointer Module

The Locate Pointer Module adds a large crosshair to the cursor when it becomes active after being idle, which allows you to see its location quickly. This feature is particularly helpful in a MultiMonitor system.

**Figure 800 - Locate Pointer Module**



The settings include these.

Setting	Description
Locate Pointer Hotkey	Allows you to set a hotkey to make the cursor appear.
Locate Pointer Hotkey Modifier	Allows you to set the modifier key to activate the hotkey to show the pointer cursor.
Home Pointer Hotkey	Allows you to set a hotkey that moves the cursor to the center of the main screen.
Home Pointer Hotkey Modifier	Allows you to set the modifier key that moves the cursor to the center of the main screen.
Locate Inactivity Time (seconds)	Sets the length of the idle time before the locate pointer cursor is activated.
Home Pointer Inactivity Time (seconds)	Sets the length of the idle time before the locate pointer cursor is moved to the center of the main screen.
Locate Display Time (seconds)	The length of time that the locate pointer crosshair cursor is displayed when activated.

### Mouse Configuration Module

The Mouse Configuration Module allows USB or PS/2 mice to be configured and allows the use of two mice. These are the Mouse configuration settings.

Setting	Description
Primary Mouse Type	Allows both a PS/2 mouse and USB mouse to be used on a Terminal. Define which mouse is considered the primary mouse.
Mouse Protocol	Allows the selection of different protocols used by the mouse.
Scroll Mouse	When set to Yes, allows a scroll mouse to function on a Terminal.
Acceleration Multiplier	Allows the mouse movement to be slowed down or sped up.

Setting	Description
Acceleration Threshold (pixels)	The number of pixels a mouse must move before the acceleration multiplier takes effect.
Left Button	Disables the left mouse button when set to Disabled.
Right Button	Disables the right mouse button when set to Disabled.
Scroll Button	Disables the scroll button when set to Disabled.
Scroll Wheel	Disables the scroll wheel when set to Disabled.

1. To change a parameter, highlight the parameter and choose a new value from the Value pull-down menu.
2. Click Set to accept the new parameter value.

## PS/2 Mouse Module

The PS/2 Mouse Module is the predecessor of the Mouse Configuration Module. It allows the changing of PS/2 settings like mouse type, acceleration, and threshold. All of these features are now available in the Mouse Configuration Module.

Setting	Description
Primary Mouse Type	Allows both a PS/2 mouse and USB mouse to be used on a Terminal. Define which mouse is considered the primary mouse.
Scroll Mouse	When set to Yes, allows a scroll mouse to function on a Terminal.
Acceleration Multiplier	Allows the mouse movement to be slowed down or sped up.
Acceleration Threshold (pixels)	The number of pixels a mouse must move before the acceleration multiplier takes effect.

## Serial Mouse Driver

The Serial Mouse Driver allows a serial mouse to be used with thin clients.

Setting	Description
Mouse Type	Defines what type of mouse is used.
Serial Port	Set this value to the serial port number used for the mouse.

## Share Keyboard and Mouse Modules

See [Share Keyboard and Mouse Modules on page 554](#).

The Share Keyboard and Mouse Master module is licensed for each master thin client. The Share Keyboard and Mouse Follower module is free. Each controller module can have 1...4 follower units. Future releases expand the number of replicas that the master can control.

## Network Modules

### Domain Name System Module

The Domain Name System Module allows you to specify a DNS server for a Terminal without the need to turn on DNS for the entire ThinManager Server system.

## Second Network Module

The Second Network Module allows you to use the dual network ports on a Terminal on different networks.

Add the Second Network Module and configure the second port.

The Terminal always boots from the first port; but once booted, it enables the second port and allows communication on both networks. This is useful for separating IP camera bandwidth from the process control network, for example.

**Figure 801 - Second Network Module**

The settings include these.

Setting	Description
IP Method	Allows the second port to use DHCP or a static IP.
IP Address (Static Only)	Allows the second port to be assigned a static IP address.
NetMask (Static Only)	Allows the second port to be assigned a subnet mask.
Router (Static Only)	Allows the second port to be assigned a router.

## Third Network Module

The Third Network Module allows you to configure a third network port to connect to a different network than the first network port on Terminals with three network ports.

These are the Third Network Module parameters.

Parameter	Description
IP Method	Allows you to choose a static IP or use DHCP.
IP Address (Static Only)	Allows you to set a static IP address if Static was the chosen IP method.
NetMask (Static Only)	Allows you to set a NetMask if Status was the chosen IP method.
Router (Static Only)	Allows you to set a static IP address for a router if Static was the chosen IP method.

## RDP Modules

### RDP Experience Module

The RDP Experience Module allows a session to add features when connected to a Windows 2003 Remote Desktop Server with RDP.

These are the RDP Experience Module parameters.

Parameter	Description
Allow Desktop Background	If set to Yes, allows a Terminal to show a desktop background.
Show Window Contents While Dragging	If set to Yes, allows a Terminal to show window contents while dragging.
Allow Menu and Window Animation	If set to Yes, allows a Terminal to show window and menu animations.
Allow Themes	If set to Yes, allows a Terminal to show a desktop theme.
Allow Font Smoothing	If set to Yes, uses the Microsoft font smoothing in the session.
Duplicate Server Connect Delay (seconds)	Adds a delay when a Terminal is creating multiple connections to a Remote Desktop Server and, normally, displays an error message that the server is busy. Add a delay to possibly minimize that error message.
Enable Network Level Authentication	Allows you to turn off NLA (Network Level Authentication) for that Terminal.
Use Hardware Scaling When Available	If set to Yes, uses the local video hardware for scaling.

Enable RDP Experience in Windows Group Policy Editor in order to use these features. See Microsoft documentation for details.

### RDP Port Module

The RDP Port Module allows the port that RDP uses to communicate to the Remote Desktop Server with to be changed from the default 3389.

- Type the new port number for RDP in the RDP Server Port Number (decimal) field.

### RDP Serial Port Redirection Module

The use of serial ports on a thin client presents a paradox: the session runs on a Remote Desktop Server and not the thin client. If you connect a serial device to the thin client and reference it in the session, the session looks at the local serial ports on the server and not the remote serial ports on the Terminal where the device is attached.

Adding the RDP Serial Port Redirection Module maps the remote ports on the Terminal to the local ports in the session. If the session references COM Port 1, it is sent to the Terminal COM Port 1.

The RDP Serial Port Redirection Module has no configuration. Add it to map the remote COM Ports.

## RDP Session IP Module

The RDP Session IP Module allows a Terminal to use an alias IP address for a specific Display Client session.

The RDP Session IP module has three settings.

Setting	Description
Group Name	Specifies the Display Client to use.
Session IP Address	The IP address to use as the alias.
Session IP Address for Instant Failover	The IP address to use for a backup session if the Display Client is configured to use Instant Failover.

## Smart Card Module

The Smart Card module must be added to use a Smart Card Reader and Smart Cards.



Network Level Authentication (NLA) must be disabled on the Remote Desktop Servers to use a smart card as a login device. It can be left enabled if you are using the smart card to send information to the active session.

## Relevance Modules

### Bluetooth Module

ThinManager supports Bluetooth 4.0 USB adapters as resolvers for Relevance. A Bluetooth USB adapter can be plugged into a thin client USB port to provide a Bluetooth beacon that does not require batteries. The Bluetooth module allows you to configure the USB adapter.

**Figure 802 - Bluetooth Module**

The screenshot shows the 'Module Properties' dialog box for the Bluetooth module. It contains the following fields and values:

- Device Number: 0
- Advertising Mode: ACP
- Advertising Name: ACP-{BD\_ADDR}
- Custom Advertising Name (16 char max): None
- Advertising Interval (Milliseconds): 250
- UUID (iBeacon Only): 11111111-2222-3333-4444-55555555
- Major Number (0-65535) (iBeacon Only): 1
- Minor Number (0-65535) (iBeacon Only): 1

At the bottom of the dialog, there are three buttons: 'Set to Default', 'Done', and 'Cancel'.

The Bluetooth Module has several settings.

Setting	Description
Device Number	Add this module for each device added and assign each device a different number. ThinManager sorts out which is which.
Advertising Mode	Allows you to set the transmission mode of the USB adapter.
ACP	Sets the adapter to transmit in the ACP protocol.
iBeacon	Sets the adapter to transmit in the iBeacon protocol. You must assign a UUID, a major number, and a minor number.
Disabled	Stops the transmission from the adapter.
Advertising Name	Allows you to choose which naming convention is used to identify the Bluetooth USB adapter.
ACP-{BD_ADDR}	Transmits the Bluetooth address of the USB adapter with the "ACP-" prefix.
ACP-{Terminal Name}	Transmits the Terminal name of the client that hosts the USB adapter with the "ACP-" prefix.
BD-Address	Transmits the Bluetooth address of the USB adapter.
Terminal Name	Transmits the Terminal name of the client that hosts the USB adapter.
Custom	Allows you to set a custom advertising name in the Custom Advertising Name (16 char max) field.
Custom Advertising Name (16 char max)	Allows you to set a Custom Advertising Name if Custom is chosen in the Advertising Name pull-down menu. You are limited to 16 characters.
Advertising Interval (Milliseconds)	Sets the frequency of the Bluetooth signal.
UUID (iBeacon Only)	Each iBeacon has a Universally Unique Identifier (UUID). Allows you to associate your iBeacon to the Terminal if iBeacon was chosen from the Advertising Mode pull-down menu.
Major Number (0-65535) (iBeacon Only)	Allows you to add the iBeacon major number for registration.
Minor Number (0-65535) (iBeacon Only)	Allows you to add the iBeacon minor number for registration.




iBeacon USB adapters normally have a UUID, a major number, and a minor number assigned to them. These must be added to the Bluetooth Module in the appropriate fields.

ThinManager® with Relevance® filters Bluetooth adapters by default and only shows Bluetooth beacons with the ACP prefix. If you use the BD-Address, Terminal Name, or Custom advertising names you must turn off the ACP filter, which is done in the Relevance Settings dialog box.

1. From the ThinManager menu bar, choose Manage>Relevance>Settings.

The Relevance Settings dialog box appears.



**Figure 803 - Relevance Settings Dialog Box**


The dialog box titled "Relevance Settings" contains the following controls:

- Location Transfer Timeout:** A text box with "15" and a "seconds" label.
- Location Transfer Extension Time:** A text box with "15" and a "seconds" label.
- Bluetooth Device Name Filter Prefix:** A text box with "ACP-".
- iBeacon GUIDs:** A list box with "Add", "Delete", and "Edit" buttons to its right.
- Enable iPhone Beacons:** A checkbox, which is highlighted with a red rectangle in the image, currently unchecked.
- Allow New Resolvers to be registered:** A checked checkbox.
- Buttons:** "OK" and "Cancel" buttons at the bottom right.

Setting	Description
Location Transfer Timeout (seconds)	The amount of time an operator has to allow a session to transfer during a normal Transfer.
Location Transfer Extension Time (seconds)	The amount of time that a transfer can wait when user selects More Time during a transfer.
Bluetooth Device Name Filter Prefix	Allows you to filter Bluetooth beacons by their prefix.
iBeacon GUIDs	Lists the registered iBeacon devices.
Enable iPhone Beacons	Check to allow the ThinManager Beacon application on an iPhone to work as a beacon to identify the location of the ThinManager user. This setting tells the client application (iTMC or aTMC) to look for devices that run ThinManager Beacon, which a free iPhone application available from the App Store®.
Allow New Resolvers to be registered	Check to allow new resolvers to be added. Clear this checkbox to prevent the addition of new resolvers unless an administrator re-enables this setting.


2. Clear or change the Bluetooth Device Name Prefix if you use the BD-Address, Terminal Name, or Custom advertising names.

The iTMC application can show the Bluetooth beacons it is receiving.

3. Click Menu in the upper-right corner of the iTMC menu bar.

The Main Menu appears.

4. Click View Bluetooth Beacons to see the Bluetooth beacons.

**Figure 804 - Bluetooth Beacons in iTMC Application**


The screenshot shows the "Bluetooth" section of the iTMC application. It includes a "Done" button in the top left and a "Bluetooth" title. Below the title, the "STATUS" section shows "Scanning" and "Bluetooth State: On". The "BLUETOOTH BEACONS" section lists two beacons:

- ACP-1\_Terminal**  
RSSI: -68 (avg) : -68 (last reading)  
Transmission Interval: 0.379 seconds (avg) : 0.153 seconds (last reading)
- ACP-9059AF08ADB5**  
RSSI: -75 (avg) : -78 (last reading)  
Transmission Interval: 0.828 seconds (avg) : 0.888 seconds (last reading)

The first beacon entry is highlighted with a red rectangle.

[Figure 804 on page 559](#) shows a beacon using the ACP-{Terminal Name} advertising name.

iPhone Beacon

To use your iPhone as a beacon, follow these steps.

- 1. Choose Manage>Relevance>Settings.

The Relevance Settings dialog box appears.

- 2. Check Enable iPhone Beacons.
- 3. Launch the ThinManager Beacon app on your iPhone.


The ThinManager Beacon app is available at the App Store. Once the app is turned on, the iPhone can be used as a beacon.

DigitalPersona UareU Fingerprint Reader

ThinManager supports the DigitalPersona UareU Fingerprint Reader biometric reader from Crossmatch to add another element of security to a ThinManager system.

See [Fingerprint Reader on page 404](#) for more details.

Figure 805 - DigitalPersona UareU Fingerprint Reader Module



The DigitalPersona UareU Module has several settings.

Setting	Description
Mode	Allows you to use the reader with TermSecure, TermMon ActiveX, or as a TermMon Lookup device.
Data Format	Allows you to choose the data format used by the biometric reader.
Show Status Messages	Displays activity messages in the upper-right corner of the Terminal.
Allow Manual Logon	Can be set to No to require access only through the biometric device.
Prompt for TermSecure Password	Set to Yes to require a password in addition to fingerprint scan.

## RF Ideas pcProx Modules



On the Biometric Device Configuration page of the ThinManager Server Configuration Wizard, check Support Finger Print Readers to use a fingerprint scanner. Set the data format here, as well.

ThinManager supports card readers from RF Ideas for use with badges in TermSecure. There is a serial RF Ideas pcProx Module and a USB RF Ideas pcProx Module.

### *Serial RF Ideas pcProx Module*

This module is used with the RFIdeas pcProx Enroll Series 81 readers like RDR-xx81AKx.

**Figure 806 - RF Ideas pcProx Module Parameters**

Module Properties	
Port	COM1
Number of Data Bits	26
Use Facility Code	YES
Allow Manual Logon	YES
Prompt for Password	NO
Zero Pad Facility Code and ID	NO
<div> Set to Default Done Cancel </div>	


These are the parameters.

Parameter	Description
Port	Choose the port on which the RF Ideas pcProx card reader is installed.
Number of Data Bits	As different cards use different numbers of data bits in their format, this sets the number of data bits to match that used by the card as an identifier. The choices are 26, 37, or Raw.
Use Facility Code	Set to Yes to require the addition of the card's Facility Code to the Card/Badge ID number.
Allow Manual Login	<ul style="list-style-type: none"> <li>Yes allows a ThinManager user to log in to a Terminal without a TermSecure ID device.</li> <li>No requires TermSecure users to use a TermSecure ID device to log in.</li> </ul>
Prompt for Password	Set to Yes to require a TermSecure user to enter their password for access even if the password is configured in ThinManager.
Zero Pad Facility Code and ID	Adds a zero to the number string. This is rarely needed.

### *USB RF Ideas pcProx USB Module*

This module is used with the RDR-6081AKU, RDR-80582AKo, and RDR-80082AKo USB RFIdeas pcProx readers.

Figure 807 - RF Ideas pcProx USB Module



These are the RF Ideas USB pcProx Module parameters.

Parameter	Description
Model	Allows you to choose between the RDR-6081AKU, RDR-80582AKO, and RDR-80082AKO USB pcProx card reader.
Mode	<ul style="list-style-type: none"><li>• TermSecure Mode allows the card to be used with TermSecure as a login device</li><li>• Wedge Mode allows the data to be sent to the session as a character string</li><li>• TermMon Mode allows the data to be sent to the TermMon ActiveX</li></ul>
Bits in ID Number (AKO Only)	As different cards use different numbers of data bits in their format, this sets the number of data bits to match that used by the card as an identifier.
Bits in Facility Code (AKO Only)	As different cards use different numbers of data bits in their format, this sets the number of data bits of the Facility Code.
Zero Pad Facility Code and ID (AKO Only)	Adds a leading 0 to the Facility Code if needed.
Allow Manual TermSecure Login	<ul style="list-style-type: none"><li>• Yes allows a ThinManager user to log in to a Terminal without a TermSecure ID device.</li><li>• No requires TermSecure users to use a TermSecure ID device to log in.</li></ul>
Prompt for TermSecure Password	Set to Yes to require a TermSecure user to enter their password for access even if the password is configured in ThinManager.
Expose Card ID to TermMon ActiveX Control	Allows the card data to be sent to the TermMon ActiveX without using it as a ThinManager User identifier.

To configure a parameter, follow these steps.

1. Highlight the parameter.
2. Change the value.
3. Click Set to apply the new value.
4. Click Done to accept the changes.

Once the Terminal has the module added, it needs to be restarted for the changes to take effect.


5. Click Finish to close the Terminal Configuration Wizard.
6. Right-click on the Terminal in the ThinManager tree and choose Restart.

*RF Ideas pcProx Sonar Module*

RF Ideas has a sonar device that can be a pointer to the operator. It becomes active when a ThinManager User logs on and measures the time for a sonar

echo. If the user walks away without logging off, the sonar detects the absence because of the increase in the time interval of the echo.

**Figure 808 - RFIdeas pcProx Sonar Module**



Parameter	Description
Walk-Away Modifier	Allow you to use a key combination to trigger to turn off the sonar.
Walk-Away Key	
Walk-Up Modifier	Allow you to use a key combination to turn on the sonar.
Walk-Up Key	

## TermMon ActiveX Configuration

This configures the TermMon ActiveX control that collects Terminal information and can perform Terminal functions.

Normally, the TermMon ActiveX, when registered on a Remote Desktop Server, allows a Remote Desktop Server session to communicate with its Terminal and act upon it without the need of the TermMon ActiveX module. The TermMon ActiveX module can be added to the Terminal configuration to either deny the default Remote Desktop Server to Terminal access or to allow access to other sessions and PCs.

Parameter	Description
Allow ActiveX Connections	<ul style="list-style-type: none"> <li>• Yes allows the ActiveX control to function.</li> <li>• No prevents any ActiveX communication to the Terminal, which includes the default Remote Desktop Server to Terminal access.</li> </ul>
Only Allow Connections from Session	<ul style="list-style-type: none"> <li>• Yes allows other Remote Desktop Server sessions and PCs to communicate to the Terminal with the ActiveX functions.</li> <li>• No restricts communication to that between the Terminal and a session on the Remote Desktop Server belonging to the Terminal, provided that Allow ActiveX Connections is set to Yes.</li> </ul>

See Registering the Control on page 731 of the ThinManager for Relevance 11.2 User Manual for details.

## USB Flash Drive Module

The USB Flash Drive Module can be used to allow USB flash drives to be used as TermSecure ID devices.

See [Figure on page 547](#) in Local Storage Modules for details.

## Wavetrend Tag Reader (Package 5 Only)

The Wavetrend Tag Reader Module allows a Terminal to use Wavetrend RFID cards as TermSecure ID cards. This logs in a user through TermSecure when they approach the Terminal and logs them out when they leave the area. The distance required to log in and log out is configurable in the module.

These are the parameters.


Parameter	Description
Port	Specifies which COM Port the reader is attached to as the WaveTrend Tag Reader Module connects to a thin client through the serial port.
Use Vendor Code	When set to YES, the vendor code is included as part of the identifier number.
Allow Manual Login	<ul style="list-style-type: none"> <li>• YES allows a ThinManager User to use the hotkey to initiate logins, or the device.</li> <li>• NO forces a ThinManager User to use a device to login.</li> </ul>
Prompt for Password	<ul style="list-style-type: none"> <li>• NO allows the device to login without a password.</li> <li>• YES forces every ThinManager User to enter a password after using the device.</li> </ul>
Entry Signal Strength	The signal strength required to register the card as in range.
Exit Signal Strength	The signal strength required to register the card as out of range.
Entry Sensitivity	The number of reads above the Entry Signal Strength reads required to register as "Entered."
Exit Sensitivity	The number of reads below the Exit Signal Strength required to register as "Exited."

## Screen Saver Modules

The use of ThinManager Screen Savers is recommended because they run on the client. A Microsoft screen saver running in a session can utilize processing power that could be better applied to another session.

### MultiSession Screen Saver Module

The MultiSession Screen Saver Module is a screen saver that allows the different sessions of a MultiSession client to cycle.

**Figure 809 - MultiSession Screen Saver Module**

The MultiSession Screen Saver Module has two modes. It can be set to cycle through the MultiSession windows when the Terminal is inactive, or it can be set to return to the main MultiSession screen when the Terminal is inactive.

These are the parameters.


Parameter	Description
Mode	<ul style="list-style-type: none"> <li>• Cycle switches between all active sessions on the Terminal.</li> <li>• GotoFirstGroup switches the Terminal to the main session when it is inactive.</li> </ul>
Start Delay Time in secs	The number of seconds of inactivity that the Terminal allows before the screen saver starts.
Switch Interval in secs (Cycle mode only)	The number of seconds the Terminal displays each session when using the Cycle mode.

## Screen Saver Module

Screen Saver Module loads a screen saver on the client. The screen saver runs when the Terminal is idle to protect the monitor. Since the screen saver runs on the client, it saves CPU resources on the Remote Desktop Server.

This module has a Disable Time Period function that disables the screen saver during working hours so that the screen is visible during those hours.

Figure 810 - Screen Saver Module



The Screen Saver Module configuration includes these parameters.

Parameter	Description
Screen Saver	The graphic displayed when the screen saver is active.
Wait Time in Minutes	The length of time that the Terminal must be idle before the screen saver starts.
Use Disable Time Period	The screen saver can be set to be disabled or unavailable during a time block. This can be used to prevent the screen saver from running during normal business hours.
Disable Start Time (0-23)	Sets the start of the disabled time block. 0 is Midnight and 23 is 11:00 p.m.
Disable End Time (0-23)	Sets the end of the disabled time block. 0 is Midnight and 23 is 11:00 p.m.
Force Off when Start Hour is Reached	Set to Yes to turn the screen saver off when the Disable End Time is reached.

Sound Modules

Many ThinManager-ready thin clients and ThinManager-compatible thin clients have audio ports for speakers.


The use of sound from a thin client requires several things.

- Hardware with a Line Out/Speaker plug
  - Amplified speaker(s)
  - Universal Sound Driver Module
- 
1. Plug the speaker(s) into the Line Out plug on the Terminal.
  2. Add the module.
  3. Connect to the Remote Desktop Server.

Universal Sound Driver

The Universal Sound Driver Module activates ThinManager to send the correct sound driver for that Terminal. This module can be added to any thin client that has an audio jack to enable sound.



**Figure 811 - Universal Sound Driver Properties**

The Universal Sound Module has several settings.

Setting	Description
Audio Bandwidth (ICA Only)	Set to Low, Medium, or High bandwidth when using Citrix ICA.
Sound in Session	<ul style="list-style-type: none"> <li>• Enabled allows sound generated within the session to be played through the Terminal.</li> <li>• Disabled turns off the session sounds, but system sounds are generated during TermSecure login for audio feedback during the login process.</li> </ul>
Terminal Sound Effects	Set to Enabled to allow Terminal sound effects like TermSecure login sounds on the Terminal.
Only Play sound in Foreground Session	Turns off the sound in background sessions when using MultiSession.
Master Volume Level (0-100)	Sets the master volume for the Terminal.
Start Sound Volume Level (0-100)	Sets the master volume for the Terminal.
Sound Effects Volume Level (0-100)	Sets the level for sound effects on the Terminal.
Sound Card Number	Lets you specify which sound card to use if you have multiple sound cards.
Playback Device Number	Lets you choose the playback device output of the sound card.

## TermSecure Modules

There is a legacy category for TermSecure that was superseded by the Relevance category.

The modules in the TermSecure list are identical to the modules in the Relevance list. See [Relevance Modules on page 557](#).

These are the modules.

- Bluetooth Module
- DigitalPersona UareU Fingerprint Reader
- Serial RF Ideas pcProx Module
- USB RF Ideas pcProx USB Module
- RFIdeas pcProx Sonar Module
- TermMon ActiveX Configuration Module
- USB Flash Drive Module

- USB ID Reader Module
- Wavetrend Tag Reader (Package 5 Only)

## Touch Screen

ThinManager supports over a dozen serial touch screen controllers and a universal USB driver. You must add the proper driver for the controller. Some manufacturers are not consistent and use different controllers for different product lines.

### Serial Drivers

Each serial touch screen has a specific touch driver based on the touch controller of the monitor. You must add the appropriate driver that matches the touch controller.

- Arista ARP-16XXXAP-ACP Touch Screen Driver
- CarrollTouch Touch Screen Driver
- Contec Touch Screen Driver (Package 5 only)
- DMC Touch Screen Driver (Package 5 only)
- DMC TSC Series Touch Screen Driver
- Dynapro Touch Screen Driver
- Elographics Touch Screen Driver
- Gunze AHL Touch Screen Driver
- Hampshire TSHARC Touch Screen Driver
- MicroTouch Touch Screen Driver
- Panjit TouchSet Touch Screen Driver
- PenMount Touch Screen Driver
- Ronics Touch Screen Driver (Package 5 only)
- Touch Control Touch Screen Driver
- Touch International IR Touch Screen Driver (Package 5 only)
- USB Touch Screen Driver
- Xycom 33XX Touch Screen Driver (Package 5 only)
- Zytronic Touch Driver



The touch controller is the important component. Many manufacturers make touch screen monitors, but fewer make the controller. You need the module that matches the controller.

**Figure 812 - Serial Touch Screen Driver**

The screenshot shows a 'Module Properties' window with the following settings:

- Serial Port: COM1
- Monitor Number: 1
- Double Touch Area (pixels): 10
- Double Touch Time (milliseconds): 1000
- Touch De-bounce Timeout (milliseconds): 0
- Swap XY Coordinates: NO
- Hold Down Time (milliseconds): DISABLED
- Hold Down Area (pixels): 20
- Hold Down Action: RightClick
- Number of Calibration Points: 5
- Calibration Margin Percentage: 10

Buttons: Set to Default, Done, Cancel.

Some, but not all, touch screen modules have parameters that can be modified, which may include these.


Parameter	Description
<b>Connection</b>	
Serial Port	Sets the COM port that a serial touch screen is connected to.
Baud Rate	Sets the speed used for communication between the Terminal and the touch screen on some serial touch screens.
Monitor Number	Used to specify which monitor in a MultiMonitor scheme uses for the touch screen. MultiMonitor thin clients with multiple touch screens need a module loaded for each touch screen used.
<b>Touch Settings</b>	
Double Touch Area (pixels)	Sets the size of the area that a second touch registers as a double-touch.
Double Touch Time (milliseconds)	Amount of time between touches that qualifies as a double-touch.
Touch De-Bounce Timeout	A time interval used to prevent a single touch from being registered as multiple touches.
Swap XY Coordinates	If X and Y are reversed, this setting corrects the orientation.
Hold Down Time (milliseconds)	When enabled, initiates the Hold Down Action when the touch is held for the configured time
Hold Down Action	Sets the action that a long touch initiates, includes Right-Click and OnBoard Keyboard.
Hold Down Area (pixels)	Sets the size of the area that a second touch registers as a right-click.
<b>Calibration</b>	
Number of Calibration Point	Sets the number of calibration points that the calibration program uses during the calibration process.
Calibration Margin Percentage	Sets the distance from the edge of the screen at which calibration points are displayed.
Calibration Hotkey	Allows a function key to be set as a hotkey so that the calibration can be launched from a keyboard.
Calibration Hotkey Modifier	Adds CTRL or ALT to the hotkey to launch the calibration from the keyboard, if desired.
Calibration Hold Down Time (seconds)	When enabled, launches the calibration program when the screen is touched and held for the assigned number of seconds. Cannot be used with the Right-Click Hold Time.
Clean Time	Sets an idle time before the calibration to allow you to clean and wash a touch screen. The calibration waits until you are done touching the screen while cleaning.
Calibration (entered automatically)	Set automatically by machine. These are the values set during the calibration process.

Parameter	Description
<b>Miscellaneous</b>	
Hide Mouse Cursor	Hides the mouse cursor if a mouse is not present.
Orientation (entered automatically)	Set automatically by machine. Used at the direction of Tech Support in error correction.

USB Touch Screen Driver

USB touch screens are easy to use as they use a standardized format. The USB Touch Screen Driver should work for all USB touch screens.

Figure 813 - USB Touch Screen Module




Some, but not all, touch screen modules have parameters that can be modified, including these.

Parameter	Description
<b>Connection</b>	
Monitor Number	Used to specify which monitor in a MultiMonitor scheme uses for the touch screen. MultiMonitor thin clients with multiple touch screens need a module loaded for each touch screen used.
<b>Touch Settings</b>	
Double Touch Area (pixels)	Sets the size of the area that a second touch registers as a double-touch.
Double Touch Time (milliseconds)	Amount of time between touches that qualifies as a double-touch.
Touch De-Bounce Timeout	A time interval used to prevent a single touch from being registered as multiple touches.
Swap XY Coordinates	If X and Y are reversed, this setting corrects the orientation.
Hold Down Time (milliseconds)	When enabled, initiates the Hold Down Action when the touch is held for the configured time.
Hold Down Action	Sets the action that a long touch initiates, includes Right-Click and OnBoard Keyboard.
Hold Down Area (pixels)	Sets the size of the area that a second touch registers as a right-click.
<b>Calibration</b>	
Number of Calibration Point	Sets the number of calibration points that the calibration program uses during the calibration process.
Calibration Margin Percentage	Sets the distance from the edge of the screen at which calibration points are displayed.

Parameter	Description
Calibration Hotkey	Allows a function key to be set as a hotkey so that the calibration can be launched from a keyboard.
Calibration Hotkey Modifier	Adds CTRL or ALT to the hotkey to launch the calibration from the keyboard, if desired.
Calibration Hold Down Time (seconds)	When enabled, launches the calibration program when the screen is touched and held for the assigned number of seconds. Cannot be used with the Right-Click Hold Time.
Clean Time	Sets an idle time before the calibration to allow you to clean and wash a touch screen. The calibration waits until you are done touching the screen while cleaning.
Calibration (entered automatically)	Set automatically by machine. These are the values set during the calibration process.
<b>Miscellaneous</b>	
Hide Mouse Cursor	Hides the mouse cursor if a mouse is not present.
Orientation (entered automatically)	Set automatically by machine. Used at the direction of Tech Support in error correction.

The Right Click Hold Time (milliseconds) setting allows you to send a right-click to the session. Check Tile on right click setting, in the Tile Options dialog box, to allow a user to switch screens on a touch screen without a keyboard or mouse.

**Figure 814 - Tile Options**



The Tile Options dialog box appears when Tiling Options is clicked on the Terminal Interface Options page of the Terminal Configuration Wizard.

## Video Driver Modules

The method of downloading video drivers was changed in ThinManager 3.0. In previous versions, all video drivers were contained in the firmware and were downloaded at boot. In ThinManager 3.0, the video was split out of the firmware and each thin client only downloads the video driver that it needs.

One does not need to add the video module to the Terminal, but must only have the video module installed in ThinManager to make it available. As each Terminal connects to ThinManager, it downloads the correct module.

These modules are normally installed with ThinManager.

## Custom Video Mode Module

ThinManager-ready thin clients are designed for use with traditional computer monitors. The TermCap lists the standard resolutions for each Terminal. Some TVs, when used as a monitor, use a different nontraditional mode line. The Custom Video Mode Module allows a different set of parameters to be sent to the Terminal with use with the monitor.

This module is normally not needed and is used under direction of the ThinManager technical support staff.

### Monitor Configuration Module

The Monitor Configuration Module allows the manual configuration of a monitor. This is generally used at the direction of ThinManager tech support as most monitors are supported automatically by ThinManager.

Parameter	Description
Monitor 1 Connection Type	Allows you to choose the connection type of your first monitor.
Monitor 2 Connection Type	Allows you to choose the connection type of your second monitor.
Monitor 3 Connection Type	Allows you to choose the connection type of your thirde monitor.
Monitor 4 Connection Type	Allows you to choose the connection type of your fourth monitor.
Monitor 5 Connection Type	Allows you to choose the connection type of your fifth monitor.
Enable TwinView for nVidia Adapters	Enables TwinView.


## ThinManager Server Configuration Wizard

The ThinManager Server Configuration Wizard allows the configuration of global ThinManager settings. It can be launched one of these ways.

- Choose Edit>Modify while the ThinMan icon is highlighted in the ThinManager tree
- Double-click on the ThinManager icon in the ThinManager tree
- Right-click the ThinMan icon and choose Modify

### Introduction Page

Figure 815 - ThinManager Server Configuration Wizard



Unknown Terminals Page

Figure 816 - Unknown Terminals

1. Complete the Unknown Terminals page per the following descriptions.

Setting	Description
Allow unknown terminals to connect	Allows the addition of new Terminals to the ThinManager Server. Clear this checkbox to prevent replacements and new Terminals.
Authentication Required for Replacement	Controls replacement authorization.
None	Allows a Terminal to be added without authentication.
ThinManager Password	Allows you to set a password so that only authorized personnel can add Terminals to the ThinManager Server. Check to enable the password fields and allow the addition of a password.
Windows Account	Requires that the replacer enter their Windows account on the Terminal as it is being replaced. ThinManager checks and allows the replacement if the replacer is a member of a Windows Security Group that has the Allow Terminal Replacement task granted.
Enable Terminal AutoCreate	Check to allow the auto-creation of an array of Terminals as described in Auto-Creation of Terminals.
AutoCreate Mask	Base name used in the array of Terminals when using Auto-Creation of Terminals.
Require Authentication to change local settings	Requires authentication from a Windows Group that was granted the Edit Local ThinManager Server List function on the ThinManager Security Page in the ThinManager Server Configuration Wizard. This applies to mobile devices like iTMC, aTMC, and WinTMC.

These terminal settings allow greater security when thin clients are added or replaced. Require a password to control who adds Terminals. Use auto-creation to help with some large deployments.


2. Click Next to continue, Finish to save and close, or Cancel to close and not save.


The Terminal Replacement page appears, which sets the global setting to enable replacement of offline Terminals.



# Terminal Replacement Page

Figure 817 - Terminal Replacement



 Terminals that are turned on cannot be replaced until they are turned off.

1. Complete the Terminal Replacement page per these descriptions.

Setting	Description
Enable Replacement	Gives global permission for Terminals to be replaced. Clear this checkbox to prevent the appearance of all Terminals in the replacement list when a new Terminal is added, which makes Create New Terminal the only option. Also, this feature is available for the Group and Terminal level on the first page of the wizard. However, if this checkbox is cleared in the ThinManager Server Configuration Wizard, it has no effect in a Terminal Configuration Wizard when it is checked.
Allow replacement only with like model	Prevents the replacement of a Terminal with a different model to prevent configuration changes. For example, only a PXE can replace a PXE, or only an Android can replace an Android.
Allow Terminal Creation during replacement	Normally, a Terminal displays the Create New Terminal option during replacement. Clear this checkbox to remove that option and only allow a Terminal replacement, not a new configuration.


Clear the checkbox to prevent the appearance of all Terminals in the replacement list when a new Terminal is added, which makes Create New Terminal the only option.

2. Click Next to continue, Finish to save and close, or Cancel to close and not save.

The Historical Logging page appears, which adjusts the Historical Data setting to determine the length of time logs are maintained.

Historical Logging Page

Figure 818 - Historical Logging



- 1. Complete the Historical Logging page per these descriptions.

Setting	Description
Maintain Historical Log for X days	Determines the length of time that the Remote Desktop Server CPU and memory data from the Remote Desktop Server Graph tab is stored. See Details Pane for an example of the graph.
Maintain Event Log for X days	Determines how long the event log is kept.
Choose events to log	Determines which events are stored in the log.
<b>Buttons</b>	
Clear History	Erases the Historical log.
Clear Event Log	Erases the Event log.

By default, Remote Desktop Server events and ThinManager User events are not collected. Add these as well as other event logs to use as a tool when troubleshooting.


- 2. Click the Event Log tab to show the events for the highlighted tree icon.

SysLog Configuration Page

ThinManager Events, which were previously only found within the ThinManager interface’s Event Logging tab, can now be viewed in SysLog Servers when using SysLog Compatible Reporting. For example, you can log events to the Application log of Windows Event Viewer and view the logs there that have a source of ThinServer. This allows users to view ThinManager events sorted among other Windows logging events.

The SysLog Configuration option is in the ThinManager Server Configuration Wizard.


Figure 819 - SysLog Configuration



Setting	Description
SysLog Server Address	Enter the designated SysLog Server IP Address.
SysLog Protocol	From the pull-down menu, choose the appropriate SysLog protocol used. The options are TCP, TLS encrypted TCP, and UDP.
Default	Click to automatically populate the SysLog Server Port field with the standard port per the selected protocol.
SysLog Server Port	If the SysLog Server Port deviates from the standard, it may be manually entered here. Otherwise, click Default after choosing the SysLog Protocol to automatically populate the standard port.
Choose event type	By default, events are not configured for SysLog. Therefore, you must choose which events are to appear in SysLog.


Event Log Tab

Figure 820 - Event Log Tab



- 3. Double-click on an event to view its details in the Event Details dialog box.

Figure 821 - Event Details



- 4. Click OK or Cancel to close.
- 5. Click Next to continue, Finish to save and close, or Cancel to close and not save.

The System Schedule page appears, allows schedules to be setup for ThinManager and the ThinManager system.

# System Schedule Page

Figure 822 - System Schedule



1. Click Edit Schedule to create a System Schedule to automate backups, reports, and actions. This serves as a great troubleshooting tool, also.


Button	Description
Edit Schedule	Launches the Event Schedule dialog box. See <a href="#">Scheduling on page 619</a> for details.

2. Click Next to continue, Finish to save and close, or Cancel to close and not save.

The ThinManager Security Groups page appears, where access to ThinManager can be assigned to Windows User Groups. Normally, administrators are the only people who have access to ThinManager functions. This page allows access to be granted to people so they can perform specific jobs without being elevated to the administrator role.

Security Groups Page

Figure 823 - ThinManager Security Groups



Setting	Description
Windows User Group	Shows the group that is being configured.
Field	
Available	Shows the ThinManager functions that are available to the Windows group displayed in the Windows User Group dialog box. Double-click these functions to add them to the Allowed list.
Allowed	Shows the ThinManager functions that are granted to the Windows group displayed in the Windows User Group dialog box. Double-click these functions to remove them from the Allowed list.
Button	
Delete Group	Removes the highlighted group in the Windows User Group dialog box.
Add Group	Launches the New Window Group dialog box where a new Windows group can be added to the configuration.


ThinManager allows different levels of access and functionality based on standard Windows groups. By default, only members of the Windows Administrator group have the ability to connect to ThinManager and use the application. The ThinManager Security Groups allows other Windows groups to be granted privileges in ThinManager.

ThinManager comes with privileges predefined for six groups. Each of these groups (except Administrators) must be created on the domain controller or in the Local Users and Groups on the Computer Management console. Members must be added before they can be used.

Windows User Group	Description
Administrators	The Microsoft-defined Administrators group is given all privileges by default in ThinManager. Double-click a Windows User Group Permission to move it from the Allowed list to the Available list and deny particular permissions.
ThinManager Administrators	Provides full permission to do anything within ThinManager. This includes the power to log off sessions, kill processes, send messages, restart Terminals, calibrate touch screens, change Terminal configurations, update firmware, update the TermCap, and restore configurations. Administrators and members of ThinManager Administrators can shadow Terminals and interactively control the Terminal session. These privileges cannot be removed from the Allowed list and are dimmed.
ThinManager Interactive Shadow Users	Members of this group can interactively shadow a Terminal.
ThinManager Power Users	Can logoff sessions, kill processes, send messages, restart Terminals, and calibrate touch screens. They cannot change Terminal configurations, update firmware, update the TermCap, and restore configurations. ThinManager Power Users can shadow Terminals from within ThinManager, but they cannot interact with the session.
ThinManager Shadow Users	Members of this group can shadow a Terminal, but not interactively.
ThinManager Users	This is a view-only permission. They cannot log off sessions, kill processes, send messages, restart Terminals, or calibrate touch screens. ThinManager Users cannot shadow a Terminal.

1. Click Add Group in a non-domain ThinManager Server to launch the New Windows Group dialog box, which allows the configuration of additional Windows User Groups.

**Figure 824 - New Windows User Group**




2. Type a Windows Group name in the Enter Windows User Group Name field of the New Windows Group dialog box and click OK to add the Windows User Group to the pull-down menu.




This does not create the user group on any servers, it just adds the name of a group that exists to the list that ThinManager maintains.

3. Click Add Group in a domain ThinManager Server

The Select Security Group dialog box appears, which allows you to add Active Directory groups and configure their permissions in ThinManager.

**Figure 825 - New Windows User Group Dialog Box**

4. Type a local Windows User Group into the Manual Entry field and click OK.

**Figure 826 - ThinManager Security Groups Page**

5. On the ThinManager Security Groups page, choose the group from the Windows Users Group pull-down menu.
6. Double-click a function in the Available list of the Windows User Group Permissions section to grant that permission to the group. Members of the Windows User Group have the selected permissions at their next login.

Although ThinManager has Windows User Groups preconfigured with privileges, these groups were not created on the Remote Desktop Servers. These are merely templates for groups that can be created.



- a. If you need a new Windows group, create the Windows User Group using standard Microsoft methods.



The ThinServer service may need to be stopped and restarted to load the new ThinManager Security Group settings.

7. Click Next to continue the ThinManager Server Configuration Wizard, Finish to save and close, or Cancel to close and not save.

## Event Selection Page

**Figure 827 - Event Selection**

ThinManager has event notification. E-mails, SMS Messages, or Windows messages can be sent by ThinManager to identify changes in the setup, configuration, or status.

These are the settings for Event Selection page.

Windows User Group	Description
Event Type	Lists the events that can trigger a message. Choose the desired event and notification type. You can choose multiple events.
Email	Check to send an e-mail message when that event occurs. The e-mail must be set up on the next page of the wizard.
SMS Message	Check to send an SMS message when that event occurs. The SMS Messaging system must be defined on the next page of the wizard.
Windows Messages	Check to send a message to a Terminal when that event occurs. The Terminal must be defined on the next page of the wizard.

Information about these events can be useful. The event must be checked to add the notification.


The ThinManager Server Stop/Start, Remote Desktop Server Monitor Connection, and Terminal Monitor Connection events can indicate the failure of the ThinManager Server, Remote Desktop Server, or Terminal.

It can be useful to share information on configuration changes, firmware, TermCap, or license installation when management is shared among a group.

- 1. Send an e-mail to all group members to keep them informed of all changes.
- 2. Click Next to continue, Finish to save and close, or Cancel to close and not save.

Email or Windows Messaging Recipients Page


Figure 828 - Email or Windows Messaging Recipients Page



This page defines which users are notified of event changes from the Event Selection page.

Windows User Group	Description
<b>Fields</b>	
E-Mail Addresses	ThinManager sends an e-mail message to the addresses in this text box when an event is chosen on the Event Select page.
SMS Recipients	ThinManager sends an SMS message to the addresses in this text box when an event is chosen on the Event Select page.
Terminals	ThinManager sends a message to the Terminals in this text box when an event is chosen on the Event Select page.
<b>E-mail Buttons</b>	
Add	Click to make the Enter the E-mail address dialog box appear, where you can type an e-mail address.
Delete	Click to delete a highlighted e-mail address from the E-mail Addresses list.
Settings	Click to make the Email Server Settings dialog box appear, where you can configure the e-mail settings in the Email Server Settings dialog box.

Windows User Group	Description
<b>SMS (Text Message)</b>	
Add	Opens the SMS Message Recipient dialog box to add a phone number to the distribution list.
Delete	Deletes a highlighted number from the SMS Recipients list.


**Figure 829 - Enter the E-mail Address Window**

1. Click Add in the E-mail section.

The Enter the E-mail Address dialog box appears, where you can add an e-mail address to the notification list.

2. Click OK to accept the setting or click Cancel to close the dialog box and not save.
3. Click Settings in the E-mail section of the Email or Windows Message Recipients page.


The Email Server Settings dialog box appears, which allows you to configure the SMTP mail server.

**Figure 830 - E-mail Server Settings Window**

SMTP Sever Settings	Description
SMTP Server	Type the name of the SMTP Server.
SMTP Port	Type the number of the SMTP Port.
<b>SMTP Authentication</b>	
Username	Type the Username to allow the use of authentication for the connection to the SMTP server.
Password	Type the Password to allow the use of authentication for the connection to the SMTP server.
Use SSL	Check to allow the use of the SSL (Secure Socket Layer) to communicate with the SMTP server.
<b>Email Message Settings</b>	
Email Return Address	Allows you to configure a sender account for replies.
Email Subject Prefix	Allows you to configure a subject line for emails.

- 4. Click OK to accept the setting or click Cancel to close without saving.

Figure 831 - SMS Message Recipient




The SMS Message Recipient dialog box allows you to add a phone number to the SMS distribution list.

Setting	Description
Cell Phone Number	Type a phone number.
Cell Phone Service Provider	Allows you to specify what network the cell phone uses. Each service provider uses a unique account; so, the correct account is important.

- 5. Click OK to accept the setting or Cancel to close without saving.

Figure 832 - Select Terminal



The Select Terminal dialog box lists the Terminals configured on the ThinManager Server.

- 6. Highlight the desired Terminal and click OK.

[Figure 833](#) shows the Email or Windows Messaging Recipients page populated with different recipients.

**Figure 833 - Email or Windows Messaging Recipients Page**

**ThinManager Server Configuration Wizard**

**E-mail or Windows Message Recipients**  
Enter the e-mail addresses to receive e-mails, and select the terminals that will receive Windows messages.

**E-Mail**

Add  
Delete  
Settings

E-mail Addresses  
hfinn@hannibal.org  
tsawyer@hannibal.org

**SMS (Text Message)**

Add  
Delete

SMS Recipients  
(555) 867-5309@mms.att.net

**Messages**

Add  
Delete

Terminals  
1\_Terminal  
2\_Terminal

Please enter an SMTP Server. Click 'Settings' to configure SMTP

< Back   Next >   Finish   Cancel   Help




In [Figure 833](#), the SMTP server was not set up properly and an error message was displayed as a reminder.

- Click Next to continue, Finish to save and close, or Cancel to close and not save.

## Database Management Page


- Navigate to the Database Management page of the ThinManager Server Configuration Wizard. See [ThinManager Server Configuration Wizard on page 573](#) for more information on how to open the wizard.

**Figure 834 - Database Management Page**


The screenshot shows the 'Database Management' page of the ThinManager Server Configuration Wizard. The window title is 'ThinManager Server Configuration Wizard'. The page has a sub-header 'Database Management' with the description 'Allows user to change database password and other utility functions'. It contains two main sections: 'Database Password' and 'Database Health'. The 'Database Password' section has two text input fields labeled 'New Database Password' and 'Verify New Password', followed by a 'Change Password' button. The 'Database Health' section has a 'Run DB Integrity Check' button, a text label 'Vacuum can reduce the database size', and a 'Vacuum' button. At the bottom, there are navigation buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

2. Type the new password in the New Database Password and Verify New Password fields.
3. Click Change Password to commit the changes.

A dialog box confirms the database password change was successful.

**Figure 835 - Successful Database Password Change dialog**

4. Click OK.

The database password is changed.

User accounts without the Administer ThinManager Servers security role can change the running database password. However, they are prompted to enter the current database password. See [Figure 836 on page 589](#).

**Figure 836 - Current Database Password and Integrity Check**

ThinManager Server Configuration Wizard

**Database Management**  
Allows user to change database password and other utility functions

Database Password

New Database Password

Verify New Password

Current Database Password

Change Password

Database Health

Run DB Integrity Check

Vacuum can reduce the database size

Vacuum

< Back   Next >   Finish   Cancel   Help

---

**IMPORTANT** Backups are still unrecoverable if the password is lost.

---

- Click Run DB Integrity Check to run an integrity check on the configuration database.




Contact Technical Support if any errors result from the integrity check.

- Click Vacuum to compress the running database, which is useful prior to database exportation or major database change.
- Click Finish to exit the wizard, or click Next to proceed to the Multicast Configuration page.

Multicast Configuration Page

Figure 837 - Multicast Configuration Page



- 1. Configure TFTP Settings, if required, based on network infrastructure for the following properties.

Setting	Description
Maximum Packet Size	Allows the firmware download packet size to be changed, if needed.
Enable Firewall Compatible TFTP	Enables the firewall friendly TFTP (Trivial File Transfer Protocol) to be used to send firmware to the thin client. This setting makes it easier to get through a firewall.
Enable Multicast	Check to enable multicast.
Enable Smart Multicast	Check to enable Smart Multicast.
Set Don't Fragment Flag	Check to tell the switch to keep the packets together instead of breaking them into fragments. This setting adds the Don't Fragment header in the network packets used to deliver firmware to the thin clients. Network hardware, such as switches and routers, will not break these packets apart. Checked by default because the thin client cannot rejoin fragmented packets.
Advanced	Click to display the advanced settings.
Set to Defaults	Click to return the settings back to the defaults.

You may need to change the settings if there is a conflict with another multicast server on the network.

Multicast provides the ability for an unlimited number of Terminals to boot simultaneously from the same data stream. This feature reduces the amount of network traffic and the load on the ThinManager Server when multiple Terminals boot concurrently. Multicast is especially useful for low-bandwidth connections and highly utilized networks.

Smart Multicast allows the Terminal firmware to be sent directly to the Terminal while a single Terminal boots. If additional Terminals request the Terminal firmware at this time, the firmware is multicast so that all Terminals can receive the firmware from a single data stream. If Smart Multicast is disabled, the firmware is always sent as a multicast transmission.



Multicast is only available on Terminals with ThinManager Boot Loader Version 5.0 and later. No local Terminal configuration is needed to use Multicast.

When a ThinManager error check determines that a Terminal's multicast download failed, the firmware download is switched to unicast. The thin client continues to try to use multicast at each boot, but uses unicast if multicast continues to fail.

**Figure 838 - Advanced Multicast Options**

Changing the multicast settings is beneficial if there is a conflict with another multicast server on the network.

Setting	Description
<b>Multicast Settings</b>	
Address	IP address used for Multicast transmissions.
Port	Destination port used for Multicast transmissions.
Time-to-Live (TTL)	Maximum number of router hops for Multicast packets. Set to 255 to allow for unlimited hops.
<b>IGMP Settings</b>	
Internet Group Management Protocol	
Version	Sets the IGMP version for use with multicast-capable routers.
Time-to-Live (TTL)	Sets the time-to-live value for IGMP packets.

2. Click Next to continue, Finish to save and close, or Cancel to close and not save.

HTTPS Server Settings Page


The HTTPS Server Settings page is used to set the HTTPS port for ThinServer and API settings. By default, the HTTPS port is enabled and set to Port 8443. This port is used to deliver some modules after the firmware delivery and is used to access the API. If set to 0, modules will be delivered via UDP 69 and UDP 4900 and the API will not be accessible.

To use the API, Enable API Endpoints must be checked. This is in addition to setting the HTTPS Port to a valid number. API end point documentation is intended to be accessed via a web browser and can be found at https://[thinserverhostIP]:[HTTPS port]/api/documentation. For example, to connect with the default port when ThinServer is installed on the local host, navigate to https://localhost:8443/api/documentation. The API supports GET, POST, PUT, and DELETE methods.

For more information on the API, see page [insert page here in Ch. 4 ThinManager® System]

See [API on page 57](#) for more details.

Figure 839 - HTTPS Server Settings Page




Setting	Description
HTTPS Port	This sets the TCP port which the HTTPS server will run on for access to the API.
Enable API Endpoints	Enabling this settings allows for an entry point to communicate with the HTTPS server. Without enabling this setting, the API cannot be utilized.
Allow User Login	This setting allows for User API Keys to be generated using the Login API endpoint. The ThinManager API allows for application keys and user keys to be generated. When enabled, users can generate their own API key from the login endpoint. API User keys are inherited from the users group membership role as defined in ThinManager Security Groups.
User Quota (time and unit)	Sets the number of times a user can use an user API key to authenticate a method on an endpoint for the specified rolling duration.
Button	
Manage Keys	Launches the Manage API Keys wizard which allows for API keys to be created, edited, or deleted. The Manage Keys wizard will manage both application and user API keys.

### Why Change from Default Settings?

The API for ThinServer is not enabled by default, and must be enabled to communicate with any of the endpoints. When enabled, only application keys are enabled without enabling user keys. User keys allow users to self-generate a key to authenticate their use of the API for the endpoints which their ThinManager Security Group would allow them to configure.

**Figure 840 - Manage API Keys Dialog**



**Importance of Page:** This page allows an administrator to view all user and application API keys that have been created in the system. User keys will be named with a Windows username and application keys will be named with a logical name given by the administrator during creation. The prefix of each key will be shown to help identify the key but cannot be used alone for authentication. The full key value is required for endpoint authentication. Application key values cannot be retrieved after their creation. A key can be created, modified, or deleted from this page. This page also displays information such as create date, rolling usage quota, create date, disable date, and status.

Button	Description
Generate New Key	Launches a page to create a new application API key.
Enable API Endpoints	Enabling this settings allows for an entry point to communicate with the HTTPS server. Without enabling this setting, the API cannot be utilized.
Edit	After one of the listed API keys is selected press this button to launch the Edit API Key page, where the permissions, quota, and disable date are modified.
Delete	Press to delete the selected PI key.

### Why change from default settings?

API Keys are required to access the API endpoints. Users who no longer have access to the API endpoints can have their key disabled or deleted. Keys which need a more or less restrictive access to the API can be modified with the appropriate permissions.

Figure 841 - Generate API Key

Generate API Key

Name

Disable at

05/16/2023

4:50 PM

Quota

1000

per Hour

Key Permissions

Available

Connect  
Shadow  
Interactive Shadow  
Reset Sessions  
Kill Processes  
Reboot Terminal Servers  
Connect to Terminal Servers  
Logoff TermSecure Users  
Administer ThinManager Server  
Create Terminals

Allowed

Key

9grme6lVE..4pkhTtp6Xe0lJ3virmGsOQ3aN12pEYdGqw==

Please copy and save this API key.  
This key wont be displayed in its full state again!

OK

Cancel

Importance of Page: API keys provide access for authentication to communicate with API endpoints. If this page was accessed from the Generate New Key button, then the Name field appears empty. The full API key is displayed in the Key field at the bottom of the page if a new API key is generated.

**IMPORTANT** This key will not be displayed in its full state again and must be copied and stored for use.


Fields	Description
Name	Enter the name of an application key here. If the page was accessed from the Edit button on the Manage API Keys page, this field is already populated and can be edited from this window.
Disable at	Set the date and time to disable the key, which prohibits the connection to any API endpoints that occur after the specified value.
Quota	(numeric input and rolling time duration) Set the limit for the number of times an API key can be used to authenticate a method within the specified rolling time frame. Each endpoint is authenticated every time a method is called from the API.
Available	This list box shows the ThinManager functions available via API endpoint when authenticating with the API key in the Name text field. Double-click the functions to add them to the Allowed list.
Allowed	This list box shows the ThinManager functions granted to the API key in the Name text field of the page. Double-click these functions to remove them from the list.
Key	Displays the API key required to establish communication with the API for any desired endpoint. When editing a key, only the key prefix is shown. The key prefix cannot be used to authenticate the API. Note: When creating a new application key, the key is only displayed in its full state one time. Therefore, the key must be copied and saved in a safe place for use.

Why Change from Default Settings?

API keys grant access to endpoint methods. Key creation and modification allow for granular permissions to be distributed to users and applications utilizing the ThinManager API. Quotas and disable dates, prevent unauthorized access, and provide a method to revoke access for applications or users who access ThinManager from the API.

Shadow Configuration Page

Figure 842 - Shadow Configuration Port



By default, the Shadow port in ThinManager is Port 5900. This can be changed under Shadow Options.


Setting	Description
Shadow Port	ThinManager uses port 5900 as the default shadow port. Enter a different port number into the Shadow Port field to change the port used if it is in conflict with another process's use of the port.

ThinManager uses the same port as VNC. If VNC is installed on a WinTMC PC, then there could be a conflict between shadow services. If this happens, the port can be changed in ThinManager.

1. Click Finish to accept changes or select Cancel to close without making changes.

Biometric Device Configuration Page

Figure 843 - Biometric Device Configuration



- 1. Navigate to the Biometric Device Configuration page and select the properties, as required, as described here.


Setting	Description
Support Finger Print Readers	Enables the use of readers.
Fingerprint storage format	From the pull-down menu, choose the data format you plan to use. There are two formats: ISO_19794_2_2005 and ANSI_378_2004.
False Match Probability	Sets the sensitivity of the read. 1/100 is less sensitive than 1/1,000,000.

- 2. Click Finish to accept the changes.

## Docker Server Settings Page

The Docker Server Settings page of the wizard is where the user can set the range of ports used for containers. Each connection to a container uses its own unique RDP port.

**Figure 844 - Docker Server Settings Page**



The screenshot shows the 'Docker Server Settings' page of the 'ThinManager Server Configuration Wizard'. The window title is 'ThinManager Server Configuration Wizard'. The page title is 'Docker Server Settings' with the subtitle 'Settings for docker servers'. The main content area is titled 'Docker Server RDP Port Settings' and contains a checkbox labeled 'Use Default Port Settings' which is checked. Below the checkbox are two text input fields: 'Docker Server Minimum RDP port' with the value '3390' and 'Docker Server Maximum RDP port' with the value '65535'. At the bottom of the window are five buttons: '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

If Use Default Port Settings is checked, containers use port 3390 and increment by one per connection. If the checkbox is cleared, the user can input custom port numbers.

**Notes:**



## MultiMonitor

The MultiMonitor method uses specific ThinManager-ready thin clients that have multiple video ports built into the hardware. Beginning with ThinManager version 11.1, the number of monitors is dependent on available video ports on a thin client. These monitors can be configured to merge into an expanded desktop, called “spanned” by ThinManager; or can display individual desktops, called “screened” by ThinManager; or combinations of “spanned” and “screened” sessions.

WinTMC supports MultiMonitor sessions on PCs that run Windows on multiple desktops.


MultiMonitor is configured in the Terminal Configuration Wizard or the Group Configuration Wizard.

**Figure 845 - Terminal Hardware**

The screenshot shows the 'Terminal Hardware' page of the 'Terminal Configuration Wizard'. The window title is 'Terminal Configuration Wizard'. The page header says 'Terminal Hardware' and 'Select the manufacturer and model of this terminal.' Below this, it says 'Use this to configure the type of hardware for this terminal.' There are two dropdown menus: 'Make / OEM' with 'Arista' selected, and 'Model' with 'BoxPC240' selected. Below these, the 'OEM Model' is 'BoxPC240-ACP' and the 'Video Chipset' is 'Via Unichrome'. There is a 'Terminal Firmware Package' dropdown with 'Model Default' selected. Below that, it says 'Terminal will run Package 7.'. There is a section for 'Terminal ID and IP Address' with a 'Terminal ID' field containing 'None' and buttons for 'Clear' and 'Edit'. At the bottom, there are buttons for '< Back', 'Next >', 'Finish', 'Cancel', and 'Help'.

1. On the Terminal Hardware page of the Terminal Configuration Wizard, choose a MultiMonitor-capable thin client to initiate MultiMonitor configuration.

**Figure 846 - MultiMonitor - Enable MultiMonitors**




MultiMonitor requires the use of Display Clients.

2. On the Terminal Mode Selection page, check Use Display Clients to make the Enable MultiMonitor terminal mode available.
3. Click Next until the MultiMonitor Layout page appears.

## MultiMonitor Layout Page

The MultiMonitor configuration process changed in ThinManager 11.1.

**Figure 847 - Monitor Layout**



The default setting shows two monitors. You can add more as needed.


Setting	Description
Add	Launches the Monitor Properties dialog box and adds a new monitor.
Delete	Deletes a highlighted monitor.
Edit	Opens the Monitor Properties dialog box of a highlighted monitor, where the resolution can be changed.
Reset Scale	Centers the monitors in the configuration wizard. Also, you can use the scroll wheel of the mouse to zoom in and out.
Choose Layout	Allows you to select from layout templates. Otherwise, you can drag monitors to a location.

The monitor resolution is set in the Monitor Properties.

1. Click Add.

The Monitor Properties dialog box appears, where the monitor resolution is set when you create another monitor.


**Figure 848 - Monitor Properties**



Setting	Description
Resolution	Choose the desired video resolution for the monitor from the pull-down menu.
Rotation	Choose the clockwise rotation, in degrees, for a monitor from the pull-down menu. Use when the monitor is in vertical, portrait mode versus horizontal, landscape mode.
Refresh Rate	Choose the refresh rate for the monitor from the pull-down menu.


2. Click OK to return to the Monitor Layout page.

Figure 849 - Monitor Layout Page



Once the necessary monitors are added, drag them to move them.

Figure 850 - Monitor Layout - Rearranged




The Screen Layout page of the Terminal Configuration Wizard allows you to logically segment the monitors. Each letter represents a unique group of monitors. Sessions on monitors that share the same letter are called “Spanned” sessions and logically act like a single monitor. Sessions on monitors that have a unique letter are called “Screened” sessions, and the session appears on the specified monitor only.

Spanned monitors must form a rectangular shape and have the same resolution.

All monitors start as Screen A.

**Figure 851 - Monitor Layout - Screen Letters Assigned**




3. Choose the screen letter from the Screen pull-down menu to change a monitor letter designation, and then click a monitor icon, which applies the monitor letter to the screen.

Monitors can share a desktop if they have the same letter designation. They must be the same resolution and form a rectangle; they cannot be askew.

4. Click Edit Properties.

The Screen Options dialog box appears, where you can configure monitor properties.

Figure 852 - Screen Options Dialog Box



The Reset Scale button on the Monitor Layout page makes monitor configuration easier to see once in order.

Setting	Description
Main Monitor	Sets which monitor has the mouse focus on boot and displays the Relevance Main Menu.
Allow Display Clients to move to/from screen	Allows you to move Display Clients from monitor to monitor because it lets you open the Display Client in a different monitor.
Show Display Client Selector	Makes the Group Selector pull-down menu available.
Selector Options	Makes the Display Client Selector Options dialog box appear.
Auto-hide Selector	Check to hide the Group Selector pull-down menu. Clear the checkbox to display the Group Selector.
Tile on Selector Activation	If selected, tiles the sessions when an auto-hide selector is activated.
Select Menu Size	Allows you to change the size of the Group Selector.
Enable Tiling	Shows all Display Clients assigned to a monitor in a tiled mode, if selected. Select one tile to display it on the full monitor.
Tiling Options	Opens the Tile Options dialog box that configures tile options.
Show Grid	Displays grid lines when it is tiled.
Tile Activity Time (secs)	Sets the time before the monitor reverts to tiled mode when a single screen is displayed.
Tile Display Clients at start up	Configures the monitor to show the display clients in tiled mode at startup.
Include Main Menu as tile	Adds a tile with the Main Menu in it, which is handy for terminals with touch screens.
Tile Interactive	Changes the behavior of the mouse. Instead of a switch from tiled mode to a single display client, it allows the user to click in the tiled session and use the session in the tiled mode.
Screen Specific Mouse Button Mapping	Allows you to assign actions to mouse buttons.

Setting	Description
Mouse Button Mapping	<p>Opens the Mouse Button Mapping dialog box, where each mouse button can be configured with one of these actions.<sup>(1)</sup></p> <ul style="list-style-type: none"> <li>• Calibrate Touch Screen</li> <li>• Tile</li> <li>• Swap</li> <li>• Full Screen</li> <li>• Go to next display client</li> <li>• Go to previous display client</li> <li>• Log on ThinManager user</li> <li>• Main Menu</li> <li>• Left Mouse Button</li> <li>• Right Mouse Button</li> <li>• Middle Mouse Button</li> <li>• Scroll Up</li> <li>• Scroll Down</li> <li>• Virtual Keyboard</li> <li>• Disable Button</li> </ul>
Use Microsoft Extended Desktop	<p>Apply the Microsoft Extended Desktop to a spanned set of monitors. With the Microsoft Extended Desktop, an expanded application stops at the monitor boundary as it does in Windows. Without the Microsoft Extended Desktop, an expanded application fills the entire desktop.</p>
Main Desktop Monitor	Sets which monitor of a spanned set is the primary desktop.
MultiStation Options	Applies to MultiStation, a feature where a MultiMonitor thin client can support several users by adding multiple keyboards and mice. It is turned on by selecting the Enable MultiStation checkbox on the Terminal Mode Selection page of the Terminal Configuration Wizard.
Station has a keyboard	Use this checkbox if you are using a keyboard with MultiStation.
Station has a mouse	Use this checkbox if you are using a mouse with MultiStation.
Screen Edge Display Client Selection	Allows you to switch between display clients by moving the mouse to either edge of the monitor.

(1) Touch Screen Modules have a Hold Time that can convert a long touch to a right-click. Use the Mouse Button Mapping feature to apply any of these actions to the long hold.



The desktop of a spanned session is limited to 4096 x 2048 in Server 2008 R2 and earlier. The resolution of a Server 2012 is 8196 x 8196. The Use Session Size Limits pull-down menu on the MultiMonitor Video Setting page allows you to change to this higher resolution.


The selection of monitor resolution on the MultiMonitor Video Settings page can affect the number of monitors that you can add to a spanned session.

##### 5. Click Next to continue.

The Display Client Selection page of the Terminal Configuration Wizard appears, where Display Clients are assigned to the screens.


## MultiMonitor Display Client Selection Page

**Figure 853 - Display Client Selection**



1. From the Screen pull-down menu, choose the screen.
2. Highlight a display client in Available Display Clients list and use the right-facing arrow to move it to the Screen list on the right side of the dialog box.

**Figure 854 - Change Screen Letter**



3. In the Screen pull-down menu, change the screen letter to choose a different screen to which to apply the display client. The icon of the screen changes color to show which screen is being edited.

Multiple display clients can be added to each screen.




#### 4. Click Override.

The Override Settings dialog box appears, where you can apply customized settings to the display client.

## Override Function

By default, Microsoft restricts each user to a single session on a server. Keep this setting to prevent conflicts. If it is disabled, then a user creates multiple sessions, which consumes licenses and resources, which makes it more difficult to connect to the proper session.


**Figure 855 - Limit Number of Sessions**



MultiMonitor has an Override function that allows Display Clients on a MultiMonitor thin client to log in with different user accounts or video resolutions. This prevents conflicts between monitors over a single session.


This could be necessary to run duplicate copies of a program on the same thin client.

Figure 856 - Remote Desktop Server Users




In reality, a user can log in to a Remote Desktop Server multiple times as long as they are running different applications. Each Username/Application needs to be unique.

It is common to want to run the same application twice on MultiMonitor displays. Typically, that presents a problem. However, the Override function solves this issue.

**Figure 857 - Override Button**

1. Highlight a Display Client assigned to the MultiMonitor thin client on the Display Client Selection page.
2. Click Override.

The Override Settings dialog box appears.

**Figure 858 - Override Settings**

- 3. Click Override to activate the respective override setting and allow customization.

Setting	Description
Display Name	Allows the display client to show a different name than the one originally listed.
Windows Login Settings	Allows different credentials to be used for the display client.
AppLink Command Line	Allows different command line parameters to be applied to the program.
Video Settings	Allows the resolution of the display client to be changed from the monitor setting.



When multiple user accounts are used on a Terminal, it does not affect the “Per Device” TS/RDS CAL count, but it requires more “Per User” TS/RDS CALs.

Figure 859 - Display Client Selection





Figure 859 shows the Override button and the Plus icon for a Display Client with its properties overridden.

- 4. Repeat for any display client that requires a different user account.

Share Keyboard and Mouse Module

The Share Keyboard and Mouse module allows several ThinManager-ready thin clients to be controlled with a single keyboard and mouse without the need of a KVM (Keyboard/Video/Mouse) switch.

**Figure 860 - Share Keyboard and Mouse Layout**

### Shared Keyboard and Mouse Module

The Share Keyboard and Mouse module can be used by placing several monitors connected to ThinManager-ready thin clients side-by-side or top-to-bottom. The Share Keyboard and Mouse Master module is loaded on the center thin client. This module is configured by adding the IP addresses of the secondary follower thin clients. The other Terminals receive the Share Keyboard and Mouse follower module.

Place three Terminals and their monitors side-by-side.

### Master Thin Client Configuration

One thin client needs to be configured as the Master. It is the dominant Terminal whose keyboard and mouse are used to control the grouped Terminals.

1. Double-click the center Terminal in the ThinManager tree.

The Terminal Configuration Wizard appears.

2. Click Next until the Module Selection page appears.
3. Click Add.

The Attach Module to Terminal dialog box appears.


4. Highlight Share Keyboard and Mouse Master Module and click OK.

The module appears in the Installed Modules list of the Module Selection page.

5. Highlight Share Keyboard and Mouse Master Module and click Configure.

The Module Properties dialog box appears.

**Figure 861 - Share Keyboard and Mouse Master Module**



The Share Keyboard and Mouse Master module has a few settings.

Setting	Description
Left Terminal IP Address	Enter the IP address of the left Terminal, if present.
Right Terminal IP Address	Enter the IP address of the right Terminal, if present.
Top Terminal IP Address	Enter the IP address of the top Terminal, if present.
Bottom Terminal IP Address	Enter the IP address of the bottom Terminal, if present.
Allow Interactive Shadow of Master	Controls whether the master Terminal is allowed to be controlled by a remote user.

- 6. Click Done.
- 7. Restart the ThinManager-ready thin client to apply the changes.

**Replica Thin Client Configuration**

The other Terminals in the group need the Replica module.

- 1. Double-click each Terminal in the ThinManager tree.

The Terminal Configuration Wizard appears.

- 2. Click Next until the Module Selection page appears.
- 3. Click Add.


The Attach Module to Terminal dialog box appears.

- 4. Highlight Share Keyboard and Mouse Follower Module and click OK.

The module appears in the Installed Modules list of the Module Selection page.

- 5. Highlight Share Keyboard and Mouse Follower Module and click Configure.

The Module Properties dialog box appears.

**Figure 862 - Share Keyboard and Mouse Follower Module Properties**

The Share Keyboard and Mouse Follower Module Properties dialog box has one parameter that allows the replicas to point to a master.

Setting	Description
Master IP Address	Set to ANY, then this Terminal can be added to several master Terminals and controlled from any. To prevent confusion, a single master Terminal can be defined in the field.

6. Click Done.
7. Restart the ThinManager-ready thin client to apply the changes.

Once the ThinManager-enabled thin clients are booted, the mouse on the master thin client can be moved seamlessly into the other desktops. The keyboard is active in the screen on which the mouse pointer is present.

This allows an operator to have control of several displays with only one keyboard and mouse. The mouse movement is seamless, allowing access to displays without switching.



A Controller Share Keyboard and Mouse session cannot be interactively shadowed in ThinManager unless that parameter is activated.

The keyboards and mice for the follower thin clients can be left attached, but stowed away until a multi-user configuration is needed.

## Share Keyboard and Mouse with MultiMonitor

The Share Keyboard and Mouse module became less popular as MultiMonitor hardware was introduced. It is easier to use a single MultiMonitor thin client to show multiple displays than to use several thin clients and the Share Keyboard and Mouse module. However, the module regained popularity when using it to tie multiple MultiMonitor thin clients to set up a control room environment.

**Figure 863 - MultiMonitor with Share Keyboard and Mouse**

MultiMonitor Shared Keyboard and Mouse Module

The configuration of the Controller and Follower Share Keyboard and Mouse modules are the same with MultiMonitor thin clients as they are with single monitor thin clients.



# Reports

ThinManager has the ability to run reports, show data, and collect data on the ThinManager system. These reports can show the event log, configurations, uptimes, and other data.

A Report tab on the Details pane shows a report for a highlighted ThinManager Server, Terminal, Terminal group, Remote Desktop Server, TermSecure user, or ThinManager User group.

Reports can be scheduled to be run and saved as \*.html or \*.CSV files for storage or further analysis.


## Select Reports

The reports are displayed on a Report tab in ThinManager.

1. Choose View>Select Reports from the ThinManager menu.

The Select Reports dialog box appears, which allows the selection of which report to display.

Figure 864 - Select Reports



The Select Reports dialog box has four fields that determine which report is displayed on the report tab.

Setting	Description
System Report	Choose the report to display on the Report tab when the ThinManager Server is highlighted.


Setting	Description
Terminal Report	Choose the report to display on the Report tab when a Terminal or Terminal group is highlighted.
Remote Desktop Server Report	Choose the report to display on the Report tab when a Remote Desktop Server is highlighted.
ThinManager User Report	Choose the report to display on the Report tab when a ThinManager User or ThinManager User Group is highlighted.

2. Use the pull-down list to select the desired reports.

Report Tab

The reports chosen in the Select Reports dialog box are displayed on the Report tab in ThinManager.

Figure 865 - Report Tab




3. Highlight the desired ThinManager Server, Terminal, Terminal group, Remote Desktop Server, or ThinManager user, then click the Report tab to display the report.

Print Report

1. Choose one of the following methods to start the process to print a report.
- a. Click the Report tab and choose View>Print from the ThinManager menu.
  - b. Right-click on the report inside of the Details pane.

The Print dialog box appears with all the printers defined on the ThinManager Server.

Figure 866 - Print Dialog Box



2. Highlight the desired printer and click Print to print the report.

## Report Template Installation


ThinManager installs a number of reports into the ThinManager folder at installation. The default location is C:\Program Files\Automation Control Products\ThinManager\ReportTemplates.

New Reports are added to service packs and new releases. Additional report templates can be downloaded from <http://downloads.thinmanager.com/> as they become available.

1. Choose Install>Reports from the ThinManager menu to install new reports.

The Reports dialog box appears.

Figure 867 - Reports




2. Click one of the following radio buttons.

Setting	Description
Report Templates	Click to browse for *.html files.
SQL Files	Click to browse for *.sql files.
Images, Finished Reports, etc.	Click to browse for assorted files.

3. Click Install.

**Figure 868 - File Browser**



Each report has an \*.html or \*.CSV component and an \*.sql component.

4. Click the Report Templates radio button, browse to the new \*.html file, and click Open to install.
5. Click the SQL Files radio button, browse to the new \*.sql file, and click Open to install.

Once these two components are added, the report is available.

## Scheduling

Reports can be scheduled to run once at a specified time or regularly at a specific time. The reports are saved as \*.html files for storage or further analysis.

Scheduling is available for more than to run reports. Schedules can be created for these items.

- The System in the ThinManager Server Configuration Wizard
- Terminals in the Terminal Configuration Wizard
- Remote Desktop Servers in the Remote Desktop Server Configuration Wizard
- TermSecure Users in the ThinManager User Configuration Wizard


### System Scheduling of Reports

Reports are scheduled on the ThinManager Server Configuration Wizard. Follow these steps to schedule report generation.

1. Right-click on the ThinManager Server icon and choose Modify.

The ThinManager Server Configuration Wizard appears.


**Figure 869 - ThinManager Server Configuration Wizard - System Schedule**



- 2. Click Next until the System Schedule page appears.
- 3. Click Edit Schedule.

The Event Schedule dialog box appears.

**Figure 870 - Event Schedule**



- 4. Click Add.

The Schedule dialog box appears, which allows system events configuration.

**Figure 871 - Schedule Window**


Setting	Description
Event Type	Choose the event.
Backup Biometric Database	Choose to schedule automatic backup of the biometric (fingerprint) data, which is kept in a separate database.
Backup Configuration Database	Allows an automatic schedule of the configuration database.
Run Report	Allows you to run a report and save it as an *.html file on a regular basis.
Report Template File	Allows you to select the type of report and whether to save it as *.html or *.CSV.
Report Output File	Applies the naming convention to the saved reports.
Auto Generate Filename	Check to save the file to the ThinManager folder with the report name and a time stamp as its title. Clear the checkbox to type a desired filename, which must end in .html or *.CSV, depending on the template.
Repeat Interval	Sets the frequency of report generation.
Time	Sets the time of report generation and changes based on the Report Interval. The Time field can allow dates, days, hours, or intervals to be set for the report.

There are a few changes that allow the filename to be modified with a timestamp for identification purposes. If you do not use a timestamp, the file is overwritten each time the report is run.

- %c – Adds date and time
- %h – adds hour (0-24)
- %M – adds minute (0-59)
- %x – adds date
- %X – adds time

5. Once the report is configured, click OK to accept the report schedule.

Figure 872 - Event Schedule




The scheduled report is displayed in the Event Schedule dialog box.

Setting	Description
Add	Adds another report schedule.
Edit	Edits the schedule of a highlighted report.
Delete	Deletes the schedule of a highlighted report.
OK	Accepts the schedules and closes the dialog box.


When a report is run, the files are saved to be viewed.

Figure 873 - Saved Reports



Once the report is run, it can be opened in a web browser if it is in \*.HTML format or in a spreadsheet application if in \*.CSV format.



**Figure 874 - Report Shown in Browser**


Event Type	Type	Name	Description	Time	User
Synchronization	system	system	Not Synchronized	03/13/15 14:16:32	
ThinServer	system	ThinServer	ThinServer Service started	03/13/15 14:16:32	system
MonitorConnection	terminal	C03FD56D3FC0	Monitor Connection Established	03/13/15 14:20:09	
TerminalSystemEvent	terminal	C03FD56D3FC0	Received Configuration from ThinManager Server 10.7.10.31	03/13/15 14:20:09	
TerminalSessionEvent	terminal	C03FD56D3FC0	Session Established on Server Green12 for Display Client HMI	03/13/15 14:20:10	
TerminalSessionEvent	terminal	C03FD56D3FC0	Session Established on Server Green12 for Display Client Desk_12	03/13/15 14:20:10	
MonitorConnection	terminal	C03FD56D3FC0	Monitor Connection Lost	03/13/15 14:21:07	
MonitorConnection	terminal	C03FD56D3FC0	Monitor Connection Established	03/13/15 14:21:11	
TerminalSystemEvent	terminal	C03FD56D3FC0	Received Configuration from ThinManager Server 10.7.10.31	03/13/15 14:21:11	
TerminalSessionEvent	terminal	C03FD56D3FC0	Session Established on Server Green12 for Display Client HMI	03/13/15 14:21:11	
TerminalSessionEvent	terminal	C03FD56D3FC0	Session Established on Server Green12 for Display Client Desk_12	03/13/15 14:21:11	
MonitorConnection	terminal	C03FD56D3FC0	Monitor Connection Lost	03/13/15 18:34:36	
MonitorConnection	terminal	C03FD56D3FC0	Monitor Connection Established	03/13/15 18:34:43	
TerminalSystemEvent	terminal	C03FD56D3FC0	Received Configuration from ThinManager Server 10.7.10.31	03/13/15 18:34:43	

Once the report is generated the data can be saved or reformatted, as desired, using standard HTML tools.

## Schedule Configuration Backups

It is a good idea to back up your ThinManager configuration before you make any major changes. You can use the Scheduler to do this automatically.


To schedule report generation, follow these instructions.

1. Right-click the ThinManager Server and choose File>Modify.

The ThinManager Server Configuration Wizard appears.

2. Click Next until the System Schedule page appears.


**Figure 875 - System Schedule Page**



3. Click Edit Schedule.

The Event Schedule dialog box appears.

**Figure 876 - Event Schedule**



4. Click Add.

The Schedule dialog box appears, which allows system events, like configuration backups, to be created.

Figure 877 - Schedule Dialog Box

Schedule

Event Type

Backup Configuration Database

Backup File

☒ Auto Generate Filename

Browse

Repeat Interval

☐ Once Only

☒ Weekly / Daily

☐ Time Interval

☐ Monthly

☐ Yearly

Weekly Schedule

☐ Monday

☐ Tuesday

☐ Wednesday

☐ Thursday

☒ Friday

☐ Saturday

☐ Sunday

Every Day

Time

8:00 PM

Cancel

OK

Create a system event based on these settings.

Setting	Description
Event Type	Choose Backup Configuration Database from the pull-down menu.
Repeat Interval	Click Weekly/Daily.
Weekly Schedule	Check a day.
Time	Choose a time.

5. Click OK to accept the changes.

A weekly backup allows you to have a current configuration available in case you need one.

**Notes:**

## TermMon ActiveX

ActiveX can be used to monitor and provide useful information about client hardware. TermMon (Terminal Monitoring) ActiveX can be embedded into an application that runs on the Remote Desktop Server. When a Terminal starts a session on the server and launches the application with TermMon ActiveX, ActiveX creates a socket connection to the Terminal and the session. ActiveX is able to pull data from the Terminal into the application using the events, methods, and properties that are provided by TermMon.

TermMon Active X is commonly used by customers that have Automation HMI products. With this ActiveX, customers can get information about the Terminal, sessions that are running, users that are logged on, and the current Location for Relevance applications. You can create tags for the data and populate them with data from the client via the ActiveX.

There are also methods to control the current Display Client, logged on Users, IP Cameras overlays, and many others.

For Location Services, the main use case is for Location. Once a mobile device resolves to a Location, a string property is available that has the path and name of the current Location. If you have nested Locations, it provides this information in a path form, such as “ParentLocation\ChildLocation\ChildLocation”. This can be a very versatile item for customers that are using HMIs and want to control access to pages, security, and other things based on the Location.

One other Location Services feature in the ActiveX is the ability to trigger an Operator to scan a code through the application. This can be used to provide an extra layer of safety and security to an application. It can be tied to any operation in the HMI.

For example, the feature could be added to a button to run a pump. Prior to the command to run, an event can be triggered that prompts the Operator to scan a code. The operator then scans a QR Code, which returns a result to the HMI. Then, the code on the button determines if it can provide the command to run the pump based on whether it received the expected information from the Location via the ActiveX.

The ActiveX also contains properties that allow you to Logon or Logoff (Enter or Exit) of a Location via ActiveX. This tells the session which Location to log in to by passing a string to the appropriate ActiveX property. The Logoff item is the same as the Leave button that is part of the iTMC application.

## Register the Control

The TermMon ActiveX Control can be found on the ThinManager CD as `termmon.ocx`. Also, it is available in the Download section of [www.thinmanager.com](http://www.thinmanager.com).

The Control must be registered before it can be used. Copy the file `termmon.ocx` to the computer where you want to use it. Register the OCX by executing `regsvr32 <path\termmon.ocx>`.

## Read-only Properties

The following properties are read-only strings. An event is generated any time one of these properties changes. The Enable method must be invoked prior to reading these properties.

Property	Description
TerminalName	Name of the Terminal.
TerminalModel	Terminal model number.
TerminalIP	Terminal IP address.
TerminalMAC	Terminal MAC address.
TerminalBootLoaderVersion	Terminal network boot loader version.
TerminalFirmwareVersion	Firmware version that the Terminal runs.
TerminalWindowsUsername	Windows Username that is specified in the Terminal's ThinManager configuration.
TermSecureUsername	TermSecure username of the TermSecure user currently logged on to the Terminal. If no TermSecure user is logged on, this value is blank.
TermSecureWindowsUsername	Windows Username associated with a TermSecure user and all TermSecure user sessions. If no TermSecure user is logged on, this value is blank.
TerminalServerGroupList	A comma-separated list of Display Clients currently run on the Terminal.
ConnectionState	The Control's connection state with the Terminal.
CurrentTerminalServerGroup	The Display Client that is currently displayed on the Terminal.
CurrentWindowsUsername	Windows Username of the session where the Control has been executed. This property is not available when the RunInSession property is set to False.
TerminalServerName	Name of the Remote Desktop Server where the Control runs. This property is not available when the RunInSession property is set to False.
UserID	Identifier associated with a TermSecure user; for example, the number of a security badge used by a TermSecure user when the badge is scanned. Use of this property may require the "Expose ID" setting to be enabled in the appropriate ThinManager module, such as RFIdeas pcProx USB Module.
RelevanceLocationName	The complete path and name of the current Location.
ScanResult	Contains the result of the Command Method Scan Code commands.
BiometricData	Contains the raw data returned from a biometric scan. The format of this data is determined by the Biometric module as configured on the Terminal.
BiometricLookupResult	Contains the result of the ScanBiometricAndQueryUser command. <ul style="list-style-type: none"> <li>TermMonConst.Success - The lookup was successful.</li> <li>TermMonConst.Timeout - The request timed out.</li> <li>TermMonConst.Busy - The Control is busy with another request.</li> <li>TermMonConst.UserNotFound - The scan did not match an enrolled user.</li> <li>TermMonConst.Fail - The operation failed.</li> </ul>
BiometricLookupUsername	Contains the TermSecure username when the result of the ScanBiometricAndQueryUser command is successful.

## Read-Write Properties

These properties can be set by the application.

Property	Description
RunInSession	When the RunInSession property is set to True, the Control runs in the Terminal's Remote Desktop Services session. The Terminal IP Address is determined automatically by the control.
OverrideIP	If the RunInSession property is set to False, the OverrideIP property specifies the IP Address of the Terminal to which the Control connects. <sup>(1)</sup>
WatchdogTime	The number of seconds before the watchdog resets the Terminal session. Once this property is set to a non-zero value, the property must be updated before the watchdog time reaches zero. To disable the watchdog, set this property to zero. The watchdog is disabled by default. <sup>(2)</sup>
ActiveScreen	For MultiMonitor configurations, this is the active screen number. A value of zero (default) will set the active screen to the screen the mouse pointer is on when a method or command is executed. A non-zero value will set the Active Screen to the screen number specified. All methods and commands will be executed on the specified screen.

(1) To use the OverrideIP property, the TermMon ActiveX Control Configuration Module must be added to the Terminal configuration in ThinManager. In the module configuration, Allow ActiveX Connections must be set to YES, and Only Allow Connections from Session must be set to NO.

(2) The Enable Method does not need to be called for watchdog operation. Watchdog operation is independent of the Enable and Disable Methods.

## Events

When a property value changes, an event is generated by the Control. When an Event occurs, the event code can be used to determine the property that changed. The Enable method must be invoked in order to receive events (except for WatchdogTime). The event code is provided by the Control as follows.

- TermMonEvent.TerminalName
- TermMonEvent.TerminalModel
- TermMonEvent.TerminalIP
- TermMonEvent.TerminalMAC
- TermMonEvent.TerminalBootLoaderVersion
- TermMonEvent.TerminalFirmwareVersion
- TermMonEvent.TerminalWindowsUsername
- TermMonEvent.TermSecureUsername
- TermMonEvent.TermSecureWindowsUsername
- TermMonEvent.TerminalServerGroupList
- TermMonEvent.ConnectionState
- TermMonEvent.CurrentTerminalServerGroup
- TermMonEvent.CurrentWindowsUsername
- TermMonEvent.TerminalServerName
- TermMonEvent.WatchdogTime
- TermMonEvent.RelevanceLocationName
- TermMonEvent.ScanResult
- TermMonEvent.BiometricData
- TermMonEvent.BiometricLookupResult
- TermMonEvent.BiometricLookupUsername

## Methods

Method	Description
Enable	Invoke this method to enable the Control. The Control attempts to connect to the Terminal and generates events to update the Control Properties. The Control maintains a connection to the Terminal as long as it is enabled.
Disable	Invoke this method, which causes the Control to break the connection with the Terminal. Events are generated to clear the Control Properties.
Command	The Command method can be used to send Terminal action commands. The Command method requires one parameter, which is the Terminal command, to be performed. The Enable method must be invoked before these commands can be executed (aside for noted exceptions). The supported commands follow.
Reboot	Initiates a Terminal reboot.
Restart	Initiates a Terminal restart.
Calibrate	Initiates a touch screen calibration.
GotoMainMenu	Causes the Main Menu to be displayed.
SwitchToNextGroup	Switches to the next Display Client.
SwitchToPrevGroup	Switches to the previous Display Client.
SwitchInstFailover	Switches the instant failover group.
ChangeTermSecureUser	Disconnects any current TermSecure user sessions, and then displays the TermSecure Log On menu.
LogOffAndChangeTermSecureUser	Logs off any current TermSecure user sessions, and then displays the TermSecure Log On menu.
LogOffTermSecureUser	Logs off any current TermSecure user sessions and returns to a Display Client, which is assigned to the Terminal. If no Display Clients are configured on the Terminal, the TermSecure Log On menu is displayed.
DisconnectTermSecureUser	Disconnects any current TermSecure user sessions and returns to a Display Client, which is assigned to the Terminal. If no Display Clients are configured on the Terminal, the TermSecure Log On menu is displayed.
DisconnectSession	Disconnects the Remote Desktop Services Session on the Terminal. This command does not require that the Enable Method is invoked prior to execution.
LogOffSession	Logs off the Remote Desktop Services Session on the Terminal. This command does not require that the Enable Method is invoked prior to execution.
TileStart	Tiles the Display Clients on the current Screen.
TileEnd	Untiles the Display Clients on the current Screen.
ScanCodeReturnData	Prompts the user to scan a QR Code or Barcode. After the scan is complete, the scan data is returned in the ScanResult property.
ScanCodeAndQueryLocation	Prompts the user to scan a QR Code or Barcode. After the scan is complete, the location path and name is returned in the ScanResult property.
ScanBiometricAndQueryUser	Sends the next Biometric scan to ThinServer and returns the associated TermSecure Username. The result of the operation is returned in the BiometricLookupResult property. Upon a successful result, the TermSecure username is returned in the BiometricLookupUsername property.
SendGenericEvent	Sends an event expression as a string type parameter to ThinServer. Once received by ThinServer, a ThinManager Event with an expression matching the generic event executes the configured ThinManager Event Action.

The Command Method constants are provided by the Control as follows.

- TermMonCommand.Reboot
- TermMonCommand.Restart
- TermMonCommand.Calibrate
- TermMonCommand.GotoMainMenu
- TermMonCommand.SwitchToNextGroup
- TermMonCommand.SwitchToPrevGroup
- TermMonCommand.SwitchInstFailover
- TermMonCommand.ChangeTermSecureUser
- TermMonCommand.LogOffAndChangeTermSecureUser
- TermMonCommand.LogOffTermSecureUser
- TermMonCommand.DisconnectTermSecureUser



- TermMonCommand.DisconnectSession
- TermMonCommand.LogOffSession
- TermMonCommand.TileStart
- TermMonCommand.TileEnd
- TermMonCommand.ScanCodeReturnData
- TermMonCommand.ScanCodeAndQueryLocation
- TermMonCommand.ScanBiometricAndQueryUser
- TermMonCommand.SendGenericEvent

Method	Description
ChangeTerminalServerGroup	Can be used to change the Display Client currently displayed on the Terminal. This method requires one parameter which is the name of the Display Client that the Terminal should switch to.
TermSecureCheckAccess	Can be used to query the access rights of a TermSecure user. This method requires two parameters. The first parameter is the name of the user. The second parameter is the name of the Access Group. This method returns the result of the query as follows.
TermMonConst.Timeout	The request timed out.
TermMonConst.Busy	The Control is busy with another request.
TermMonConst.InvalidMember	User is not a member of the specified TermSecure Access Group.
TermMonConst.ValidMember	User is a member of the specified TermSecure Access Group.
TermMonConst.UserNotFound	The TermSecure Username was not found.
TermMonConst.GroupNotFound	The Access Group Name was not found.
GetGroupScreen	Can be used to determine which screen the specified Display Client is currently on for MultiMonitor configurations. This method requires one parameter which is the name of the Display Client.
TermSecureLogonUser	Can be used to Log On a specified TermSecure user. This method requires two parameters. The first parameter is the name of the TermSecure user. The second parameter is the password of the TermSecure user. The password will be encrypted before being sent to the Terminal. This method returns a result as follows.
TermMonConst.Success	The TermSecure user was successfully logged on.
TermMonConst.Timeout	The request timed out.
TermMonConst.Busy	The Control is busy with another request.
TermMonConst.UserNotFound	The TermSecure username was not found.
TermMonConst.BadPassword	The TermSecure password was invalid.
TermMonConst.NoPermission	The TermSecure user does not have permission to use the Terminal.
TermMonConst.PasswordChangeReq	The TermSecure user is required to change his password.
TermMonConst.NoWindowsUsername	This TermSecure user does not have a Windows Username specified in the TermSecure user configuration. This is only required for Remote Desktop Services Display Clients assigned to the TermSecure User.
TermMonConst.NoWindowsPassword	This TermSecure user does not have a Windows Password specified in the TermSecure user configuration. This is only required for Remote Desktop Services Display Clients assigned to the TermSecure User.
CameraOverlayEnable	Used to enable a camera overlay. This method requires two parameters. The first parameter is the name of the Display Client the overlay is on. The second parameter is the name of the overlay.
CameraOverlayDisable	Used to disable a camera overlay. This method requires two parameters. The first parameter is the name of the Display Client the overlay is on. The second parameter is the name of the overlay.
CameraOverlayCycleStart	Used to start camera cycling for a camera overlay. This method requires two parameters. The first parameter is the name of the Display Client the overlay is on. The second parameter is the name of the overlay.
CameraOverlayCycleStop	Used to stop camera cycling for a camera overlay. This method requires two parameters. The first parameter is the name of the Display Client the overlay is on. The second parameter is the name of the overlay.
CameraOverlaySwitchNext	Used to switch to the next camera in a camera overlay list. This method requires two parameters. The first parameter is the name of the Display Client the overlay is on. The second parameter is the name of the overlay.

Method	Description
CameraOverlaySwitchPrev	Used to switch to the previous camera in a camera overlay list. This method requires two parameters. The first parameter is the name of the Display Client the overlay is on. The second parameter is the name of the overlay.
CameraOverlayFullscreenEnter	Used to make the current camera in a camera overlay enter full screen. This method requires two parameters. The first parameter is the name of the Display Client the overlay is on. The second parameter is the name of the overlay.
CameraOverlayFullscreenExit	Used to make the current camera in a camera overlay exit full screen. This method requires two parameters. The first parameter is the name of the Display Client the overlay is on. The second parameter is the name of the overlay.
CameraOverlaySwitchByName	Used to change cameras in a camera overlay. This method requires three parameters. The first parameter is the name of the Display Client the overlay is on. The second parameter is the name of the overlay. The third parameter is the name of the camera. The camera name must include the full path if the camera is in a camera group.
CameraOverlayMove	Used to change the position of a camera overlay. This method requires four parameters. The first parameter is the name of the Display Client the overlay is on. The second parameter is the name of the overlay. The third parameter is the x location. The forth parameter is the y position.
CameraOverlayResize	Used to change the size of a camera overlay. This method requires four parameters. The first parameter is the name of the Display Client the overlay is on. The second parameter is the name of the overlay. The third parameter is the width. The forth parameter is the height.
CameraOverlayResizeMove	Used to change the size and position of a camera overlay. This method requires six parameters. The first parameter is the name of the Display Client the overlay is on. The second parameter is the name of the overlay. The third parameter is the x position. The forth parameter is the y position. The fifth parameter is the width. The sixth parameter is the height.
RelevanceLocationLogon	Used to log into a location. This method requires two parameters. The first parameter is the complete path and name of the desired location formatted as "top_level_location_name\sub_location_name\location_name". This string must match the location tree hierarchy in the ThinManager location tree. The second parameter is the action to be performed as defined by the TermMonRelevance action constants.
RelevanceLocationLogoff	Log the device out of the current location.
GetCustomVariable	Can be used to retrieve a custom variable. In ThinManager, custom variables can be added to users, locations, and Terminals. This method requires one parameter. The parameter is the name of the custom variable. This method returns the result of the query as follows.
TermMonConst.Timeout	The request timed out.
TermMonConst.Busy	The Control is busy with another request.
TermMonConst.InvalidMember	The custom variable does not exist.
TermMonConst.Success	The request completed successfully.

Upon a successful result, the value of the custom variable can be read from the CustomVariableValue property.

## Control Constants

Constant values provided by the Control are as follows.

## TermMonEvent

Constant	Value
TerminalName	1
TerminalModel	2
TerminalIP	3
TerminalMAC	4
TerminalBootLoaderVersion	5
TerminalFirmwareVersion	6
TermSecureWindowsUsername	7
TermSecureUsername	8
TermSecureWindowsUsername	9
TerminalServerGroupList	10
ConnectionState	11
CurrentTerminalServerGroup	12
CurrentWindowsUsername	13
TerminalServerName	14
WatchdogTime	15
UserID	16
RelevanceLocationName	17
ScanResult	18
BiometricData	19
BiometricLookupResult	20
BiometricLookupUsername	21

## TermMonCommand

Constant	Value
Reboot	100
Restart	101
Calibrate	102
GotoMainMenu	103
SwitchToNextGroup	104
SwitchToPrevGroup	105
SwitchInstFailover	106
ChangeTermSecureUser	107
LogOffAndChangeTermSecureUser	108
LogOffTermSecureUser	109
DisconnectTermSecureUser	110
DisconnectSession	111
LogOffSession	112
TileStart	113
TileEnd	114
ScanCodeReturnData	115
ScanCodeAndQueryLocation	116
ScanBiometricAndQueryUser	117

## TermMonConst

Constant	Value
Success	1
Fail	2
Disconnected	3
Connected	4
Timeout	5
Busy	6
Updating	7
RequestFailed	8
InvalidMember	9
ValidMember	10
UserNotFound	11
GroupNotFound	12
BadPassword	13
NoPermission	14
PasswordChangeReq	15
NoWindowsUsername	16
NoWindowsPassword	17

## TermMonRelevance

Constant	Value
ActionNone	0
ActionTransfer	1
ActionClone	2
ActionShadow	3

The following terms and abbreviations are used throughout this manual. For definitions of terms not listed here, refer to the Allen-Bradley Industrial Automation Glossary, publication [AG-7.1](#).

<b>Access Group</b>	Provides the Relevance permissions that control access to a location, application, or function.
<b>Basic Service Set Identifiers (BSSID)</b>	Describes sections of wireless local area network, or WLAN. Recognizes the access point or router because it has a unique address, which creates the wireless network.
<b>Content</b>	The data, sessions, or information delivered to a thin client, terminal, or mobile device. It could be an HMI, a document, access to a full desktop, a camera image, or a shadow of another client. Deployed as Display Clients.
<b>Dynamic Host Configuration Protocol (DHCP)</b>	A network protocol that enables a server to automatically assign an IP address to a computer from a defined range of numbers.
<b>Fat client</b>	A Terminal with a hard drive that connects to a server.
<b>Fencing</b>	Provides an additional security layer to restrict access to a location via a hierarchy that has a resolver at a top-level location that must be resolved before using a resolver of a lower level.
<b>Global Positioning System (GPS)</b>	A U.S.-owned utility that provides users with positioning, navigation, and timing (PNT) services.
<b>Installation ID</b>	An identifier used in licensing, found near the bottom of the Licensing dialog box. Choose Install>Licenses to launch the Licensing dialog box.
<b>Location</b>	A configured element that is used as an endpoint for content deployment. It can contain display clients for content, be assigned a Windows user account, contain resolver actions, and be assigned to a terminal. An individual location is configured in a manner similar to terminals and TermSecure users in ThinManager.
<b>MAC Address</b>	Media Access Control address, a unique identifier assigned to a network interface controller for use as a network address in communications within a network segment.
<b>Mobile Device</b>	Apple, Android, or Windows device that has the appropriate ThinManager application installed and configured so that it can interact with the ThinManager Platform through Relevance.
<b>Preboot Execution Environment (PXE)</b>	A standardized client-server interface that allows networked computers that are not yet loaded with an operating system to be configured and booted remotely by an administrator.
<b>Relevance</b>	A function of ThinManager that controlled access to applications and assets through Location or User Permissions. Deprecated with version 13.
<b>Relevance ID</b>	The unique ID and name assigned to a new resolver device when it was added to the system. Deprecated with version 13.

---

**Remote Desktop Protocol (RDP)** Microsoft's proprietary protocol that provides a user with a graphical interface to connect to another computer over a network connection.

**Remote Desktop Server (RDS)** A 2008 R2 or later terminal server.

**Resolver** A Bluetooth® beacon, GPS, iBeacon, QR code, or Wi-Fi access point that a mobile device uses to identify a particular area.

**Resolver Actions** The functions that are authorized on a mobile device by a resolver, which include Shadow, Transfer, Forced Transfer, and Clone.

**SmartSession** Provides load balancing between member remote desktop servers. This feature uses CPU availability, memory usage, and session count on the remote desktop servers to determine the load on the servers. ThinManager polls the server every eight seconds to maintain accurate status levels. Thin clients connect to the Remote Desktop Server with the most available resources. When SmartSession is not used, polling is turned off by default.

**TermCap** Terminal Capability, a software library and database that enables programs to use display terminals in a terminal-dependent manner; describes the capabilities of hundreds of different display terminals in great detail.

**Terminal** A client that connects to a server.

**Terminal Server** A computer that acts like a mainframe, allowing clients to log in, start sessions, and run apps on the server but display the results on a terminal.

**TermSecure** The former name for the security component of ThinManager that grants or denies access to content in Relevance, which was deprecated with version 13. Now, ThinManager User Services.

**Thin client** Also, Zero client. A terminal without a hard drive that connects to a server.

**ThinManager** The graphic user interface component of the ThinManager system used to control and configure the ThinServer database.

**ThinManager Server** A computer running the ThinManager interface and the ThinServer service.

**ThinManager User Services** See TermSecure.

**ThinServer** A database engine that contains the ThinManager configuration. It runs as a Windows service that ThinManager hardware communicates with in order to receive firmware, configuration, and to get information related to the Relevance setup.

**Unified Extensible Firmware Interface (UEFI)** New BIOS format for ThinManager Compatible PXE boot thin clients. It requires Port UDP-4011 open.

**Uniform Resource Locator (URL)** Web address of a resource on the Internet or a locally stored file. The resource can be any type of file stored on a server, such as a Web page, a text file, a graphics file, or an application program.

**Zero client** See Thin client.



# Rockwell Automation Support

Use these resources to access support information.

<b>Technical Support Center</b>	Find help with how-to videos, FAQs, chat, user forums, and product notification updates.	<a href="http://rok.auto/support">rok.auto/support</a>
<b>Knowledgebase</b>	Access Knowledgebase articles.	<a href="http://rok.auto/knowledgebase">rok.auto/knowledgebase</a>
<b>Local Technical Support Phone Numbers</b>	Locate the telephone number for your country.	<a href="http://rok.auto/phonesupport">rok.auto/phonesupport</a>
<b>Literature Library</b>	Find installation instructions, manuals, brochures, and technical data publications.	<a href="http://rok.auto/literature">rok.auto/literature</a>
<b>Product Compatibility and Download Center (PCDC)</b>	Download firmware, associated files (such as AOP, EDS, and DTM), and access product release notes.	<a href="http://rok.auto/pcdc">rok.auto/pcdc</a>
<b>ThinManager Website</b>	Visit the ThinManager website to download resources for your ThinManager solution.	<a href="https://thinmanager.com/">https://thinmanager.com/</a>

## Documentation Feedback

Your comments help us serve your documentation needs better. If you have any suggestions on how to improve our content, complete the form at [rok.auto/docfeedback](http://rok.auto/docfeedback).

## Waste Electrical and Electronic Equipment (WEEE)



At the end of life, this equipment should be collected separately from any unsorted municipal waste.

Rockwell Automation maintains current product environmental information on its website at [rok.auto/pec](http://rok.auto/pec).

Allen-Bradley, expanding human possibility, FactoryTalk, ThinManager, and Rockwell Automation are trademarks of Rockwell Automation, Inc.

EtherNet/IP is a trademark of ODVA, Inc.

Docker is a trademark of Docker, Inc.

VMware vCenter is a trademark of VMware, Inc.

Bluetooth is a trademark of Bluetooth SIG, Inc.





Apple, iTunes, and App Store are trademarks of Apple Inc.

Google Play is a trademark of Google LLC.

Windows is a trademark of Microsoft Corporation.

Trademarks not belonging to Rockwell Automation are property of their respective companies.

Rockwell Otomasyon Ticaret A.Ş. Kar Plaza İş Merkezi E Blok Kat:6 34752, İçerenköy, İstanbul, Tel: +90 (216) 5698400 EEE Yönetmeliğine Uygundur

Connect with us.    

**rockwellautomation.com** — expanding **human possibility**™

AMERICAS: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

EUROPE/MIDDLE EAST/AFRICA: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

ASIA PACIFIC: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication TM-UM0016-EN-P - September 2022

Supersedes Publication TM-UM001F-EN-P - May 2022

Copyright © 2022 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.