



ThinManager4.1

Help Manual

Contents

Introduction	1
Documentation Contents	1
ACP ThinManager 4.1	2
What is New in ThinManager 4.1?.....	2
Evolution of ThinManager Terminology	3
Essential ThinManager Functionality.....	3
The Client/Server Relationship in Terminal Services	3
Hardware Configuration Tool	4
Wizards	5
Terminal Server Groups.....	6
Application Groups.....	7
Display Servers and Display Clients.....	8
System Overview	11
Quick Start Checklist.....	11
Required Components	12
Windows Terminal Server Operating System.....	12
Client Communication Protocol.....	12
ThinManager Administrative Software.....	12
ThinManager Ready Thin Client Hardware	13
Connection Overview	14
Failover Overview	14
MultiSession Overview.....	16
MultiMonitor Overview	17
TermSecure Overview	17
Installation of ThinManager	19
Standard ThinManager Installation in Windows 2003	19
WinTMC Installation.....	27
Licensing ThinManager	35
ThinManager Licensing.....	35
Master License Advantages.....	36
License Activation	36
Adding a Master License to ThinManager	53
Delete License	55
License Details.....	55
Install Demo Code	56
Show Old Licenses	56
WinTMC Licenses.....	57
TermSecure Licenses	57
Upgrading to ThinManager 4 from Older ThinManager versions	57

Redundant ThinManager Servers	59
Redundancy Overview	59
Redundancy Differences.....	60
Creating a Redundant Pair of ThinManager Servers.....	61
Creating Mirrored Redundancy	61
ThinManager Interface	63
Opening ThinManager	63
ThinManager Graphic User Interface	64
Tree Pane	65
Icons.....	66
Tree Icons	66
Details Pane.....	74
ThinManager Server Detail Tabs	74
Terminal Group Detail Tabs.....	75
Terminal Detail Tabs.....	76
Terminal Server Detail Tabs	77
Modifying a Terminal.....	80
Deleting a Terminal.....	80
Restarting a Terminal.....	80
Rebooting a Terminal.....	80
Renaming a Terminal.....	81
Menu Items	83
<u>E</u> dit.....	83
Add <u>T</u> erminal.....	83
Add <u>T</u> erminal <u>G</u> roup.....	83
Add ThinManager <u>S</u> erver.....	83
Remove ThinManager Server.....	85
<u>D</u> elete.....	85
<u>M</u> odify.....	86
<u>R</u> ename.....	86
<u>L</u> ock.....	86
<u>U</u> nlock	86
<u>F</u> ind	87
<u>F</u> ind <u>N</u> ext.....	87
<u>M</u> anage	88
ThinManager Server List.....	88
TermSecure <u>A</u> ccess Groups.....	88
<u>D</u> NS Configuration	89
<u>C</u> onfigure Default Terminal	89
<u>R</u> estore Configuration	89
<u>B</u> ackup Configuration.....	90
<u>S</u> ynchronize Configuration.....	90
<u>R</u> econnect	91
<u>D</u> isconnect	91
<u>I</u> nstall.....	91
<u>L</u> icenses	91
<u>M</u> odules.....	92
<u>R</u> eports (Installation).....	93
<u>F</u> irmware	96
<u>T</u> ermCap Database.....	96
<u>T</u> ools	97
Restart Terminals.....	97

<u>R</u> eboot Terminals.....	98
Reboot Terminal Server.....	98
<u>D</u> isable Terminals.....	98
Enable Terminals.....	99
Disable Terminal Server.....	100
Enable Terminal Server.....	100
<u>C</u> alibrate Touch Screen.....	100
Send Message.....	101
Clear Event Log.....	102
<u>V</u> iew.....	102
Status Bar.....	102
Show <u>C</u> onected Only.....	102
<u>R</u> eports (Selection).....	102
<u>P</u> rint.....	103
Options.....	104
<u>R</u> emoteView.....	105
Interactive Shadow.....	105
Scaled to Window.....	105
Go <u>F</u> ullScreen.....	106
Connect <u>O</u> ptions.....	106
Send <u>K</u> ey.....	107
<u>H</u> elp.....	107
Help Topics.....	107
<u>A</u> bout ThinManager.....	107
Right Click Menus in the Tree Pane.....	108
Right Click on the ThinManager Server Icon.....	108
Right Click on the Terminals Branch Icon.....	108
Right Click on a Terminal Group Icon.....	108
Right Click on a Terminal Icon.....	109
Right Click on the Display Servers Terminal Servers Branch Icon.....	109
Right Click on a Terminal Server Icon.....	109
Right Click on the VCenter Servers Branch Icon.....	110
Right Click on the Display Client Branch Icon.....	110
Right Click on a Display Client Member Icon.....	110
Right Click on the TermSecure Users Branch.....	112
Right Click on a TermSecure Users Group Icon.....	112
Right Click on a TermSecure Users Icon.....	112

Adding Thin Client Hardware 113

The Boot Process.....	113
IP Address Assignment.....	114
DHCP.....	114
Static IP.....	116
Hybrid IP Addressing.....	118
Configuring New Hardware.....	119
Create New Terminal Mode.....	119
Replace or Create New Terminal Mode.....	120
Auto-Creation of Terminals.....	120
Enabling AutoCreate.....	121
Configuring Default Terminal.....	122

Configuration Wizards 125

Introduction to Wizards.....	125
List Wizards.....	126

Configuration Wizards.....	126
ThinManager Server List.....	129
Automatic Synchronization	130
Defining ThinManager Servers for Manual Synchronization	134
Manual Synchronization.....	136
ThinManager Server Configuration Wizard	141
DNS Configuration	161
Terminal Configuration	165
Terminal Configuration Wizard	165
Terminals Using Individual Terminal Servers	174
Terminals Using Display Clients	178
Display Client Selection	179
Continuation of the Terminal Configuration	187
Terminal Group Configuration Wizard	203
Changing a Terminal's Group	207
Unique Group Configurations	211
Display Servers	215
Terminal Services Display Servers	215
Camera Configuration Wizard.....	224
IP Camera Group Configuration	228
IP Camera Administration	230
Display Clients	231
Display Client List	231
Terminal Services Display Clients	234
Camera Display Clients	244
Adding a Camera Overlay to a Display Client	256
Camera Overlays and TermMon ActiveX Control.....	259
Terminal Shadow Display Clients	260
Failover and Instant Failover	267
Failover Introduction	267
Failover	267
Failover Setup For a Terminal Using Terminal Services Display Clients	269
Instant Failover.....	272
Instant Failover Configuration	275
Instant Failover Setup using Terminal Services Display Clients	275
Switching Between Instant Failover Sessions	277
Switching Between Sessions with Display Clients.....	278
Instant Failover Tree Icons	279
Modules	281
Module Overview	281
Module List.....	281
Installing a Module	284
Adding a Module to a Group or Terminal.....	287
Changing Module Parameters	290
Individual Module Details	293
ICA Modules.....	293
Citrix ICA UseAlternateAddress Module	293

Citrix ICA wfclient.ini Extension Module	294
Keyboard Modules	294
Key Block Module	294
Key Block Single Key Module	294
Keyboard Configuration Module	295
Local Storage Modules	296
USB Flash Drive Module.....	296
USB Memory Card Reader Module	297
Miscellaneous Modules.....	297
Add Serial Port	297
Firmware Update (Disk On Chip / Compact Flash) Update Module.....	297
Local Print Module	299
MultiMonitor Module.....	302
Redundant Ethernet Module	303
Second Network Module.....	303
Terminal Shadow Module	304
TermMon ActiveX Configuration Module	304
Terminal Shadow Module	304
Time Zone Redirection Module.....	304
User Override Module.....	305
Mouse Modules.....	306
Mouse Configuration Module	306
PS/2 Mouse Module.....	307
Serial Mouse Driver	307
Share Keyboard and Mouse Modules	307
RDP Modules	311
RDP Experience Module.....	311
RDP Module for ThinManager v2.4 and Older	312
RDP Port Module	312
RDP Serial Port Redirection Module	313
RDP Session IP Module	316
Screen Saver Modules.....	317
MultiSession Screen Saver Module.....	317
Screen Saver Module	318
Sound Modules	319
TermSecure Modules.....	321
RF Ideas pcProx Module	321
RF Ideas pcProx USB Module	322
TermMon ActiveX Configuration.....	322
USB Flash Drive Module.....	323
Wavetrend Tag Reader.....	323
Touch Screen Modules	324
USB Touch Screen Driver Module.....	326
Video Driver Modules.....	327
Advanced Modules	327
ICA Client Version 6.0/ ICA Client Version 8.0	328
Instant Failover Module.....	328

Citrix ICA 331

Terminals Using Display Clients with ICA.....	331
Display Client Configuration Wizard	332
Terminal Using Citrix and Individual Terminal Servers.....	334

Hotkeys 339

Terminal Configuration Wizard Hotkeys Display Clients	339
Multiple Monitors	349
Introduction to Multiple Monitors	349
Share Keyboard and Mouse Modules	349
MultiMonitor.....	353
Virtualization in ThinManager	367
Virtualization Overview	367
VCenter Servers.....	367
VCenter Server Right-Click Menus.....	372
Virtual Terminal Servers	375
Virtual Workstations	379
Workstation Display Clients	379
Terminals and Virtual Workstations	383
Scheduling	389
Terminal Schedule	389
Terminal Server Schedule	393
ThinManager Server Schedule	396
TermSecure User Schedule.....	400
Reports	405
Reports.....	405
Report Template Installation	405
Selecting Reports.....	407
Report Tab	408
Print Report.....	409
Scheduling Reports.....	410
Changing the Report Logo.....	415
WinTMC Fat Client	417
WinTMC Overview	417
Local WinTMC Configuration	417
WinTMC Configuration in ThinManager	420
MultiMonitor WinTMC	424
WinTMC Modules	425
WinTMC Licensing.....	425
Shadowing	427
ThinManager Shadow.....	427
Shadow Access	428
Configure Shadowing.....	429
Shadow Keystrokes	430
Terminal-to-Terminal Shadowing.....	431
ThinManager Security	437
ThinManager Security Groups.....	437
ThinManager Server Security	441
Windows Security	443

TermSecure	445
TermSecure Overview	445
Users Types	446
Windows Users	446
TermSecure Users	446
ThinManager Security Group Users	446
Deploying TermSecure	446
Permissions	447
Creating Permissions Groups	447
Permission Groups for Terminals	450
Permission Groups for Display Clients	452
Permission Groups for TermSecure Users	454
Shortcut Method of Adding TermSecure Access Groups	461
TermSecure User Configuration Wizard	465
TermSecure Users Group Configuration Wizard	480
Adding a TermSecure User to the TermSecure User Group	483
TermSecure Login	488
Logging Out	490
TermSecure Menu	491
Card and Badge Configuration for a TermSecure User	497
Automatic Card/Badge ID Number Entry	498
Manual Card/Badge ID Number Entry	502
TermMon ActiveX Control	509
Registering the Control	509
Using the Control	509
TermMon ActiveX Configuration Module	509
Read-Only Properties	509
Read-Write Properties	510
Events	510
Methods	511
Control Constants	515
TermMon ActiveX Demo Application	516
Non-ThinManager Components	519
Server 2003	519
Installing Terminal Services	519
Creating Microsoft User Profiles	522
Software Installation On Windows 2003	524
Terminal Services Configuration	527
Terminal Services Connections	528
Terminal Services Connections	533
Licensing Mode	534
Permission Compatibility	535
Restrict Each User to a Single Session	536
License Server Discovery Mode	536
Windows 2008 Server	538
Adding Terminal Server Role	538
Adding Applications in Windows 2008	543
Create Users	543
Allowing Application Access	544
Installing ThinManager	547

Allow Inbound Traffic to Firewall.....	549
Local Security Policy – User Access Controls.....	557
Command Prompt.....	558
Alternative Terminal Keystrokes.....	559
DHCP Server Setup.....	560
Group Policy.....	562
Microsoft Licenses.....	563
Microsoft Client Access Licenses (CALs).....	563
Microsoft Terminal Server Licenses.....	563
Microsoft Terminal Server Licensing Activation.....	563
ThinManager Troubleshooting Guide	565
Section 1 - From Power on to Terminal Server Login.....	565
Section 2 - Thin Client is Booted, Connected, and Running a Session on the Terminal Server.....	568
Glossary of Terms	571
Index	579